

Digital SNA Data Transfer Facility for OpenVMS

Management

Part Number: AA-JM78F-TE

May 1996

This document provides information needed to manage the Digital SNA Data Transfer Facility (DTF) product.

Revision/Update Information: This is a revised manual.

Operating System and Version: OpenVMS VAX Versions 6.1, 6.2, or 7.0
OpenVMS Alpha Versions 6.1, 6.2, or 7.0

Software Version: Digital SNA Data Transfer Facility for
OpenVMS, Version 3.2

May 1996

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation or EDS. Digital Equipment Corporation or EDS assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

Digital conducts its business in a manner that conserves the environment.

Restricted Rights: Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Copyright © 1988, 1996 Digital Equipment Corporation, EDS Defense Limited
All Rights Reserved.

The following are trademarks of Digital Equipment Corporation: Alpha, DEC, DEC/CMS, DEC/MSS, DECnet, DECSYSTEM-10, DECSYSTEM-20, DECUS, DECwriter, DIBOL, EduSystem, IAS, MASSBUS, OpenVMS, PDP, PDT, RSTS, RSX, UNIBUS, VAX, VAXcluster, VMS, VT, and the Digital logo.

IBM is a registered trademark of International Business Machines Corporation.

MS-DOS is a registered trademark of Microsoft Corporation.

Contents

Preface	v
1 Configuring the OpenVMS/DTF Server After Installation	
1.1 Configuring the OpenVMS/DTF Software	1-1
1.1.1 Invoking and Exiting from the SNADTF CFG Utility	1-2
1.1.2 Naming a Default Server Node	1-2
1.1.3 Setting Up the OpenVMS/DTF Server Account Database ...	1-3
1.1.3.1 Adding and Modifying Entries in the Server Account Database	1-4
1.1.4 Creating OpenVMS Accounts for DTF Server Accounts	1-7
1.1.5 IBM-Initiated Proxy	1-8
1.1.5.1 How Does IBM-Initiated Proxy Work?	1-8
1.1.5.2 Example of an IBM-Initiated Transfer Request with DTF	1-9
1.1.5.3 Example of an IBM-Initiated Transfer Request	1-11
1.1.6 Setting Up the File Definition Database	1-14
1.1.6.1 Adding Entries to the File Definition Database	1-14
1.2 Setting DTF Operating Parameters	1-15
1.2.1 DTF Queues	1-16
1.2.2 The OpenVMS/DTF Server Operating Parameters	1-16
1.2.3 The OpenVMS/DTF Client Operation Parameters	1-18
2 Maintaining the OpenVMS/DTF Server Account Database	
2.1 Adding and Modifying Entries in the Server Account Database	2-1
2.2 Displaying Server Account Name Information	2-6
2.3 Removing a Server Account Name	2-8

3 Maintaining the OpenVMS/DTF File Definition Database

3.1	Adding Entries to the File Definition Database	3-1
3.2	Displaying File Definition Attributes	3-3
3.3	Modifying a File Definition	3-5
3.3.1	Modifying the File Definition BASE Section	3-5
3.3.2	Modifying File Definition ALTERNATE_INDEX Sections ...	3-7
3.4	Removing an Entry from the File Definition Database	3-8

A Messages

A.1	OpenVMS/DTF Messages	A-2
-----	----------------------------	-----

B Maintaining the OpenVMS/DTF Proxy Database

B.1	Enabling the Proxy Database	B-1
B.1.1	Automatic Update of the Proxy Database	B-2
B.1.2	Option to Disable Automatic Update to the Proxy Database	B-2
B.2	Disabling the Proxy Database	B-3
B.3	Adding and Modifying Entries in the Proxy Database	B-3
B.4	Displaying Entries in the Proxy Database	B-6
B.5	Removing an Entry from the Proxy Database	B-9

Index

Figures

1-1	IBM-Initiated Access: DECnet Client Node Running DTF ..	1-10
1-2	IBM-Initiated Access: DECnet Client Node Not Running DTF	1-12

Tables

1-1	Qualifiers Used for Server Account Commands	1-5
-----	---	-----

Preface

The Digital SNA Data Transfer Facility (DTF) software is a Digital Equipment Corporation product that allows you to transfer files between IBM VM and MVS systems in an SNA network and systems in a Digital network. To use the DTF access routine, you must first install the appropriate versions of the software and hardware that you plan to use. Refer to the Software Product Description (SPD) for this information.

The DTF access routine consists of two major parts: the IBM-resident software (DTF for IBM) and the Digital-resident software (OpenVMS/DTF). This manual describes all the commands that OpenVMS system managers need to use the SNA DTF Configuration (SNADTFCFG) utility to configure the OpenVMS/DTF server.

Intended Audience

This manual is designed for system managers who configure and manage the OpenVMS/DTF product.

Changes and New Features

The Digital SNA Data Transfer Facility for OpenVMS, Version 3.2 differs from the Version 3.1 product only in that it includes support for utilizing TCP/IP to communicate between TE and the Gateways (Domain and/or Peer Server).

The information relevant to TCP/IP transport support include:

- SNA_TCP_PORT logical
- SNA_TRANSPORT_ORDER logical
- Specifying TCP/IP hostnames

SNA_TCP_PORT Logical

The SNA_TCP_PORT logical refers to the remote connection TCP/IP port. The default connection TCP/IP port number is 108. For example, if you want the remote connection TCP/IP port number to be 1234, you can enter the following command line:

```
$ define SNA_TCP_PORT 1234
```

If you want the remote connection TCP/IP port to be made to a service defined and enabled in the UCX database; for example *service_name*, you can enter the following command line:

```
$ define SNA_TCP_PORT service_name
```

SNA_TRANSPORT_ORDER Logical

The SNA_TRANSPORT_ORDER logical refers to a transport list, which is used in automatic selection of transports. Connections are attempted once for each transport in the list until either a successful connection is made, or an error is returned when all transports in the list fail to connect.

For example, if you want the software to try the DECnet transport and if this fails then to try the TCP/IP transport, you can enter the following command line:

```
$ define SNA_TRANSPORT_ORDER "decnet, tcp"
```

If you want the software to try the TCP/IP transport and if this fails then to try the DECnet transport, you can enter the following command line:

```
$ define SNA_TRANSPORT_ORDER "tcp, decnet"
```

If you want the software to never try the DECnet transport and to try only the TCP/IP transport, you can enter the following command line:

```
$ define SNA_TRANSPORT_ORDER "nodecnet, tcp"
```

If you want the software to never try the TCP/IP transport and to try only the DECnet transport, you can enter the following command line:

```
$ define SNA_TRANSPORT_ORDER "decnet, notcp"
```

Note

If the SNA_TRANSPORT_ORDER logical is not defined, the default transport order for OpenVMS Alpha will be decnet, tcp; and the default transport order for OpenVMS VAX will be local, decnet, tcp.

Specifying TCP/IP Hostnames

If you want to specify a full path hostname, the hostname must be enclosed in a pair of double-quotes; for example, "foo.bar.company.com".

If you want the TCP/IP transport to be used as the preferred transport, without specifying a TCP/IP full path hostname, then define the SNA_TRANSPORT_ORDER with "tcp" as the first element in the transport list.

If the hostname ends with a single full-colon (":"), then the TCP/IP transport will be used; for example, "foo:" or foo:.

Note

If you specify a double full-colon ("::"), you force the DECnet transport to be used; for example, "foo::" or foo::.

Document Structure

This document is divided into the following three chapters and two appendixes.

Chapter 1	Describes the OpenVMS/DTF configuration concepts that a system manager must understand to configure OpenVMS/DTF.
Chapter 2	Describes how to maintain the OpenVMS/DTF server database.
Chapter 3	Describes how to maintain the file definition database.
Appendix A	Describes all OpenVMS/DTF configuration utility (SNADTF CFG) messages.
Appendix B	Describes how to maintain the OpenVMS/DTF proxy database.

The postage-prepaid Reader's Comments form on the last page of this manual is for your critical evaluation to assist us in preparing future documentation.

Associated Documents

The Digital SNA Data Transfer Facility software documentation consists of the following manuals:

- *Digital SNA Data Transfer Facility for OpenVMS Installation*
- *Digital SNA Data Transfer Facility for OpenVMS Management*
- *Digital SNA Data Transfer Facility for OpenVMS Problem Solving and Messages*

- *Digital SNA Data Transfer Facility for OpenVMS Use*

You should have the following Digital documents available for reference when you use the Digital SNA Data Transfer Facility software:

- *Common Data Dictionary Summary Description*
- *Common Data Dictionary User's Guide*
- *Common Data Dictionary Utilities Reference*
- *Common Data Dictionary Data Definition Language Reference*
- *Digital SNA Domain Gateway Installation*
- *Digital SNA Domain Gateway Management*
- *Digital SNA Domain Gateway Guide to IBM Resource Definition*
- *DECnet SNA Gateway Problem Determination Guide*
- *DECnet SNA Gateway-CT Installation*
- *DECnet SNA Gateway-CT Problem Solving (OpenVMS & ULTRIX)*
- *DECnet SNA Gateway-CT Management (OpenVMS)*
- *DECnet SNA Gateway-CT Guide to IBM Parameters*
- *DECnet SNA Gateway-ST Installation*
- *DECnet SNA Gateway-ST Problem Solving (OpenVMS)*
- *DECnet SNA Gateway-ST Guide to IBM Parameters*
- *DECnet SNA Gateway Management for OpenVMS*
- *Digital Peer Server Installation and Configuration*
- *Digital Peer Server Management*
- *Digital Peer Server Network Control Language Reference*
- *Digital Peer Server Guide to IBM Resource Definition*
- *OpenVMS SNA Installation*
- *OpenVMS SNA Problem Solving*
- *OpenVMS SNA Guide to IBM Parameters*
- *OpenVMS SNA Management*
- *OpenVMS SNA Problem Determination Guide*

OpenVMS client users may also find the following Digital OpenVMS manuals to be helpful:

- *OpenVMS User's Manual*
- *OpenVMS Record Management Utilities Reference Manual*
- *DEC DATATRIEVE User's Guide*
- *OpenVMS DCL Dictionary*
- *VMS DCL Concepts Manual*
- *Guide to OpenVMS File Applications*

ULTRIX client users may also find the following Digital DECnet-ULTRIX manual to be helpful:

- *DECnet-ULTRIX Use*

DOS client users may also find the following PATHWORKS for DOS manual to be helpful:

- *PATHWORKS for DOS DECnet User's Guide*

OS/2 client users may also find the following PATHWORKS for OS/2 manual to be helpful:

- *PATHWORKS for OS/2 Utilities Guide*

IBM client users may also find the following IBM manuals to be helpful:

- *JCL Reference*
- *CMS Primer*
- *IBM Access Method Services*

The following IBM manuals provide additional reference information that could be helpful in problem determination:

- *DFP: Access Method Services Reference*
- *IBM VTAM Customization*
- *MVS JCL Reference Manual*
- *MVS Service Aids Manual*
- *MVS System Commands*
- *MVS System Messages*
- *VTAM Operator Commands*

- *VM Planning and Reference*
- *VM/SP6 Connectivity, Planning, and Administration*
- *VM/SP5 TSAF*

Acronyms

The following acronyms are used throughout this manual:

ASCII	American Standard Code for Information Interchange
DCL	Digital Command Language
DMCS	Digital Multinational Character Set
DTF	Digital SNA Data Transfer Facility software
EBCDIC	Extended Binary Coded Decimal Interchange Code
ESDS	Entry Sequenced Data Set
GDG	Generation Data Group
HSM	IBM's Hierarchical Storage Manager
IBM MVS	IBM's Multiple Virtual Storage
IBM SNA	IBM's Systems Network Architecture
IBM VM	IBM's Virtual Machine
ISPF	Interactive System Productivity Facility
KSDS	Key Sequenced Data Set
MS-DOS	Microsoft Corporation's DOS operating system
NFT	Network File Transfer utility
PDS	Partitioned Data Set
REXX	Restructured Extended Executor
RRDS	Relative Record Data Set
SMS	IBM's Storage Management Subsystem
SNADTF CFG	SNA DTF Configuration utility
TRANSFER/DTF	SNA DTF Transfer utility
TSO	IBM's Time Sharing Option
ULTRIX	Digital's UNIX-based operating system
OpenVMS/DTF	Digital-resident Data Transfer Facility software
OpenVMS	The OpenVMS operating system
VSAM	IBM's Virtual Storage Access Method

Conventions Used in this Document

The following conventions are used throughout this manual:

Special type	System output and user input appears in this type.
UPPERCASE	Uppercase letters in command lines indicate keywords that must be entered. You can enter keywords in either uppercase or lowercase. You can abbreviate command keywords to the first three characters or their minimum unique abbreviation.
<i>lowercase italics</i>	Lowercase italics in command syntax or examples indicate variables for which either the user or the system supplies a value.
<code>CTRL/x</code>	Hold down the CTRL key and press the key specified by <i>x</i> .
[]	Square brackets in command syntax statements indicate that the enclosed value is optional. You can enter none or one. Default values apply for unspecified options. (Do not type the brackets when you enter a command.)
<code>Return</code>	Press the RETURN key. The RETURN key, which you must press to execute commands, is assumed in command examples and therefore is not always shown in command displays.
<code>VM</code>	Instructions or comments that apply to the IBM/VM operating system only.
<code>MVS</code>	Instructions or comments that apply to the IBM/MVS operating system only.

1

Configuring the OpenVMS/DTF Server After Installation

Before proceeding with the tasks described in this chapter, you should install the OpenVMS/DTF server software on the nodes you have selected to be OpenVMS/DTF servers. You can also optionally install the OpenVMS/DTF utilities software on additional OpenVMS client nodes. Since the OpenVMS/DTF server software includes the OpenVMS/DTF utilities software, do not install the utilities software on your server nodes. For information about installing OpenVMS/DTF software, refer to the *Digital SNA Data Transfer Facility for OpenVMS Installation* manual.

After you have successfully installed OpenVMS/DTF software, you should perform the following tasks as described in this chapter:

- Configure the OpenVMS/DTF software.
- Set the OpenVMS/DTF operating parameters.

1.1 Configuring the OpenVMS/DTF Software

Before users can transfer files between Digital and IBM systems, you must perform the following configuration tasks to set up the OpenVMS/DTF databases:

- Set up the OpenVMS/DTF server account database.
- Authorize access to server accounts.
- Optionally, set up the OpenVMS/DTF file definition database.
- Optionally, set up the OpenVMS/DTF proxy database.

1.1.1 Invoking and Exiting from the SNADTF CFG Utility

To invoke the SNADTF CFG utility enter the following command:

```
$ MCR SNADTF CFG
```

The SNADTF CFG utility then returns the following prompt:

```
DTF CFG>
```

Once you receive this prompt, you can enter SNADTF CFG commands. To exit from the SNADTF CFG utility, type EXIT or press `CTRL/Z` after the DTF CFG> prompt.

1.1.2 Naming a Default Server Node

The SNADTF CFG utility allows you to manage multiple OpenVMS/DTF servers from a single node. To name an OpenVMS/DTF server node other than the local node as the default server node, use the USE [NO]NODE command. The node you specify is used as the default node when you are performing operations with other SNADTF CFG commands. If you do not define a default server node, the default is the local node.

The default OpenVMS/DTF server node is set with the USE NODE command and can be cleared with the USE NONODE command. The USE NONODE command returns the default node to the local node. You can override the default node at any time by simply including a node name with the access control information when you specify a server account or a file definition.

```
USE [NO]NODE [node["access-control">::]
```

Note

You cannot use the NONODE keyword with the *node* parameter.

Command Parameters

[*node*["*access-control*">::]

The *node* parameter specifies the OpenVMS/DTF server node at which records are added, modified, displayed, or removed from any of the databases. If the double colon (::) is not provided, SNADTF CFG appends a double colon to the node name.

The *access-control* parameter specifies the name and password of an account with read and write access to all the OpenVMS/DTF databases. The account name is usually SNADTF\$MGR.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

Example

```
DTFCFG> USE NODE BUFFALO"SNADTF$MGR SECRET"
```

This example defines BUFFALO as the default server node for other SNADTFCFG commands (ADD, MODIFY, REMOVE, and SHOW). The access control information within double quotation marks (" ") consists of an account name (SNADTF\$MGR) and password (SECRET) for an account with read and write access to all the OpenVMS/DTF databases.

1.1.3 Setting Up the OpenVMS/DTF Server Account Database

An OpenVMS/DTF server account database is automatically created with initial server accounts (SNADTF and SNASERVER) as part of the OpenVMS/DTF server installation procedure. After installation you should set up the server account database by modifying the SNADTF and SNASERVER server accounts using the MODIFY SERVER_ACCOUNT command. You can then add additional server accounts with the ADD SERVER_ACCOUNT command.

You use server accounts to specify the information OpenVMS/DTF requires to access an IBM system. You will need to set up several server accounts on a single OpenVMS/DTF server node if your server node will be doing one or more of the following:

- Accessing more than one IBM system
- Using more than one Digital SNA Gateway to access a single IBM system
- Using more than one copy of DTF for IBM on a single IBM system
- Using more than one physical unit (PU) or logical unit (LU) on a Digital SNA Gateway
- Using more than one access name on a single PU or LU on the Digital SNA Gateway

All communications between DECnet nodes or TCP/IP hosts and IBM systems are defined in terms of two types of sessions: server sessions and transfer sessions. Server sessions route transfer requests received from IBM DTF users to DECnet nodes or TCP/IP hosts capable of handling the requests. Transfer sessions pass the actual data to and from DECnet nodes or TCP/IP hosts and DTF for IBM software.

You should create different server accounts for each session type. The server session should have an IBM request/response unit (RU) size of at least 800 bytes, while transfer sessions can have varying RU sizes depending upon the application. You can change the RU sizes through the IBM logon mode tables used for your server account. Section 1.2 describes how to modify your system startup file so that you can specify a different server account for the transfer session.

Each server account allows you to specify information about the qualifiers described in Table 1-1.

1.1.3.1 Adding and Modifying Entries in the Server Account Database

To modify the SNADTF and SNASERVER server accounts, use the MODIFY SERVER_ACCOUNT command:

```
MODIFY SERVER_ACCOUNT[/qualifiers] [node["access-control"]::]server-account-name
```

To add a new server account name to the server account database, use the ADD SERVER_ACCOUNT command:

```
ADD SERVER_ACCOUNT[/qualifiers] [node["access-control"]::]server-account-name
```

The parameters and qualifiers for the ADD and MODIFY commands are identical and are described in the sections that follow.

For more detailed information about each of these commands and their parameters and qualifiers, see Chapter 2.

Command Parameters

[node["access-control"]::]

The *node* parameter specifies the OpenVMS/DTF server node on which the server account database resides. If you omit the *node* parameter from the ADD SERVER_ACCOUNT command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the name and password of an account on the server node with read and write access to all the databases. The account name is usually SNADTF\$MGR.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

server-account-name

The name for the server account in the OpenVMS/DTF server account database.

Command Qualifiers**Table 1–1 Qualifiers Used for Server Account Commands**

<i>/ACCESS_NAME=access-name</i>	Specifies the Digital SNA Gateway, OpenVMS SNA (OpenVMS VAX Version 6.1 and Version 6.2 only) access name. See the Digital SNA Gateway manager for this name.
<i>/APPLICATION_NAME=application-name</i>	Specifies the DTF for IBM application name. See the IBM system programmer for this name.
<i>/FILE_DEFINITION=file-definition</i>	Specifies the name of the default file definition to use for this server account. See Section 1.1.6 for more information.
<i>/GATEWAY=gateway-node</i>	Specifies the SNA Gateway DECnet node name, TCP/IP host name, or OpenVMS SNA name used to access the IBM system.
<i>/[NO]IBM_PREFIX</i>	Specifies a 0 to 4 character prefix string that will be used by DTF to prefix the IBM user name when using IBM-initiated proxy. See Chapter 2 for more information.
<i>/[NO]LOG</i>	Specifies if an information message confirming the operation is desired.
<i>/LOGON_MODE=logon-mode</i>	Specifies the IBM logon mode value. See the IBM system programmer for this value.
<i>/NODE=dtf-file-service-node</i> VM	Specifies the IBM system's physical node name in a Transparent Services Access Facility (TSAF) collection. See the IBM system programmer for this value.
<i>/NULL=vm-null-qualifier</i>	Specifies the response OpenVMS/DTF should use when it encounters null records during a transfer to VM systems. See Chapter 2 for more information.

(continued on next page)

Table 1–1 (Cont.) Qualifiers Used for Server Account Commands

<code>/PU=<i>pu-name</i> <i>lu-name</i></code>	Specifies the physical unit (PU) to use on the DECnet SNA Gateway, or OpenVMS SNA. Specifies the logical unit (LU) to use on Digital SNA Domain Gateway or Digital SNA Peer Server. See the SNA Gateway manager for this name.
<code>/SERVICE_MACHINE=<i>virtual-machine-name</i> VM</code>	Specifies the name of the VM virtual machine running the DTF for IBM software. See the IBM system programmer for this value.
<code>/SESSION_ADDRESS=<i>session</i></code>	Specifies the logical unit (LU) to use on the DECnet SNA Gateway, or OpenVMS SNA. See the Digital SNA Gateway manager for this name. This information is ignored when connecting to a Digital SNA Domain Gateway or Digital SNA Peer Server. See the /PU qualifier for information on how to specify an LU to use in these gateways.
<code>/[NO]TRANSLATION=<i>translation-location</i></code>	Specifies the location (either LOCAL or REMOTE) where data translation should occur. See Chapter 2 for more information.

Example 1

```
DTFCFG> MODIFY SERVER_ACCOUNT/GATEWAY=SNAGWY/ACCESS_NAME=DTF-
_DTFCFG> /APPLICATION=DTFV302/PU=SNA-0/LOGON=R8129/NULL=IGNORE -
_DTFCFG> SNASERVER
```

This example modifies entry SNASERVER in the server account database on the local node. The /GATEWAY qualifier specifies that the node SNAGWY provides access to the IBM system referenced by SNASERVER. The /ACCESS_NAME qualifier specifies that the access name DTF on the SNA Gateway contains the proper information for accessing the IBM system. The /APPLICATION, /PU, and /LOGON qualifiers specify information about the access name. The /NULL qualifier specifies that the default action will be to ignore null records during transfers to VM systems. The OpenVMS/DTF software uses this information when starting the server session SNASERVER.

Example 2

```
DTFCFG> MODIFY SERVER_ACCOUNT/GATEWAY=SNAGWY/ACCESS_NAME=DTF-
_DTFCFG> /APPLICATION=DTFV302/PU=HOIDEOIE/LOGON=R8129/NULL=IGNORE -
_DTFCFG> SNASERVER
```

This example is just like Example 1, except an LU name is specified in the /PU qualifier.

1.1.4 Creating OpenVMS Accounts for DTF Server Accounts

Every OpenVMS/DTF server account used for a transfer session must contain a corresponding entry in the OpenVMS user authorization file (UAF). After adding a server account, you must also add the UAF record with the Authorize utility. You can use the following sequence of commands to invoke the Authorize utility:

```
$ SET DEFAULT SYS$SYSTEM
$ RUN AUTHORIZE
```

The system responds with the following prompt:

```
UAF>
```

Then enter either of the following commands.

```
UAF> COPY SNADTF new-server-acct-name/NOADD_IDENTIFIER/NOPASSWORD
```

```
UAF> COPY SNADTF new-server-acct-name/NOADD_ID/PASSWORD=new-pass
```

You must supply the new server account name and you can supply an optional password. All the default authorization characteristics are then copied from the default SNADTF server account to your new server account. Refer to the *OpenVMS System Management Utilities Reference* manual for more information about using the Authorize utility.

If you decide to add a password to the server account, you should use the /PASSWORD qualifier. If you do not specify the /NOADD_IDENTIFIER qualifier an error message is reported which you can ignore.

If the server account is not given a password, all users on any OpenVMS/DTF client node or server node can use DTF. However, they can access IBM-resident files only if they know the IBM file's correct access control.

1.1.5 IBM-Initiated Proxy

IBM-initiated proxy allows the IBM user to submit a request with the DECnet file specifications without specifying the DECnet password. Refer to the chapter on data security in the *Digital SNA Data Transfer Facility for OpenVMS Use* for more information on IBM-initiated proxy. For information on adding proxy entries, refer to the Authorize Utility in *OpenVMS System Management Utilities Reference* manual.

1.1.5.1 How Does IBM-Initiated Proxy Work?

The proxy concept is based on a pseudo-IBM user name constructed from an optional prefix string attached to the actual IBM user name. The prefix string can be 0 to 4 characters long. The prefix is the differentiator between an IBM user name and an OpenVMS user name that happen to be the same. For example, an IBM user name CURRIE might become the pseudo-IBM user name, IBM_CURRIE.

You can specify IBM prefixes on a server-by-server basis using the ADD SERVER command. See Chapter 2 for more information on IBM prefixes.

OpenVMS/DTF uses the pseudo-IBM user name in the following ways.

With DTF Running on the Client Node

1. The dispatcher user name changes to the pseudo-IBM name before connecting to the SNARCOPY object on the client node.
2. If there is a DECnet proxy entry, and SNARCOPY is running on the client node, the connect to the client SNARCOPY succeeds and the transfer runs to completion.

Without DTF Running on the Client Node

1. Access fails when the SNADTF\$DISPATCHER tries to connect to the SNARCOPY object on the client node.
2. The dispatcher invokes SNARCOPY from the server node through DTF\$SERVER.
3. SNARCOPY on the server node runs and changes its user name to the pseudo-IBM user name. (The node name in the request will now be the server node name, and the user name will be the pseudo-IBM user name, *server-node::pseudo-ibm-name*.)
4. If there is a DECnet proxy entry on the client node, SNARCOPY on the server node is able to access the files on the client node and the copy runs to completion.


Note

Before proxy can work, the user must ask the OpenVMS system manager of the remote DECnet system to enter a proxy entry coming from the *server-node::pseudo-account-name* and accessing the local account name. This one proxy entry will work regardless of whether SNARCOPY is on the remote node or not.

1.1.5.2 Example of an IBM-Initiated Transfer Request with DTF

Figure 1-1 illustrates a request made from a user on an IBM client system for DTF services. The remote DECnet node is running DTF. Note that the DECnet SNA Gateway can also represent a Digital SNA Domain Gateway or Digital SNA Peer Server, where you can use TCP/IP interchangeably with DECnet.

Figure 1-1 IBM-Initiated Access: DECnet Client Node Running DTF



LKG-5493-93R

1. IBM user MARTIN issues a DTF command to access files owned by BOSTON"JONES".
2. The SNADTF\$DISPATCHER on server node TAMPA receives the request.
3. The dispatcher, SNADTF\$DISPATCHER, connects to the SNARCOPY object on BOSTON by using the user name IBM_MARTIN. (For this example, assume the prefix was set to IBM_.) BOSTON receives the connection to the SNARCOPY object from remote user TAMPA::IBM_MARTIN.
4. DECnet proxy checks whether user TAMPA::IBM_MARTIN is set up for access to JONES. If the proxy entry is defined, SNARCOPY runs under the JONES account.


Node BOSTON requires the following OpenVMS proxy entry:

```
$ MCR AUTHORIZE
UAF> ADD/PROXY TAMPA::IBM_MARTIN JONES
```

1.1.5.3 Example of an IBM-Initiated Transfer Request

Figure 1-2 illustrates a request made from an IBM user for DTF services. The remote DECnet node is not running DTF. Note that the DECnet SNA Gateway can also represent a Digital SNA Domain Gateway or Digital SNA Peer Server, where you can use TCP/IP interchangeably with DECnet.

Figure 1-2 IBM-Initiated Access: DECnet Client Node Not Running DTF



LKG-5632-93R

1. IBM user MARTIN issues a DTF command to access files owned by NASHUA"RAFAL".
2. The SNADTF\$DISPATCHER on server node TAMPA receives the request.
3. SNADTF\$DISPATCHER changes its name to the IBM user name and tries to connect to the SNARCOPY object on NASHUA. SNARCOPY is not running on NASHUA. The connection fails.
4. SNADTF\$DISPATCHER connects to the SNARCOPY object on server node TAMPA. SNARCOPY changes its name to the IBM user name. SNARCOPY uses the user name IBM_MARTIN to complete the request. (For this example, assume the prefix was set to IBM_.)
5. NASHUA sees that TAMPA::IBM_MARTIN is trying to access a file in the RAFAL account. DECnet proxy checks if user TAMPA::MARTIN is set up for access to RAFAL. If the proxy entry is defined, the request continues.

Node NASHUA requires the following OpenVMS proxy entry:

```
$ MCR AUTHORIZE
UAF> ADD/PROXY TAMPA::IBM_MARTIN RAFAL
```

1.1.6 Setting Up the File Definition Database

A file definition database is automatically created as part of the OpenVMS/DTF server installation procedure. After installation, you may wish to add file definitions with the ADD FILE_DEFINITION command.

A file definition provides users with a short cut for specifying IBM file creation parameters. A file definition consists of a collection of default IBM file creation parameters under a single file definition name. Users can specify the file definition name instead of entering individual IBM file specification qualifiers when transferring files with a COPY command. If users include file specification qualifiers and a file definition name with a COPY command, the qualifiers they include override the parameters specified in the file definition.

Refer to the *Digital SNA Data Transfer Facility for OpenVMS Use* for information on the file creation parameters and for information on the IBM file specification qualifiers.

1.1.6.1 Adding Entries to the File Definition Database

To add a new entry to the file definition database, use the ADD FILE_DEFINITION command:

```
ADD FILE_DEFINITION[/qualifier] [node["access-control"]::] file-definition-name input-file-spec
```

```
or ADD FILE_DEFINITION[/qualifier] [node["access-control"]::] file-definition-name ibm-file-spec-quals
```

For more detailed information about this command and its parameters and qualifiers, see Chapter 3.

Command Parameters

[node["access-control"]::]

The *node* parameter specifies the OpenVMS/DTF server node where the file definition database resides. If you omit the *node* parameter, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, your current node is selected.

The *access-control* parameter specifies the account name and password of an account on the server node with read and write access to all the databases. The account name is usually SNADTF\$MGR.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

file-definition-name

The user-assigned name of the file definition in the definition database.

input-file-spec

The name of the file used to define file creation parameters.

ibm-file-spec-quals

Any of the IBM file specification qualifiers described in the *Digital SNA Data Transfer Facility for OpenVMS Use* manual with the exception of those qualifiers that specify passwords.

Command Qualifier

The /LOG qualifier used to request informational messages about the operation.

Example

```
DTFCFG> ADD FILE_DEFINITION PERSONNEL_FILE PERSONNEL
```

This example creates the PERSONNEL_FILE file definition record in the file definition database on the default node (the node defined by the last USE NODE command). The DTF file definition attributes are read from the PERSONNEL.SNADTF\$FDL file in the current directory.

1.2 Setting DTF Operating Parameters

To set the DTF operating parameters, you must edit your system startup file and change the parameters associated with the following OpenVMS/DTF startup command procedures:

- SNADTF\$STARTUP_SERVER.COM (for server nodes)
- SNADTF\$STARTUP_CLIENT.COM (for client nodes)

After editing the system startup file, you must either invoke the OpenVMS/DTF command procedure using the same parameters or reboot the system.

Note

When DTF is installed on an OpenVMS cluster, you must run the same DTF startup procedure on all the members of the cluster.

1.2.1 DTF Queues

DTF execution queues are used for recoverable file transfers. Only one recoverable file transfer per queue is allowed at a time. To have concurrent recoverable file transfers, you must start a number of execution queues. The DTF generic queue allows users to treat the DTF execution queues as a single entity. For example, if a user submits a job to the DTF generic queue, the request would be executed by the next available DTF execution queue.

Use the DTF system startup procedures to create and initialize new queues. You can create new queues by altering the parameters passed to the DTF startup command files in your system startup file.

After a queue is created and initialized, you can use the SET QUEUE command to alter queue parameters. The SHOW QUEUE command displays the name and characteristics of the queues after they have been initialized.

1.2.2 The OpenVMS/DTF Server Operating Parameters

The OpenVMSQINSTALL procedure prompts you to add the following line to your system startup procedure:

```
@SYS$STARTUP:SNADTF$STARTUP_SERVER [p1] [p2] [p3] [p4] [p5] [p6] [p7] [p8]
```

where

- [p1] specifies the device where the OpenVMS/DTF server work file directory [SNADTF] is located. The default for this parameter is SYSSCOMMON:.
- [p2] specifies all the OpenVMS/DTF execution queues that you want started at system startup time.
Note that in an OpenVMS cluster environment, you can also specify the node for each execution queue by using the following format for this parameter:
[node::]queue-name[, [node::]queue-name]
If this parameter is not specified, an execution queue named SNADTF\$QUEUE is initialized and started.
- [p3] specifies a YES or NO response to indicate whether or not a generic OpenVMS/DTF queue called SNADTF\$QUEUE is started at system startup time. If you specify a null p2, then parameter p3 is ignored. The default value YES specifies that you want to start and initialize the generic queue SNADTF\$QUEUE. To use the generic queue, however, you must specify the values for the parameter p2 that will be used for your execution queues. If you specify NO for p3 and a value for p2, then the SNADTF\$QUEUE is initialized and started as an **execution** queue.

- [*p4*] specifies a list of server account names used for server sessions by SNADTF\$DISPATCHER for IBM-initiated transfers. This list must have a one-to-one correspondence with the list in *p6*. The default for this parameter is the SNASERVER server account name.
- [*p5*] specifies the time interval that passes before the dispatcher attempts to connect to an IBM host after a server session is disconnected. This parameter is specified in OpenVMSQ delta time. The default for this parameter is 00:15:00.
- [*p6*] specifies a list of server account names to be used for IBM-initiated transfer sessions. This list must have a one-to-one correspondence with the list in *p4*. The default for this parameter is SNADTF.
- [*p7*] specifies a YES or NO response to indicate whether or not the OpenVMS/DTF software should send a cluster alias or system-specific node name to IBM for DTF when the server session starts. A YES indicates the cluster alias should be used; a NO indicates the system-specific node name should be used. If not specified, a cluster alias is used.
- [*p8*] specifies the translation table file name to be used by OpenVMS/DTF for translating from ASCII to EBCDIC and from EBCDIC to ASCII. If not specified, the default translation table is used. This translation table controls how commands over the server sessions are translated; it does not affect text translation over the transfer sessions.

The following example shows how you might specify parameters *p2*, *p3*, and *p4*.

```
@SYS$STARTUP:SNADTF$STARTUP_SERVER " " DTFQUE01,DTFQUE02 YES DISP1,DISP2
```

In this example, the double quotation marks specify that the [SNADTF] directory is located on the default device SYS\$COMMON:. Two execution queues (DTFQUE01 and DTFQUE02) as well as a generic queue (SNADTF\$QUEUE) are started. The generic queue SNADTF\$QUEUE supplies jobs to the two OpenVMS/DTF execution queues DTFQUE01 and DTFQUE02.

Two server sessions are started using information from server accounts DISP1 and DISP2. Finally, because parameters *p5* through *p8* are not specified, the dispatcher retry interval defaults to 15 minutes, IBM-initiated transfers will use the SNASERVER account for the server session and the SNADTF account for the transfer session, IBM-initiated transfers will use the cluster alias, and the default ASCII-to-EBCDIC translation table is used.

Option to Disable Connect to Client SNARCOPY

During an IBM-initiated transfer request, the DTF server software attempts to connect to the client node's SNARCOPY object to get the copy to run on the client node. However, if SNARCOPY is not running on the client node, the copy will run on the server node. This results in a security violation logged on the client node.

You have the option to disable connects to the client node on nonrecoverable transfers. The /NOCONNECT qualifier in the START SERVER command in the SNADTF\$DISPATCHER utility activates the disable connect option. A security violation will not be logged if /NOCONNECT is specified.

To disable the /NOCONNECT qualifier to the remote DECnet node's DTF, uncomment the line in the SNADTF\$STARTUP_SERVER file which defines the qualifier as /NOCONNECT.

Note

If a recoverable transfer was specified, DTF ignores the /NOCONNECT qualifier and issues a connect to the client node.

1.2.3 The OpenVMS/DTF Client Operation Parameters

The VMSINSTAL procedure reminds you to add the following line to your system startup procedure:

```
@SYS$STARTUP:SNADTF$STARTUP_CLIENT [p1] [p2] [p3]
```

where

[p1] specifies the device on which the OpenVMS/DTF work file directory [SNADTF] is located. The default for this parameter is SYS\$COMMON.

[p2] specifies all the OpenVMS/DTF execution queues that you want started at system startup time.

Note that in an OpenVMS cluster environment, you can also specify the node for each execution queue by using the following format for this parameter:

```
[node::]queue-name[, [node::]queue-name]
```

If this parameter is not specified, then an execution queue named SNADTF\$QUEUE is initialized and started.

[*p3*] specifies a YES or NO response to indicate whether or not a generic OpenVMS/DTF queue (SNADTF\$QUEUE) is started at system startup time. If you specify a null value for *p2*, then parameter *p3* is ignored. The default value YES specifies that you want to start and initialize the generic queue SNADTF\$QUEUE. To use the generic queue, however, you must specify the values for the parameter *p2* that will be used for your execution queues. If you specify NO for *p3* and a value for *p2*, then the SNADTF\$QUEUE is initialized and started as an **execution** queue.

The following example shows how you might specify parameter *p2*:

```
@SYS$STARTUP:SNADTF$STARTUP_CLIENT SYS$COMMON: DTFQUE01,DTFQUE02 YES
```

In this example, the [SNADTF] directory is located on the default device SYS\$COMMON:. Two execution queues (DTFQUE01 and DTFQUE02) as well as a generic queue (SNADTF\$QUEUE) are started. The generic queue SNADTF\$QUEUE supplies jobs to the OpenVMS/DTF execution queues DTFQUE01 and DTFQUE02.

Maintaining the OpenVMS/DTF Server Account Database

The server account database is used by OpenVMS/DTF to obtain information on how to set up the session. The server account name defines the parameters that users need to access DTF for IBM software. A server account database containing server account names resides on each OpenVMS/DTF server node.

The SNADTFCFG utility is used to manage the server account database. You can add new entries, display entries, modify entries, and remove entries as necessary. The following sections describe these operations.

2.1 Adding and Modifying Entries in the Server Account Database

To add a new server account name to the server account database, use the ADD SERVER_ACCOUNT command:

```
ADD SERVER_ACCOUNT[/qualifiers] [node["access-control"]::]server-account-name
```

To modify the characteristics of a server account name in the server account database, use the MODIFY SERVER_ACCOUNT command:

```
MODIFY SERVER_ACCOUNT[/qualifiers] [node["access-control"]::]server-account-name
```

Any values for qualifiers not specified with the MODIFY SERVER_ACCOUNT command remain the same.

Command Parameters

[node["access-control"]::]

The *node* parameter specifies the OpenVMS/DTF server node on which the server account database resides. If you omit the *node* parameter from the ADD SERVER_ACCOUNT or MODIFY SERVER_ACCOUNT command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the name and password of an account on the server node with read and write access to all the databases. The account name is usually SNADTF\$MGR.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

server-account-name

The name for the OpenVMS/DTF server account in the server account database.

Command Qualifiers

/ACCESS_NAME=access-name

Specifies a 1- to 16-character SNA Gateway, or OpenVMS SNA access name. This access name represents a list of parameters required for accessing an IBM system. This list includes the PU name, LU list, logon mode, and application name. See the SNA Gateway manager for this name. This qualifier is required if access is provided by OpenVMS SNA.

/APPLICATION_NAME=application-name

Specifies a 1- to 8-character DTF/VTAM application name. This qualifier overrides the application name specified with the */ACCESS_NAME* qualifier. See the appropriate IBM system programmer for this name.

/FILE_DEFINITION=file-definition

Specifies the 1- to 32-character name of the file definition entry that will be used as the default file definition if users do not specify one. See Section 1.1.6 for more information. This qualifier is ignored for server sessions.

/[NO]IBM_PREFIX=prefix-string

Specifies a 0- to 4-character prefix string that will be used by DTF to prefix the IBM user name when using IBM-initiated proxy. The server node initiates the proxy access from the concatenation of this IBM prefix and the IBM user's user name. This prefix allows the differentiation between users with the same user name but on different IBM systems, and also between users with the same user name on the IBM system and on the OpenVMS server node. No prefix is used when the default, */NOIBM_PREFIX*, is specified. Refer to Chapter 1 for more information on managing IBM-initiated proxy. Refer to *Digital SNA Data Transfer Facility for OpenVMS Use* for information on using IBM-initiated proxy.

/GATEWAY=gateway-node

Specifies the 1- to 80-character node name of the node users use to access the IBM system. You can specify either a SNA Gateway DECnet node, an SNA Gateway TCP/IP host name, or an OpenVMS SNA node name. To specify an OpenVMS SNA node name, type 0 for the *gateway-node* parameter.

/[NO]LOG

Displays informational messages about the operation.

/LOGON_MODE=logon-mode

Specifies a 1- to 8-character logon mode table entry. The */LOGON_MODE* qualifier overrides the logon mode entry specified with the */ACCESS_NAME* qualifier. See the appropriate IBM system programmer for this name.

/NODE=dtf-file-service-node

Specifies a 1- to 8-character node in a Transparent Services Access Facility (TSAF) collection. See the appropriate IBM system programmer for this node name.

/NULL:option

Specifies the action to take when a null record is to be written to an IBM file. You can choose from the following options:

<i>value</i>	specifies a number or character that should be stored in place of the null record. The value must be specified as one of the following:
<i>%Cchar</i>	specifies that the indicated character should be stored in place of the null record.
<i>%Dnumber</i>	specifies that the indicated decimal number should be stored in place of the null record. The number must be between -128 and +127 inclusive.
<i>%Xnumber</i>	specifies that the indicated hexadecimal number should be stored in place of the null record. The number must be between 0 and FF inclusive.
<i>%Onumber</i>	specifies that the indicated octal number should be stored in place of the null record. The number must be between 0 and 277 inclusive.
SPACE	specifies that a single space should be stored in place of the null record.
IGNORE	specifies that the null record should be ignored (that is, not copied).
NONE <input type="checkbox"/>	specifies no special processing will occur. An error will be returned if a null record is encountered.

NONE MVS specifies no special processing will occur. The record will be accepted as is.

REJECT MVS specifies that an error should be returned if a null is encountered.

Usage Notes:

- If you do not specify a value, the default specified in the server account database will be used.
- Applies only to non-VSAM files.
- This qualifier is valid only for DECnet to IBM transfers. It will be ignored when copying files from IBM to Digital.
- VM Null records cannot be written to CMS files. If a null record is encountered, an error will be returned.

/PU=pu-name | lu-name

Specifies a 1- to 8-character PU name for a PU between the SNA network and either a DECnet SNA Gateway node, or an OpenVMS SNA node, or an LU name for an LU between the SNA network and either a Digital SNA Domain Gateway or a Digital SNA Peer Server. The /PU qualifier overrides the PU or LU specified with the /ACCESS_NAME qualifier. See the SNA Gateway manager for this information.

/SERVICE MACHINE=virtual-machine-name VM

Specifies the 1- to 8-character name of the virtual machine which handles file access for this transfer. See the appropriate IBM system programmer for this name.

/SESSION_ADDRESS=session

Specifies a number between 1 and 255 inclusive that is the LU number for the transfer session. If you do not specify the /SESSION qualifier, a free LU is selected from the range specified with the /ACCESS_NAME qualifier. See the SNA Gateway manager for this information. When connecting to a Digital SNA Domain Gateway or Digital SNA Peer Server this qualifier is ignored.

Note

This qualifier is not recommended for transfer sessions. This qualifier overrides any range of sessions specified for the SNA Gateway, OpenVMS SNA access name. Specifying this qualifier for a transfer session will restrict the server account to one user and will not allow certain file access operations that require more than one session address.

/[NO]TRANSLATION=*translation-location*

Specifies where data translation is to be performed.

LOCAL specifies that translation is performed on the OpenVMS server node.

REMOTE specifies that translation is performed on the IBM node.

/NOTRANSLATION specifies that no data translation is performed.

This qualifier is ignored for server sessions. The default is /TRANSLATION=LOCAL.

ADD SERVER_ACCOUNT Examples

```
DTFCFG> ADD SERVER_ACCOUNT DOPEY"SNADTF$MGR PASSWORD"::SERVER_017-  
_DTFCFG> /GATEWAY=SNAGWY/ACCESS=DTF/NULL=IGNORE/TRANSLATION=REMOTE
```

This example creates entry SERVER_017 in the server account database on node DOPEY. SNADTF\$MGR is created at installation time. It is a good idea to use this account in situations similar to this because the account has access to the files and databases in the SNADTF\$MANAGER area. The /GATEWAY qualifier stores the value SNAGWY as part of the new server account record (SERVER_017). The /ACCESS qualifier stores value DTF in this record. If the transfer is to a VM system, NULL records are ignored and the translation occurs on the DTF for IBM side. The OpenVMS/DTF server software uses these values to make a connection to the IBM host system when using server account SERVER_017.

```
DTFCFG> ADD SERVER_ACCOUNT CORPORATE/GATEWAY=GWY001/ACCESS=CICS-  
_DTFCFG> /PU=SNA-0/APPLICATION=SNADTF
```

This example creates entry CORPORATE in the server account database on the default node (the node defined by the last USE NODE command). The /GATEWAY, /ACCESS_NAME, /PU, and /APPLICATION qualifiers store values GWY001, CICS, SNA-0, and SNADTF, respectively, as part of the new server account CORPORATE.

MODIFY SERVER_ACCOUNT Examples

```
DTFCFG> MODIFY SERVER_ACCOUNT SMILEY"SNADTF$MGR PASSW"::BIG_XFER-  
_DTFCFG> /ACCESS_NAME=XCICS/APPLICATION=SNADTF3/SESSION=1
```

This example modifies the server account record for the OpenVMS/DTF server account BIG_XFER on node SMILEY. The access name becomes XCICS, the application name becomes SNADTF3, and the session address becomes 1. DTF uses these new values the next time the server software attempts to connect to the IBM system using the BIG_XFER server account.

```
DTFCFG> MODIFY SERVER_ACCOUNT STAR/APPLICATION
```

This example modifies the server account record for the OpenVMS/DTF server account STAR on the default node. The /APPLICATION qualifier erases that record's application name field.

2.2 Displaying Server Account Name Information

To display the characteristics of a specified server account name from the server account database specified on the server node, use the SHOW SERVER_ACCOUNT command:

```
SHOW SERVER_ACCOUNT [node["access-control"]::]server-account-name
```

Command Parameters

[node["access-control"]::]

The *node* parameter specifies the OpenVMS/DTF server node on which the server account database resides. If you omit the *node* parameter from the SHOW SERVER_ACCOUNT command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the name and password of an account on the server node with read and write access to all the databases. The account name is usually SNADTF\$MGR.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

server-account-name

The server account name for the OpenVMS/DTF server account in the server account database. The server account name you specify can include wildcard characters. If you choose to use wildcards, information on all servers with matching wildcards is displayed. A percent sign (%) indicates a single wildcard character, and an asterisk (*) indicates a wildcard string. See the description of the OpenVMS RTL routine STR\$MATCH_WILD in the *OpenVMS DCL Dictionary* for more information about wildcards.

Examples

```
DTFCFG> SHOW SERVER_ACCOUNT CORPORATE
```

```
Server account: CORPORATE
Access Name:    CICS      PU:          SNA-0       Node:
Application:    SNADTF    Logon Mode:  FT008192    Session:
Translation:    NONE      Null:        NONE        Service m/c:
File Definition:                               IBM Prefix:
Gateway:        GWY001::
```

This example displays the record for server account CORPORATE from the database of the default node.

```
DTFCFG> SHOW SERVER_ACCOUNT FILLY::*DTF*
```

```
Server account: DTFMVS
Access Name:    CICS      PU:          SNA-0       Node:
Application:    DTFPROD   Logon Mode:  FT02048    Session:
Translation:    LOCAL     Null:        NONE        Service m/c:
File Definition:                               IBM Prefix:
Gateway:        GWY003::

Server account: DTFMVS1
Access Name:    CICS      PU:          SNA-0       Node:
Application:    DTFTST    Logon Mode:  FT02048    Session:
Translation:    LOCAL     Null:        NONE        Service m/c:
File Definition:                               IBM Prefix: MVS_
Gateway:        GWY003::

Server account: DTFVM
Access Name:    CICS      PU:          SNA-0       Node:
Application:    VMPROD    Logon Mode:  FT001024   Session:
Translation:    NONE      Null:        NONE        Service m/c: VM1
File Definition:                               IBM Prefix: VM_
Gateway:        GWY003::

Server account: SNADTF
Access Name:    CICS      PU:          SNA-0       Node: VM2
Application:    VMPROD    Logon Mode:  FT001024   Session:
Translation:    REMOTE    Null:        IGNORE     Service m/c: VM3
File Definition:                               IBM Prefix:
Gateway:        GWY003::
```

This example displays records for all server accounts on node FILLY that contain DTF in the server account name.

2.3 Removing a Server Account Name

To remove a server account name from the server account database on a specified OpenVMS/DTF server node, use the REMOVE SERVER_ACCOUNT command:

```
REMOVE SERVER_ACCOUNT[/qualifier] [node["access-control"]::]server-  
account-name
```

Command Parameters

[node["access-control"]::]

The *node* parameter specifies the OpenVMS/DTF server node on which the server account database resides. If you omit the *node* parameter from the REMOVE SERVER_ACCOUNT command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, your current node is selected.

The *access-control* parameter specifies the name and password of an account on the server node with read and write access to all the databases. The account name is usually SNADTF\$MGR.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

server-account-name

The server account name for the OpenVMS/DTF server account in the server account database.

Command Qualifier

/[NO]LOG

Provides the option of displaying informational messages about the operation.

Examples

```
DTFCFG> REMOVE SERVER_ACCOUNT SERVER_017
```

This example deletes server account record SERVER_017 from the server account database on the default node.

```
DTFCFG> REMOVE SERVER_ACCOUNT GLEE"SNADTF$MGR PASSWORD"::SNADTF_2
```

This example deletes server account record SNADTF_2 from the server account database on node GLEE.

Maintaining the OpenVMS/DTF File Definition Database

A file definition database resides on each OpenVMS/DTF server node and contains the file definitions that are used to access files on the IBM system.

3.1 Adding Entries to the File Definition Database

To add a new entry to the file definition database, use the ADD FILE_DEFINITION command:

```
ADD FILE_DEFINITION[/qualifiers] [node["access-control"]::]file-definition-name input-file-spec
```

or

```
ADD FILE_DEFINITION[/qualifiers] [node["access-control"]::]file-definition-name ibm-file-spec-quals
```

Command Parameters

[node["access-control"]::]

The *node* parameter specifies the OpenVMS/DTF server node where the file definition database resides. If you omit the *node* parameter from the ADD FILE_DEFINITION command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the account name and password of an account on the server node with read and write access to all the databases. The account name is usually SNADTF\$MGR.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

file-definition-name

Specifies the user-assigned name of the file definition in the definition database.

input-file-spec

The name of the file used to define file creation parameters. This file can be used for all supported file types, including VSAM files. See the *Digital SNA Data Transfer Facility for OpenVMS Use* for information on setting up this file.

ibm-file-spec-quals

Specifies IBM file specification qualifiers. These qualifiers are described in the DTF File Specifications chapter in the *Digital SNA Data Transfer Facility for OpenVMS Use* manual.

Note

The qualifiers that can be specified in the ADD FILE_DEFINITION command are limited to those in the following list:

/ALIGNMENT	/BATCHID	/BLOCK_SIZE
/CATALOG	/CLASS	/DENSITY
/DIRECTORY_BLOCKS	/HSMRECALL	/LABEL
/MDADDRESS	/MRS	/NULL
/OWNERID	/RECORD_DEFINITION	/RELEASE
/RETENTION_PERIOD	/SECURITY_DATA	/SEQUENCE_NUMBER
/SINGLE	/SMSDCLASS	/SMSMCLASS
/SMSSCLASS	/SPANNED	/SUPERSEDE
/TRANSLATE	/UNIT	/USERID
/VOLUME		

Command Qualifier**/[NO]LOG**

Provides the option of displaying informational messages about the operation.

ADD FILE_DEFINITION Examples

```
DTFCFG> ADD FILE_DEFINITION PERSONNEL_FILE PERSONNEL
```

This example creates the PERSONNEL_FILE file definition record in the file definition database on the default node (the node defined by the last USE NODE command). The DTF file definition attributes are read from the PERSONNEL.SNADTF\$FDL file in the current directory.

```
DTFCFG> ADD FILE_DEFINITION/LOG RAWDATA TAPE_SPECS.TXT
%SNADTF-I-ADDFIL, file definition RAWDATA added
```

This example creates the RAWDATA file definition record in the file definition database on the default node. The /LOG qualifier indicates that a message should be displayed indicating that the file definition has been created. The DTF file definition attributes are read from the TAPE_SPECS.TXT file in the current directory.

```
DTFCFG> ADD FILE_DEFINITION SWNODE"SNADTF$MGR SECRET"::SWD_DATA-
_DTFCFG> SWD_DATA
```

This example creates the SWD_DATA file definition record in the file definition database on node SWNODE. The DTF file definition attributes are read from the SWD_DATA.SNADTF\$FDL file in the current directory.

```
DTFCFG> ADD FILE_DEFINITION NON_VSAM1/NOSUPERSEDE/MDADDRESS=193
```

This example creates a file definition record NON_VSAM1 in the file definition database on the default node (the node defined by the last USE NODE command). The values for the various file creation parameters are specified on the command line. Files created using the NON_VSAM1 file definition will not be superseded and will be placed on the minidisk with an address of 193.

3.2 Displaying File Definition Attributes

To display the attributes of a single file definition or a group of file definitions in the file definition database on a specified node, use the SHOW FILE_DEFINITION command:

```
SHOW FILE_DEFINITION[/qualifiers] [node["access-control"]::]file-definition-
name
```

Command Parameters

[node["access-control"]::]

The *node* parameter specifies the OpenVMS/DTF server node where the file definition database resides. If you omit the *node* parameter from the ADD FILE_DEFINITION command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the account name and password of an account on the server node with read and write access to all the databases. The account name is usually SNADTF\$MGR.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

file-definition-name

Specifies the user-assigned name of the file definition in the definition database.

The file definition you specify can include wildcard characters. If you choose to use wildcards, information about all file definitions with matching wildcards is displayed. A percent sign (%) indicates a single wildcard character, and an asterisk (*) indicates a wildcard string. Refer to the description of the OpenVMS RTL routine STR\$MATCH_WILD in the *OpenVMS DCL Dictionary* for more information about wildcards.

Command Qualifiers

/BRIEF

Displays only the file definition names. By default, the entire contents of a file definition are displayed.

/OUTPUT[=*file-specification*]

The name of the file where the output of the SHOW FILE_DEFINITION command is to be placed. If the /OUTPUT qualifier is used without an argument, SYSS\$OUTPUT is used as the default.

SHOW FILE_DEFINITION Examples

```
DTFCFG> SHOW FILE_DEFINITION/BRIEF *DAT*
```

```
!  
!   File definition:  
!  
RAWDATA   SWD_DATA
```

This example displays the file definition names in the database containing the string DAT. The /BRIEF qualifier causes only the names to be displayed, rather than the entire file definition.

```
DTFCFG> SHOW FILE_DEFINITION/OUTPUT=VSAM_ESDS VSAM_ESDS_FDL
```

This example displays the VSAM_ESDS_FDL file definition. The /OUTPUT qualifier directs the output from this command to the VSAM_ESDS.SNADTF\$FDL file in the current directory.

```
DTFCFG> SHOW FILE_DEFINITION PERSONNEL_FILE

!
!   File definition: PERSONNEL_FILE
!
BASE
  RECORD_DEFINITION      PERSONNEL_RECORD
  RELEASE                NO
  SINGLE                 NO
  SPANNED                NO
  SUPERSEDE             NO
  TRANSLATE              YES
  UNIT                   DISK01
  USERID                 PERONL
  VOLUMES                VOL1
  VSAM_SEQUENTIAL       NO
```

This example displays the PERSONNEL_FILE file definition on the user's terminal.

3.3 Modifying a File Definition

The process for modifying file definitions depends on whether you are modifying the BASE section or an ALTERNATE_INDEX section. The following two subsections describe the modify process for each instance.

3.3.1 Modifying the File Definition BASE Section

To modify entries in the file definition's BASE section, use the MODIFY FILE_DEFINITION command:

```
MODIFY FILE_DEFINITION[/qualifier] [node["access-control"]::]file-definition-
name ibm-file-spec-quals
```

Command Parameters

[node["access-control"]::]

The *node* parameter specifies the OpenVMS/DTF server node where the file definition database resides. If you omit the *node* parameter from the MODIFY FILE_DEFINITION command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the account name and password of an account on the server node with read and write access to all the databases. The account name is usually SNADTF\$MGR.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

file-definition-name

Specifies the user-assigned name of the file definition in the definition database.

ibm-file-spec-quals

Specifies IBM file specification qualifiers. These qualifiers are described in the DTF File Specifications chapter in the *Digital SNA Data Transfer Facility for OpenVMS Use* manual.

Note

The qualifiers that can be specified in the MODIFY FILE_DEFINITION command are limited to those in the following list:

/ALIGNMENT	/BATCHID	/BLOCK_SIZE
/CATALOG	/CLASS	/DENSITY
/DIRECTORY_BLOCKS	/HSMRECALL	/LABEL
/MDADDRESS	/MRS	/NULL
/OWNERID	/RECORD_DEFINITION	/RELEASE
/RETENTION_PERIOD	/SECURITY_DATA	/SEQUENCE_NUMBER
/SINGLE	/SMSDCCLASS	/SMSMCLASS
/SMSSCLASS	/SPANNED	/SUPERSEDE
/TRANSLATE	/UNIT	/USERID
/VOLUME		

Command Qualifier

/[NO]LOG

Provides the option of displaying informational messages about the operation.

MODIFY FILE_DEFINITION Examples

```
DTFCFG> MODIFY FILE_DEFINITION PERSONNEL_FILE PERSONNEL
```

This example creates the PERSONNEL_FILE file definition record in the file definition database on the default node (the node defined by the last USE NODE command). The DTF file definition attributes are read from the PERSONNEL.SNADTF\$FDL file in the current directory.

```
DTFCFG> MODIFY FILE_DEFINITION NON_VSAM1/TRANSLATE/NOSUPERSEDE-  
_DTFCFG> /MDADDRESS=195
```

This example updates the NON_VSAM1 file definition. Files created using the NON_VSAM1 file definition will now use DMCS/EBCDIC data translation, will not be superseded, and will be on the minidisk with address 195.

```
DTFCFG> MODIFY FILE_DEFINITION MVS_VSAM/USERID=PAYROLL-  
_DTFCFG> RETENTION_PERIOD=1000/TRANSLATE
```

This example alters the values associated with the RETENTION_PERIOD and USERID attributes and allows data translation for the file definition MVS_VSAM. Note that all of these changes occur only in the BASE section of the file definition.

3.3.2 Modifying File Definition ALTERNATE_INDEX Sections

To modify file definition ALTERNATE_INDEX sections, do the following:

1. Use the SHOW FILE_DEFINITION command with the /OUTPUT qualifier. This creates a copy of the file definition you want to modify.
2. Edit this copy of the file and make your changes.
3. Use the REMOVE FILE_DEFINITION command to remove the file definition you want modified.
4. Use the ADD FILE_DEFINITION command to replace the file definition with your modified file.

SHOW FILE_DEFINITION Example

```
$ RUN SYS$SYSTEM:SNADTF CFG
DTFCFG> SHOW FILE_DEFINITION/OUTPUT=NEW_CHANGES.DAT PERSONNEL_FILE
DTFCFG> EXIT
$ EDIT NEW_CHANGES.DAT
.
.
.
* EXIT
$ RUN SYS$SYSTEM:SNADTF CFG
DTFCFG> REMOVE FILE_DEFINITION PERSONNEL_FILE
DTFCFG> ADD FILE_DEFINITION PERSONNEL_FILE NEW_CHANGES.DAT
DTFCFG> EXIT
```

In this example, PERSONNEL_FILE is the file definition you want to modify; NEW_CHANGES.DAT is the copy of the file definition that you use to make your actual changes.

3.4 Removing an Entry from the File Definition Database

To remove a file definition from the file definition database on a specified server node, use the REMOVE FILE_DEFINITION command:

```
REMOVE FILE_DEFINITION [node["access-control"]::]file-definition-name
```

Command Parameters

[*node*["*access-control*"]::]

The *node* parameter specifies the OpenVMS/DTF server node where the file definition database resides. If you omit the *node* parameter from the REMOVE FILE_DEFINITION command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the account name and password of an account on the server node with read and write access to all the databases. The account name is usually SNADTF\$MGR.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

file-definition-name

Specifies the user-assigned name of the file definition in the definition database.

REMOVE FILE_DEFINITION Examples

```
DTFCFG> REMOVE FILE_DEFINITION ACCOUNTING_FILE
```

This example deletes the record called `ACCOUNTING_FILE` from the file definition database on the current node.

```
DTFCFG> REMOVE FILE_DEFINITION MOOSE"SNADTF$MGR SECRET":POP_FILE
```

This example deletes the record called `POP_FILE` from the file definition database on node `MOOSE`. The access control information within double quotation marks (" ") consists of an account name (`SNADTF$MGR`) and password (`SECRET`) for an account with read and write access to the file definition database.

A

Messages

This appendix lists and describes all OpenVMS/DTF SNADTFCFG messages. All OpenVMS/DTF messages have the following format:

facility-l-ident, text

where

facility is the name of the facility or program that generates the message. All the messages in this appendix have the facility code SNADTF.

l is a severity level indicator with one of the following values:

Code	Meaning
S	Success—the action completed successfully.
I	Information—you do not need to take any further action.
W	Warning—OpenVMS/DTF may have performed some of your request.
E	Error—the output is incorrect. You may need to refer to the problem determination guide for your interconnect system or report the problem to Digital using a Software Performance Report (SPR).
F	Fatal, or severe, error—OpenVMS/DTF cannot continue with your request. You may need to refer to the problem determination guide for your interconnect system or report the problem to Digital using a Software Performance Report (SPR).

ident is an abbreviation of the message text.

text is the explanation of the message.

A sample OpenVMS/DTF message follows:

```
%SNADTF-I-ADDFIL, file definition 'DTF1' added
```

A.1 OpenVMS/DTF Messages

The following messages are listed alphabetically according to the abbreviated message text (*ident*).

ACCROUFAI, error from Gateway access routine, gateway unknown or unreachable,

Explanation: SNA Gateway is unknown or unreachable; Transport list (defined by SNA_TRANSPORT_ORDER logical) is defined incorrectly or Gateway/Host Name specified does not support transport selected; or TCP/IP Port (defined by SNA_TCP_PORT logical) does not match the remote connection TCP/IP Port.

User Action: Check the SNA Gateway, the SNA_TRANSPORT_ORDER logical, or the SNA_TCP_PORT logical.

ADDFIL, file definition *file-definition* added

Explanation: File definition *file-definition* was added to the file definition database on the OpenVMS/DTF server node.

User Action: None. This is an informational message.

ADDPRO, proxy account *proxy-account* added

Explanation: The proxy account was added to the proxy database on the OpenVMS/DTF server node.

User Action: None. This is an informational message.

ADDSER, server account *server-account* added

Explanation: Server account *server-account* was added to the server account database on the OpenVMS/DTF server node.

User Action: None. This is an informational message.

BADIDXSEQ, alternate index name *index-name* is out of sequence

Explanation: An alternate index name is out of sequence. When alternate index names are specified for a VSAM indexed file, all names must be in ascending EBCDIC sequence. The major difference between the two character coding schemes has to do with the relationship between numeric and alphabetic characters. Numeric characters appear after alphabetic characters in the EBCDIC collating sequence, while numeric characters appear before alphabetic characters in the ASCII collating sequence.

User Action: Modify the file definition input file so that the alternate index names are in EBCDIC collating sequence order.

BUGCHK, internal error detected in *routine-name* at PC *xxxxxxx*

Explanation: An internal error has been detected in the OpenVMS/DTF software. This error is fatal and causes the running image to exit immediately. The occurrence of this message implies that the OpenVMS/DTF software is operating incorrectly.

User Action: Record this error message and all subsequent error messages associated with this error. You should gather information on all the circumstances surrounding this error, and then report the problem to Digital by submitting a Software Performance Report (SPR) or by calling the Digital support hotline.

CLIRET, unexpected value returned by routine CLISPRESNT

Explanation: This is a secondary message to the BUGCHK message.

User Action: See BUGCHK.

COMMEXC, failed to execute command successfully

Explanation: The SNADTFCFG utility failed to execute a command successfully.

User Action: Examine the subsequent error messages to determine why the command could not be executed.

CONVERMIS, SNADTF\$MANAGER:SNADTF\$SERVER_ACCOUNT.DAT is incompatible

Explanation: The server name database file on the OpenVMS/DTF server node is incompatible with the running version of the OpenVMS/DTF product.

User Action: Delete the SNADTF\$SERVER_ACCOUNT.DAT;* file from the SNADTF\$MANAGER directory on the OpenVMS/DTF server node. Use the SNADTFCFG ADD SERVER_ACCOUNT command to create a new server account database file.

CREATEACC, if *server-account* is used for file transfers, add an OpenVMS account

Explanation: This message is reported when a new server account is created on an OpenVMS/DTF server node. If the new server account is used for transfer sessions and not for server sessions, an OpenVMS account must be created on the OpenVMS/DTF server node using the OpenVMS AUTHORIZE utility.

User Action: Use the OpenVMS AUTHORIZE COPY command to create an OpenVMS user account entry with the same name as the

OpenVMS/DTF server account. You need this account to copy the existing SNADTF UAF record into the new UAF record.

ERRCLOCON, error closing server account database *file-spec*

Explanation: The server account database file could not be closed.

User Action: Examine the subsequent error messages to determine the exact cause of the error.

ERRCLOFIL, error closing file definition database *file-spec*

Explanation: The file definition database file could not be closed.

User Action: Examine the subsequent error messages to determine the exact cause of the error.

ERRCLOOUT, error closing output file *file-spec*

Explanation: The output file could not be closed.

User Action: Examine the subsequent error messages to determine the exact cause of the error.

ERRCLOPRO, error closing proxy database *file-spec*

Explanation: The proxy database file could not be closed.

User Action: Examine the subsequent error messages to determine the exact cause of the error.

ERRDELPRO, error deleting proxy database *file-spec*

Explanation: The proxy record could not be deleted from the proxy database file.

User Action: Examine the subsequent error messages to determine the exact cause of the error.

ERROPECON, error opening server account database *file-spec*

Explanation: The server account database file could not be opened.

User Action: Examine the subsequent error messages to determine the exact cause of the error. If the problem occurred because the file could not be found, use the SNADTFCFG ADD SERVER_ACCOUNT command to create a new version of the file on the OpenVMS/DTF server node.

ERROPEFIL, error opening file definition database *file-spec*

Explanation: The file definition database file could not be opened.

User Action: Examine the subsequent error messages to determine the exact cause of the error. If the problem occurred because the file could not be found, use the SNADTFCFG ADD FILE_DEFINITION command to create a new version of the file on the OpenVMS/DTF server node.

ERROPEPRO, error opening proxy database *file-spec*

Explanation: The proxy database file could not be opened.

User Action: Examine the subsequent error messages to determine the exact cause of the error. If the problem occurred because the file could not be found, use the SNADTFCFG ENABLE PROXY command to create a new version of the file on the OpenVMS/DTF server node.

ERRPARVSA, error parsing VSAM definition file

Explanation: The VSAM definition file cannot be parsed.

User Action: Examine the subsequent error messages to determine the exact cause of the error.

ERRREAPRO, error reading proxy database *file-spec*

Explanation: A proxy record could not be read from the proxy database file.

User Action: Examine the subsequent error messages to determine the exact cause of the error.

ERRSUBMITTING, error encountered while submitting *file-spec*

Explanation: An error was encountered while submitting the indicated file to the DTF queue.

User Action: Examine the subsequent error messages to determine the exact cause of the error.

ERRWRIOUT, error writing to output file *file-spec*

Explanation: A line could not be written to the output file.

User Action: Examine the subsequent error messages to determine the exact cause of the error.

ERRWRIPRO, error writing proxy database *file-spec*

Explanation: A proxy record could not be written to the proxy database file.

User Action: Examine the subsequent error messages to determine the exact cause of the error.

FAITRALOG, failed to translate logical name *logical-name*

Explanation: The logical name *logical-name* could not be translated.

User Action: Examine the subsequent error messages to determine why the specified logical name could not be translated.

FILALREXI, file definition *file-definition* already exists

Explanation: The file definition *file-definition* cannot be added to the file definition database on the OpenVMS/DTF server node because a file definition of the same name already exists.

User Action: Modify the existing file definition, or use the ADD FILE_DEFINITION command to create a new and different file definition name.

FILDEFCOR, file definition *file-definition* is corrupt

Explanation: This error occurs when attempting to read a file definition from the file definition database. This error indicates that there is an internal consistency error for the specified file definition. This situation can occur if an ADD FILE_DEFINITION command is interrupted (for example, by the user pressing the CTRL/C sequence).

User Action: Delete the corrupted file definition. Use the ADD FILE_DEFINITION command to re-enter the file definition into the database.

FILEREM, error removing file definition from *file-spec*

Explanation: The REMOVE FILE_DEFINITION command failed to remove a file definition from the file definition database *file-spec* that resides on the OpenVMS/DTF server node.

User Action: Examine the subsequent error messages to determine why the REMOVE command failed.

FILVERMIS, SNADTF\$MANAGER:SNADTF\$FILE_DEFINITION.DAT is incompatible

Explanation: The file definition database file on the OpenVMS/DTF server node is incompatible with the running version of the OpenVMS/DTF product.

User Action: Delete the SNADTF\$FILE_DEFINITION.DAT;* file from the SNADTF\$MANAGER directory on the OpenVMS/DTF server node. Use the SNADTFCFG ADD FILE_DEFINITION command to create a new file definition database file.

IDXNAMMIS, an alternate index name is missing

Explanation: If one alternate index name is specified in a file definition input file, then all alternate index names must be specified. This error occurs if there are more indexes specified than index names.

User Action: Modify the file definition input file either to remove all alternate index names or to specify an alternate index name for all alternate indexes.

INVNODNAM, *node-name* is an invalid node name

Explanation: An invalid node name was specified in an SNADTFCFG command.

User Action: Reissue the command specifying a valid DECnet node or TCP/IP host name.

INVQUAL, invalid value specified for qualifier */qualifier-name*

Explanation: An invalid value was specified for this IBM file specification qualifier.

User Action: Correct the command that specified the incorrect value and reenter the command.

KEYWRDCON, keyword conflict in file definition input

Explanation: Two mutually exclusive keywords were specified in a DTF file definition file.

User Action: Examine the subsequent error message to determine which keywords conflict.

MODPRO, proxy account *proxy-account* modified

Explanation: The proxy account in the proxy database on the OpenVMS/DTF server node was modified.

User Action: None. This is an informational message.

MODSER, server account *server-account* modified

Explanation: Server account *server-account* on the OpenVMS/DTF server node was modified.

User Action: None. This is an informational message.

NOMATFIL, no file definition found that matched specification

Explanation: This error message occurs if you issue an SNADTF CFG SHOW FILE_DEFINITION command using a wildcard file definition, and there are no matching definitions in the OpenVMS/DTF server node file definition database.

User Action: Reissue the command using a more generic wildcard specification (for example: SHOW FILE_DEFINITION *).

NOMATPRO, no proxy account found that matched specification

Explanation: This error message occurs if you issue an SNADTF CFG SHOW PROXY command using a wildcard file definition, and there are no matching definitions or the file is empty, in the OpenVMS/DTF server node proxy database.

User Action: Reissue the command using a more generic wildcard specification (for example: SHOW PROXY *).

NOMATSER, no server account found that matched specification

Explanation: This error message occurs if you issue an SNADTF CFG SHOW SERVER_ACCOUNT command using a wildcard file definition, and there are no matching server accounts in the OpenVMS/DTF server node file server account database.

User Action: Reissue the command using a more generic wildcard specification (for example: SHOW FILE SERVER_ACCOUNT *).

NOSUCHFIL, file definition *file-definition* does not exist

Explanation: The file definition *file-definition* has not been defined in the file definition database on the OpenVMS/DTF server node.

User Action: Add the file definition to the file definition database or use an existing file definition name.

NOSUCHPRO, proxy account *proxy-account* does not exist

Explanation: The proxy account has not been defined in the proxy database on the OpenVMS/DTF server node.

User Action: Create the account or use an existing account.

NOSUCHSER, server account *server-account* does not exist

Explanation: The server account *server-account* has not been defined in the file definition database on the OpenVMS/DTF server node.

User Action: Create the account or use an account name that has been defined.

PROALREXI, proxy account *proxy-account* already exists

Explanation: The proxy account *proxy-account* cannot be added to the proxy account database on the OpenVMS/DTF server node because a proxy account of the same name already exists.

User Action: Use the MODIFY PROXY command to modify the existing proxy account, or use the ADD PROXY command to create a new proxy account with a different name.

PRODISABLED, proxy database is disabled

Explanation: The proxy database has been disabled.

User Action: None. This is an informational message.

PROENABLED, proxy database is enabled

Explanation: The proxy database has been enabled.

User Action: None. This is an informational message.

PROXYDIS, proxy database is disabled

Explanation: The proxy database has been disabled.

User Action: If you want to enable the proxy database, use the ENABLE PROXY command.

REMFIL, file definition *file-definition* removed

Explanation: File definition *file-definition* was removed from the file definition database on the OpenVMS/DTF server node.

User Action: None. This is an informational message.

REMPRO, proxy account *proxy-account* removed

Explanation: The proxy account was removed from the proxy database on the OpenVMS/DTF server node.

User Action: None. This is an informational message.

REMSER, server account *server-account* removed

Explanation: Server account *server-account* was removed from the server account database on the OpenVMS/DTF server node.

User Action: None. This is an informational message.

REQUAL, IBM userid and server account qualifiers are required

Explanation: IBM user ID and server account qualifiers are required qualifiers.

User Action: Specify the IBM user ID and server account name qualifiers in the command.

RETEXP, RETENTION_PERIOD and EXPIRATION_DATE are mutually exclusive

Explanation: Both the RETENTION_PERIOD and EXPIRATION_DATE attributes were used in a file definition. These two keywords are mutually exclusive.

User Action: Modify the DTF file definition file to remove one of the two keywords.

SERALREXI, server account *server-account* already exists

Explanation: The server account *server-account* cannot be added to the server account database on the OpenVMS/DTF server node because a server account of the same name already exists.

User Action: Use the MODIFY SERVER_ACCOUNT command to modify the existing server account definition, or use the ADD SERVER_ACCOUNT command to create a new server account definition with a different name.

SERVREM, error removing server account from *server-account*

Explanation: The REMOVE SERVER_ACCOUNT command failed to remove a server account definition from the server account database *server-account* that resides on the OpenVMS/DTF server node.

User Action: Examine the subsequent error messages to determine why the REMOVE command failed.

TOOLONG, the value specified for */qualifier-name* is too long

Explanation: The value specified for the qualifier was too long.

User Action: Retype the command specifying a correct value for this qualifier.

UNERETSYS, unexpected return code from a system routine

Explanation: This is a secondary message to the BUGCHK message.

User Action: See BUGCHK.

UNIREU, UNIQUE and REUSE are mutually exclusive

Explanation: The UNIQUE keyword was used for the COMPONENT_ALLOCATION attribute and the YES keyword was used for the REUSE attribute. These two keywords are mutually exclusive.

User Action: Modify the file definition input file to alter the value for either the COMPONENT_ALLOCATION or REUSE attribute.

UNRKEY, *keyword* is not a recognized keyword

Explanation: This is a secondary message to the BUGCHK message.

User Action: See BUGCHK.

UNRKEYVAL, *value* is not a recognized keyword value

Explanation: This is a secondary message to the BUGCHK message.

User Action: See BUGCHK.

UNRVERB, unrecognized command verb

Explanation: This is a secondary message to the BUGCHK message.

User Action: See BUGCHK.

VALREQ, missing keyword value - supply all required values

Explanation: A value must be specified for a keyword in the DTF file definition file.

User Action: Modify the DTF file definition file and supply a value for the keyword.

VALTOOLONG, the value specified for keyword *keyword-name* is too long

Explanation: The value specified for the keyword was too long.

User Action: Modify the command specifying a correct value for this qualifier.

B

Maintaining the OpenVMS/DTF Proxy Database

The proxy database lets you store IBM security information for an OpenVMS, ULTRIX, RSX-11M/M-PLUS, OS/2, or MS-DOS user. If an authorized DECnet user does not include IBM security information in the access request, the proxy database is checked to see if security information is stored for that user. If it is, that information is included in the access request to the IBM system.

You can use the SNADTFCFG utility to add, modify, display, and remove proxy database entries. To access the proxy database, you must invoke the SNADTFCFG utility from an account that has read and write access to the proxy database and has the SYSPRV privilege. The following sections describe these operations.

Note

For IBM MVS DTF clients, the IBM system programmer can also set up a proxy database using a technique similar to that used for the OpenVMS/DTF server proxy database. You may want to consult with the IBM system programmer to determine a mutually agreeable course of action concerning proxies. See the *Digital SNA Data Transfer Facility for OpenVMS Use* manual for more information about the interplay between the two proxy databases if both are created.

B.1 Enabling the Proxy Database

To enable the proxy database, use the ENABLE PROXY command:

```
ENABLE PROXY [node["access-control"]:]
```

This command enables the database and creates the database if one is not already available.

Command Parameter

[node["access-control"]::]

The *node* parameter specifies the OpenVMS/DTF server node where the proxy database resides. This parameter must be specified if the proxy database is on a node other than the one you are currently on. If the *node* parameter is omitted from the ENABLE PROXY command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the account name and password of an account on the server node with read and write access to all the OpenVMS/DTF databases and with the SYSPRV privilege.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

B.1.1 Automatic Update of the Proxy Database

The OpenVMS/DTF server software updates the DTF proxy database when a valid password is specified on the command line and it is different from the password in the database. This allows users to update the proxy database automatically when accessing an IBM file using DTF.

To update the passwords stored in the proxy database automatically, users should specify both the /USER and /PASSWORD qualifiers or both the /USER qualifier and any of the minidisk password qualifiers. If the specified password is different from the one stored in the database and the access works using the new password, then the new password is stored in the database.

This function was built into the product as an ease-of-use feature for users who specify updated passwords.

B.1.2 Option to Disable Automatic Update to the Proxy Database

The option to disable automatic update of passwords was added to facilitate those users who typically do not store IBM passwords. However, this option will allow users to obtain other security information included in an access request sent to the IBM system.

To disable automatic updating of the proxy database, specify the /NOAUTOMATIC qualifier on the ENABLE PROXY command line. To enable the feature, specify the /AUTOMATIC qualifier on the ENABLE PROXY command line. The feature is enabled by default.

B.2 Disabling the Proxy Database

To disable the proxy database, use the DISABLE PROXY command:

```
DISABLE PROXY [node["access-control"]::]
```

The records in the database remain stored there, but they cannot be used as long as the proxy database is disabled.

Command Parameter

[node["access-control"]::]

The *node* parameter specifies the OpenVMS/DTF server node where the proxy database resides. This parameter must be specified if the proxy database is on a node other than the one you are currently on. If the *node* parameter is omitted from the DISABLE PROXY command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the account name and password of an account on the server node with read and write access to all the OpenVMS/DTF databases and with the SYSPRV privilege.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

DISABLE PROXY Examples

```
DTFCFG> DISABLE PROXY
```

This example disables the proxy database on the current node or the node defined by the last USE NODE command.

```
DTFCFG> DISABLE PROXY RABBIT"SNADTF$MGR PASSWORD"::
```

This example disables the proxy database on node RABBIT.

B.3 Adding and Modifying Entries in the Proxy Database

To add a new entry to the proxy database, use the ADD PROXY command:

```
ADD PROXY[/qualifiers] [node["access-control"]::] proxy-account-  
name/SERVER_ACCOUNT=server-account /USERID=ibm-userid
```

The first entry for any node/user/server account triple becomes the default record in the proxy database. The /SERVER_ACCOUNT and /USERID qualifiers must be specified when using this command.

To change a user's IBM password or minidisk passwords, use the MODIFY PROXY command.:

```
MODIFY PROXY[/qualifiers] [node["access-control"]:] proxy-account-  
name/SERVER_ACCOUNT=server-account /USERID=ibm-userid
```

The /SERVER_ACCOUNT and /USERID qualifiers are required to specify the proxy entry to be modified. In addition, if there are multiple entries for a node/user/server account triple, you must also specify the /NODE qualifier to specify the proxy entry to be modified. You cannot modify the IBM user ID, the name of the server, the nodename, the minidisk address, or the minidisk owner ID. If you need to modify any of these fields, remove the entry and add a new entry with the modified information.

Command Parameters

[node["access-control"]:]

The *node* parameter specifies the OpenVMS/DTF server node where the proxy database resides. This parameter must be specified if the proxy database is on a node other than the one you are currently on. If the *node* parameter is omitted from the ADD PROXY or MODIFY PROXY command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the account name and password of an account on the server node with read and write access to all the OpenVMS/DTF databases and with the SYSPRV privilege.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

proxy-account-name

Specifies the name of the user in the proxy database.

Command Qualifiers

/DEFAULT

Specifies this record is the default. If a default record was previously specified for this node/user/server account triple, the previous default record is changed to a non-default record and the record specified with this qualifier becomes the new default record.

/[NO]LOG

Provides the option of displaying informational messages about the operation.

/MDADDRESS=*disk-address* VM

Specifies the address of the minidisk using up to 4 hexadecimal digits. For more information on minidisk addresses see the DTF File Specifications chapter in the *Digital SNA Data Transfer Facility for OpenVMS Use* manual.

/MDMPASSWORD=*multi-password* VM

Specifies the multiwrite password for the minidisk using up to 8 characters. For more information on minidisk passwords, see the DTF File Specifications chapter in the *Digital SNA Data Transfer Facility for OpenVMS Use* manual.

/MDRPASSWORD=*read-password* VM

Specifies the read password for the minidisk using up to 8 characters. For more information on minidisk passwords, see the DTF File Specifications chapter in the *Digital SNA Data Transfer Facility for OpenVMS Use* manual.

/MDWPASSWORD=*write-password* VM

Specifies the write password for the minidisk using up to 8 characters. For more information on minidisk passwords, see the DTF File Specifications chapter in the *Digital SNA Data Transfer Facility for OpenVMS Use* manual.

/NODE=*client-node*

The remote client node from which the user is accessing OpenVMS/DTF. If available, the cluster alias name is used as the default. Otherwise, the name of the node where the database is being updated is used as the default for this qualifier.

/OWNERID=*owner-id* VM

Specifies the 1- to 8-character minidisk owner as specified in the VM directory. For more information on minidisk owner IDs, see the DTF File Specifications chapter in the *Digital SNA Data Transfer Facility for OpenVMS Use* manual.

/PASSWORD=*ibm-password*

The 1- to 8-character IBM password for a particular DTF user and the corresponding IBM user ID.

Note

You do not need to include the IBM password if the proxy database on the IBM client is being used for access verification.

/SERVER_ACCOUNT=*server-account*

The server account entry in the server account database. This is a required qualifier.

/USERID=ibm-userid

The 1- to 8-character IBM user ID used by a particular DTF user. This is a required qualifier.

ADD PROXY Examples

```
DTFCFG> ADD PROXY DOE/USERID=JANE/PASSWORD=SECRET-  
_DTFCFG> /SERVER=SNADTF/NODE=JOHN
```

This example adds OpenVMS user DOE on node JOHN, whose IBM user ID is JANE and IBM password is SECRET. When user DOE (logged onto node JOHN) accesses the IBM system through DTF server account SNADTF, the MVS user ID JANE and password SECRET will be used to gain access to the IBM system.

```
DTFCFG> ADD PROXY RABBIT"SNADTF$MGR SECRET"::LOU/USERID=LOU-  
_DTFCFG> /PASS=IBMPASS/SERVER=IBMS1/NODE=VEENA
```

This example adds into the database that is located on node RABBIT the OpenVMS user LOU on node VEENA and the corresponding IBM user ID LOU and IBM password IBMPASS using the server IBMS1. When user LOU (logged onto node VEENA) accesses the IBM system through the DTF server account IBMS1 on node RABBIT, the MVS user ID LOU and password IBMPASS will be used to gain access to the IBM system.

```
DTFCFG> ADD PROXY CANTER/USERID=CANTER/PASSWORD=SECRET/SERVER=VMDTF-  
_DTFCFG> /NODE=BOSTON/MDADDRESS=191/MDRPASSWORD=sight-  
_DTFCFG> /MDWPASSWORD=ecrit
```

This example creates an entry for OpenVMS user CANTER on node BOSTON to provide access to IBM user ID CANTER on a node pointed to by server account VMDTF. Also provided are the multi, read, and write minidisk passwords for the 191 disk. These passwords are valid only if the IBM account is on a VM system.

MODIFY PROXY Example

```
DTFCFG> MODIFY PROXY MIKE/USER=MIKE/SER=SNADTF/PASS=NEWPAS
```

This example changes the password of the OpenVMS user MIKE to NEWPAS. The IBM user ID is MIKE and the server account is SNADTF.

B.4 Displaying Entries in the Proxy Database

To display DTF security information, use the SHOW PROXY command:

```
SHOW PROXY[/qualifiers] [node["access-control"]:]proxy-account-name
```

This command shows whether the proxy database is enabled or disabled and displays the user names, node names, server accounts, IBM user IDs, and last modification dates for the requested users. The IBM passwords are not displayed.

Command Parameters

[node["access-control"]:::]

The *node* parameter specifies the OpenVMS/DTF server node where the proxy database resides. This parameter must be specified if the database is on a node other than the one you are currently on. If the *node* parameter is omitted from the SHOW PROXY command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the account name and password of an account on the server node with read and write access to all the OpenVMS/DTF databases and with the SYSPRV privilege.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

proxy-account-name

The name of the DTF user in the proxy database. You can use wildcards to show all the users in the proxy database or for a particular server, node, or IBM user ID. You can also display information specifically for default or non-default records.

Command Qualifiers

/DEFAULT

Displays information for default proxy records.

/NODE=*client-node*

The remote client node from which the user is accessing OpenVMS/DTF. The default node used is the cluster alias name, if present, or the node name where the database is being updated.

/SERVER_ACCOUNT=*server-account*

The server account entry in the server account database.

/STATUS

Displays the status of the proxy database only. You can use this qualifier to:

- Check whether the proxy database is enabled or disabled.
- Determine the status of the proxy database on a remote node by specifying the node and access control parameters for that node.
- Check whether automatic update of the DTF proxy database is enabled or disabled.

Note

Do not specify the *proxy-account-name* parameter when using this qualifier; the parameter will be ignored.

If you do not specify any parameters, the status of the proxy database for the current node is displayed.

/USERID=*ibm-userid*

The IBM user ID for a particular DTF user.

SHOW PROXY Examples

```
DTFCFG> SHOW PROXY *
```

```
DRAGO::GARY (D)
Server: DTFVM      IBM Userid: CANTER
Maddress: 191      Ownerid:   KNIGHT      25-JUL-1990 15:26

Server: DTFVM      IBM Userid: CANTER
Maddress: 193      Ownerid:   KNIGHT      25-JUL-1990 15:26

DRAGO::PETERS (D)
Server: SNADTF     IBM Userid: PETE
Maddress:          Ownerid:          25-JUL-1990 15:31

Server: SNADTF     IBM Userid: PYRL
Maddress:          Ownerid:          25-JUL-1990 15:32
```

This example shows that OpenVMS user GARY on node DRAGO has proxy access to the 191 and 193 disk with owner ID KNIGHT. Use the minidisk address and owner ID when specifying access to a VM system. This example also shows that DRAGO::PETERS has proxy access to the IBM account PETE and PYRL. The default proxies are noted by the (D).

```
DTFCFG> SHOW PROXY/STATUS
%SNADTF-I-PROENABLED, proxy database is enabled
```

This example shows you the proxy database status on the default node.

```
DTFCFG> SHOW PROXY/STATUS GLEE"SNADTF$MGR PASSWORD"::  
%SNADTF-I-PRODISABLED, proxy database is disabled
```

This example shows you the proxy database status on node GLEE.

B.5 Removing an Entry from the Proxy Database

To remove entries from the proxy database use the REMOVE PROXY command:

```
REMOVE PROXY[/qualifiers] [node["access-control"]::] proxy-account-  
name/SERVER_ACCOUNT=server-account /USERID=ibm-userid
```

The /SERVER_ACCOUNT and /USERID qualifiers must be specified when using this command. To remove records that are not defaults, you must also specify the node name.

Command Parameters

[*node*["*access-control*"]::]

The *node* parameter specifies the OpenVMS/DTF server node where the proxy database resides. This parameter must be specified if the database is on a node other than the one you are currently on. If the *node* parameter is omitted from the REMOVE PROXY command, the server node defined by the last USE NODE command is selected by default. If you have not issued a USE NODE command, then your current node is selected.

The *access-control* parameter specifies the account name and password of an account on the server node with read and write access to all the OpenVMS/DTF databases and with the SYSPRV privilege.

Note

Do not use an account in the OpenVMS/DTF server account database for the *access-control* parameter.

proxy-account-name

The name of the user in the proxy database.

Command Qualifiers

/NODE=client-node

The remote client node where the user is logged on. If available, the cluster alias name is used as the default. Otherwise, the name of the node where the database is being updated is used as the default value for this qualifier.

/SERVER_ACCOUNT=server-account

The server account entry in the server account database.

/USERID=ibm-userid

The IBM user ID for a particular DTF user.

REMOVE PROXY Example

```
DTFCFG> REMOVE PROXY MIKE/USERID=MIKE/SER=SNADTF
```

This example removes the proxy record MIKE from the database. The IBM user ID is MIKE and the server account is SNADTF.

Index

A

ADD FILE_DEFINITION (SNADTF CFG)
command, 1-14, 2-1, 3-1
ADD PROXY (SNADTF CFG) command, B-1
ADD SERVER_ACCOUNT (SNADTF CFG)
command, 1-4, 2-1
Altering the client system startup file, 1-18
Altering the server system startup file, 1-16
Authorizing access to server accounts, 1-7

C

Client system startup file
altering, 1-18
Configuring OpenVMS/DTF, 1-1

D

Default OpenVMS/DTF server node
setting a default, 1-2
Defining DTF queues, 1-16
DISABLE PROXY (SNADTF CFG) command,
B-3
DTF defaults
modifying, 1-15
DTF queues
defining, 1-16

E

ENABLE PROXY (SNADTF CFG) command,
B-1
Execution queues, 1-16
Exiting from the SNADTF CFG utility, 1-2

F

File definition
adding to the file definition database,
1-14, 2-1, 3-1
displaying characteristics of, 3-3
modifying, 3-7
removing from the file definition database,
3-8
File definition database
adding file definitions, 1-14, 2-1, 3-1
displaying characteristics, 3-3
modifying a file definition, 3-7
removing file definitions, 3-8
setting up, 1-14
Files
null record handling in VM, 2-3

G

Generic queues, 1-16

I

IBM file specification qualifiers

/NULL:option, 2-3

Invoking the SNADTFCFG utility, 1-2

M

MODIFY PROXY (SNADTFCFG) command,
B-3

Modifying DTF defaults, 1-15

Modifying the proxy database, B-3

N

/NULL:option, 2-3

O

OpenVMS/DTF databases

setting up, 1-1

OpenVMS/DTF messages, A-2

P

Proxy, 1-8

IBM-initiated, 1-8

OpenVMSQ proxy, 1-8

Proxy database

adding information to, B-1

changing a user password in, B-3

disable automatic update of passwords,
B-2

disabling, B-3

displaying information of, B-6

enabling, B-1

removing information, B-9

R

REMOVE FILE_DEFINITION

(SNADTFCFG) command, 3-8

REMOVE PROXY (SNADTFCFG) command,
B-9

REMOVE SERVER_ACCOUNT

(SNADTFCFG) command, 2-8

S

Security

displaying proxy database information,
B-6

Server account database

adding server account names, 1-4, 2-1

displaying server account names, 2-6

modifying server account name in, 2-1

removing server account names, 2-8

setting up, 1-1

Server account name

adding to the server account database,
1-4, 2-1

displaying characteristics, 2-6

modifying in the server account database,
2-1

removing from the server account
database, 2-8

Server accounts

authorizing access, 1-7

Server node

setting a default node, 1-2

Server system startup file

altering, 1-16

Setting up the file definition database, 1-14

Setting up the server account database, 1-1

SHOW FILE_DEFINITION (SNADTFCFG)

command, 3-3

SHOW PROXY (SNADTFCFG) command,

B-6

SHOW SERVER_ACCOUNT (SNADTFCFG)

command, 2-6

SNADTFCFG commands

ADD FILE_DEFINITION, 1-14, 2-1, 3-1

ADD PROXY, B-1

ADD SERVER_ACCOUNT, 1-4, 2-1

DISABLE PROXY, B-3

ENABLE PROXY, B-1

MODIFY PROXY, B-6

SNADTFCFG commands (cont'd)

MODIFY SERVER_ACCOUNT, 2-1
REMOVE FILE_DEFINITION, 3-8
REMOVE PROXY, B-9
REMOVE SERVER_ACCOUNT, 2-8
SHOW FILE_DEFINITION, 3-3
SHOW SERVER_ACCOUNT, 2-6
USE [NO]NODE, 1-2

System startup file

client, 1-18
server, 1-16

System startup procedure, 1-15

U

USE [NO]NODE (SNADTFCFG) command,
1-2

