



Release Notes

PROBEwatch for ULTRIX

Firmware Version: 1.0

Part Number: AA-Q0TAB-TE

October 1993

Introduction

The following quick-start instructions enable you to use PROBEwatch for ULTRIX with default settings for a DECpacketprobe 90™.

Setup

After launching the application and responding to the copyright pop-up window, do the following:

1. Choose Add.
2. Enter the IP address of the newly configured DECpacketprobe 90 agent in the Name field of the pop-up dialog box.

Configuration

You must configure the following fields within the DECpacketprobe 90 agent from the PROBEwatch Manager window:

- Launch Domain View
- Domain Selection

Configure the fields from the PROBEwatch Manager window, as follows:

Launch Domain View

1. Select Launch Domain View.
2. Configure this field as follows:
 - a. Select the desired agent.
 - b. From the menu bar, choose the Domain View Launch function.

The Domain View window appears with the IP address or name of the selected agent at the top section of the window.

Release Notes

Domain Selection

1. Select Domain Selection.
2. Configure this field as follows:
 - a. From the Domain pop-up dialog box, choose Install.
 - b. Select the desired agent and protocol that you wish to monitor.
 - c. Select statistics, host conversations or data capture categories for the agent to monitor.

Known Problems and Restrictions

The following sections list problems and restrictions that were found in this version (V1.0) of PROBEwatch for ULTRIX.

Drop Packets Counter

The Drop Packets counter on the Segment Zoom screen is functional only when Domain View is set to All. If any other domain is selected, the counter value will indicate zero (0).

In future releases of this product, non-applicable fields will be grayed out.

Running the setld Procedure

If you attempt to run the setld procedure before setting the NSHOME environmental variable, the system will prompt you with a core dump error message.

To properly run the setld procedure, do the following:

1. Add the following to your .login file:

```
setenv NSHOME /usr/kits/probewatch 
```

```
setenv PATH ${PATH}:/usr/kits/probewatch 
```

2. Initialize your .login file as follows:

```
source .login 
```

3. Run the setld procedure

DECpacketprobe 90, ULTRIX, and the Digital logo are trademarks of Digital Equipment Corporation. DomainView is the trademark of Frontier Software Development, Inc.