

HUBwatch for Windows

Use

Part Number: AA-QS3B-TE

August 1994

This manual explains how to use the HUBwatch network management software.

Revision Information: This is a new manual.

Operating System and Version: MS-Windows V3.1 or higher

Software and Version: HUBwatch for Windows V3.1

Digital Equipment Corporation makes no representations that the use of its products in the manner described in this publication will not infringe on existing or future patent rights, nor do the descriptions contained in this publication imply the granting of licenses to make, use, or sell equipment or software in accordance with the description.

Possession, use, or copying of the software described in this publication is authorized only pursuant to a valid written license from Digital or an authorized sublicensor.

© Digital Equipment Corporation 1994. All rights reserved.

DEC, DECagent, DECbridge, DECconnect, DEChub, DECmcc, DECnet, DECrepeater, DECserver, DECwindows, EDT, HUBwatch, LAT, Open DECconnect, OpenVMS, POLYCENTER, ThinWire, ULTRIX, VAX, VAX DOCUMENT, VMS, and the DIGITAL logo are trademarks of Digital Equipment Corporation.

The following are third-party trademarks:

Apollo is a trademark of Apollo Computer, Inc.
AppleTalk is a trademark of Apple Computer, Inc.
Banyan is a trademark of Banyan, Inc.
CompuServe is a registered trademark of CompuServe, Inc.
IBM is a trademark of International Business Machines Corporation.
IEEE is a trademark of The Institute of Electrical and Electronics Engineers, Inc.
Intel is a trademark of Intel Corporation.
MS-DOS is a registered trademark of Microsoft Corporation.
Motif and OSF are registered trademarks of the Open Software Foundation, Inc.
Motorola is a registered trademark of Motorola, Inc.
MultiNet is a registered trademark of TGV, Inc.
Novell is a registered trademark of Novell, Inc.
UNIX is a registered trademark licensed exclusively by X/Open Company Limited.
VINES is a registered trademark of Banyan Systems, Inc.
Windows is a trademark of Microsoft Corporation in the United States of America and other countries.

Xerox is a registered trademark of Xerox Corporation

All other trademarks and registered trademarks are the property of their respective holders.

This document was prepared using VAX DOCUMENT, Version 2.1.

Contents

| | |
|---|------|
| Preface | xiii |
| 1 HUBwatch Introduction | |
| What Is HUBwatch? | 1-1 |
| Introduction | 1-1 |
| Definitions | 1-1 |
| Who Uses HUBwatch? | 1-1 |
| What You Can Do with HUBwatch | 1-2 |
| HUBwatch Software Environment | 1-2 |
| Related Manuals | 1-2 |
| How You Use HUBwatch | 1-3 |
| Introduction | 1-3 |
| Using HUBwatch | 1-3 |
| Related Information | 1-4 |
| Getting Help | 1-5 |
| Introduction | 1-5 |
| Help Options | 1-5 |
| Using the Help Menu | 1-5 |
| Jumps to Other Help Topics | 1-6 |
| Context-Sensitive Help | 1-6 |
| Using the Help Button | 1-6 |
| Printing a Help Topic | 1-6 |
| Rule | 1-7 |
| The HUBwatch Tutorial | 1-8 |
| Introduction | 1-8 |
| Running the Tutorial | 1-8 |
| Firmware Revision Levels | 1-9 |
| New Firmware | 1-9 |
| FTP Location | 1-9 |
| How to Register | 1-9 |
| Products That HUBwatch Manages | 1-10 |
| Introduction | 1-10 |

| | |
|--|------|
| DEChub 90 Description | 1-10 |
| DEChub 900 MultiSwitch Description | 1-10 |
| Supported Modules List | 1-11 |
| More Modules | 1-12 |
| Related Information | 1-12 |

2 Management Methods

| | |
|---------------------------------------|-----|
| Types of Management Methods | 2-1 |
| Introduction | 2-1 |
| Definitions | 2-1 |
| In-Band Management | 2-2 |
| Introduction | 2-2 |
| Management Options | 2-2 |
| Using IP Addresses | 2-3 |
| DEChub 900MS Manager IP Address | 2-3 |
| DECagent 90 IP Address | 2-3 |
| Standalone Module IP Address | 2-3 |
| Proxy SNMP Agents | 2-4 |
| Out-of-Band Management | 2-5 |
| Overview | 2-5 |
| OBM Port and SLIP | 2-5 |
| References | 2-5 |

3 SNMP Concepts

| | |
|--|-----|
| How HUBwatch Uses SNMP Agents | 3-1 |
| Introduction | 3-1 |
| Definitions | 3-1 |
| Types of SNMP Agents | 3-1 |
| Managing the DECagent 90 | 3-2 |
| Managing the DEChub 900MS | 3-2 |
| Managing Modules with Built-In Agents | 3-2 |
| Using the Agent File | 3-3 |
| Agents Must Have an IP Address | 3-3 |
| Agent File Location | 3-3 |
| HUBwatch SNMP Communities | 3-4 |
| Definition | 3-4 |
| Community Names Control Access | 3-4 |
| DECagent 90 Community Description | 3-4 |
| DEChub 900MS Manager Community Description | 3-5 |
| DECagent 90 Community in a DEChub 900MS | 3-5 |
| Built-In Agent Community Description | 3-5 |

| | |
|--|------|
| Autodiscovery | 3-6 |
| Definition | 3-6 |
| Rules | 3-6 |
| DEChub 900 Autodiscovery | 3-6 |
| DECagent 90 Autodiscovery | 3-6 |
| Hint | 3-7 |
| The HUBwatch Community Table Window | 3-8 |
| Introduction | 3-8 |
| Community Table Window | 3-8 |
| Parts of the Community Table Window | 3-9 |
| Introduction | 3-9 |
| Identification List | 3-9 |
| Agent File List | 3-9 |
| Communities of the Current Agent List | 3-10 |
| How You Use the Community Table Window | 3-12 |
| Introduction | 3-12 |
| Management Tasks | 3-12 |
| Reference | 3-12 |
| Related Information | 3-12 |

4 Starting HUBwatch

| | |
|---|-----|
| HUBwatch Startup | 4-1 |
| Introduction | 4-1 |
| Before You Start | 4-1 |
| Adding Agents | 4-1 |
| Agent File Compatibility | 4-1 |
| Reference | 4-2 |
| Starting HUBwatch Standalone | 4-3 |
| Introduction | 4-3 |
| Text Box Startup Steps | 4-3 |
| Additional Startup Information | 4-3 |
| Command Line Startup Steps | 4-4 |
| Start Command Line Syntax | 4-4 |
| Start Command Variables | 4-4 |
| Starting HUBwatch from POLYCENTER | 4-6 |
| Introduction | 4-6 |
| Starting from SNMP Manager | 4-6 |
| Starting from Network Manager | 4-7 |
| Related Information | 4-8 |
| Adding HUBwatch | 4-8 |
| Starting HUBwatch from OpenView | 4-9 |
| Introduction | 4-9 |

| | |
|------------------------------------|------|
| Starting HUBwatch | 4-9 |
| Starting HUBwatch Using SLIP | 4-10 |
| SLIP Connection | 4-10 |

5 Using Backplane LAN Segments

| | |
|---|------|
| LAN Segments | 5-1 |
| Introduction | 5-1 |
| Hardware Overview | 5-1 |
| Interconnect Functionality | 5-2 |
| How You Manage LAN Segments | 5-3 |
| Introduction | 5-3 |
| LAN Interconnect Window Figure | 5-3 |
| LAN Interconnect Window Parts | 5-4 |
| Introduction | 5-4 |
| LAN Segments | 5-4 |
| Network Modules | 5-4 |
| Port Colors | 5-4 |
| Port Connector Stars | 5-5 |
| Additional LAN Interconnect Buttons | 5-6 |
| Introduction | 5-6 |
| Expanded View | 5-6 |
| Station Configuration | 5-6 |
| Grouping Ports | 5-6 |
| Grouping Hint | 5-7 |
| Connecting Modules | 5-8 |
| Introduction | 5-8 |
| How to Connect a Module | 5-8 |
| 90-Series Modules | 5-8 |
| 900-Series Modules | 5-8 |
| Interconnect Tasks | 5-9 |
| Using the LAN Interconnect Window | 5-9 |
| Reference | 5-9 |
| Configuration Example 1 | 5-10 |
| Introduction | 5-10 |
| Configuration 1 Figure | 5-10 |
| Configuration 1 Description | 5-10 |
| Extended LAN | 5-11 |
| Caution | 5-11 |
| Configuration Example 2 | 5-12 |
| Introduction | 5-12 |
| Configuration 2 Figure | 5-12 |
| Configuration 2 Description | 5-13 |

| | |
|--|------|
| Single Rail | 5-13 |
| Moving Connections | 5-13 |
| Expanded LAN Interconnect Window Figure | 5-14 |
| Steps for Building Configuration 2 | 5-15 |
| Configuration Example 3 | 5-18 |
| Introduction | 5-18 |
| Configuration 3 Figure | 5-18 |
| Configuration 3 Description | 5-19 |
| Steps for Building Configuration 3 | 5-19 |
| Station Configuration Window Figure | 5-21 |
| Unlit LEDs | 5-22 |
| Other Connection Options | 5-22 |
| Configuration Example 4 | 5-23 |
| Introduction | 5-23 |
| Configuration 4 Figure | 5-23 |
| Configuration 4 Description | 5-24 |
| Steps for Building Configuration 4 | 5-24 |
| Port Grouping Window Figure | 5-26 |
| Backplane LAN Segment Configuration Guidelines | 5-28 |
| Introduction | 5-28 |
| Low Numbered Slot | 5-28 |
| Six Segments Only | 5-28 |
| DECrepeater 90FS/TS Restrictions | 5-28 |
| Rule | 5-28 |
| DECrepeater Configuration Guidelines | 5-29 |
| Introduction | 5-29 |
| Repeater Restrictions | 5-29 |
| Preventing Repeater Loops | 5-30 |
| Introduction | 5-30 |
| What Are Repeater Loops? | 5-30 |
| Exception | 5-30 |
| Prohibited Repeater Loop Figure | 5-30 |
| Kinds of Repeater Loops | 5-31 |
| What Happens | 5-31 |
| Preventing 900FP Repeater Loops | 5-31 |
| Loop Example | 5-32 |
| ThinWire Port Group | 5-32 |
| DECrepeater 900FP Loop Figure | 5-32 |
| DECserver Configuration Guidelines | 5-33 |
| Introduction | 5-33 |
| DECserver 900TM Ports | 5-33 |
| DECserver Restrictions | 5-33 |
| DECserver Load Host | 5-33 |

| | |
|--|------|
| Rule | 5-34 |
| DECbridge Configuration Guidelines | 5-35 |
| Introduction | 5-35 |
| DECbridge 900MX Port 3 | 5-35 |
| FDDI Configuration Guidelines | 5-36 |
| Introduction | 5-36 |
| Types of FDDI Configurations | 5-36 |
| Types Figure | 5-36 |
| FDDI Ring Grayed Out | 5-37 |
| Trunk Rings | 5-37 |

6 The HUBwatch GUI for Hubs and Modules

| | |
|---------------------------------------|------|
| Using the GUI | 6-1 |
| Introduction | 6-1 |
| Hub Front Panel Window | 6-2 |
| Introduction | 6-2 |
| How to Open It | 6-2 |
| Hub Front Panel Window Figure | 6-3 |
| Types of Views | 6-4 |
| Introduction | 6-4 |
| Physical View | 6-4 |
| Logical View | 6-4 |
| Physical View Figure | 6-5 |
| Logical View Figure | 6-6 |
| Hub Management Windows | 6-7 |
| When You Use Them | 6-7 |
| Hub Management Window Figure | 6-8 |
| How You Open Them | 6-9 |
| Menu Options | 6-9 |
| Lowercase | 6-10 |
| Help Menu | 6-11 |
| Context Sensitive Help | 6-11 |
| Reference | 6-11 |
| Module Management Windows | 6-12 |
| When You Use Them | 6-12 |
| How to Open Them | 6-12 |
| Module Management Window Figure | 6-13 |
| Reference | 6-13 |
| Network Module Icons | 6-14 |
| Standard Buttons | 6-16 |

7 Managing DEChubs and Modules

| | |
|---|------|
| Using HUBwatch Windows | 7-1 |
| Chapter Structure | 7-1 |
| Task Instructions | 7-1 |
| Reference | 7-1 |
| HUBwatch Management Windows | 7-2 |
| Introduction | 7-2 |
| Hub Management | 7-3 |
| Opening Hub Management Windows | 7-3 |
| Reference | 7-3 |
| SNMP Communities and Agents | 7-5 |
| Introduction | 7-5 |
| Window-Task Table | 7-5 |
| Opening Agent Summary Windows | 7-5 |
| Backplane LAN Segments | 7-7 |
| Introduction | 7-7 |
| Window-Task Table | 7-7 |
| Opening the Backplane Management Windows | 7-8 |
| DECconcentrator 900MX | 7-9 |
| Introduction | 7-9 |
| Window-Task Table | 7-9 |
| Opening Concentrator Windows | 7-10 |
| 90-Series Repeaters | 7-11 |
| Introduction | 7-11 |
| Hint | 7-11 |
| Window-Task Table | 7-11 |
| Opening 90-Series Repeater Windows | 7-12 |
| 900-Series Repeaters | 7-13 |
| Introduction | 7-13 |
| Window-Task Table | 7-13 |
| 900-Series Repeater Window Push Button Icons | 7-14 |
| Opening 900-Series Repeater Windows | 7-15 |
| DECserver 90L and 90L+ Terminal Servers | 7-17 |
| Introduction | 7-17 |
| Window-Task Table | 7-17 |
| Opening the Terminal Server Windows | 7-18 |
| DECserver 90TL, 90M, and 900TM Terminal Servers | 7-19 |
| Introduction | 7-19 |
| Window-Task Table | 7-19 |
| Opening the Terminal Server Windows | 7-20 |
| 90-Series Bridges | 7-21 |
| Introduction | 7-21 |

| | |
|--|------|
| Window-Task Table | 7-21 |
| Bridge Summary Window Icons | 7-22 |
| Opening Bridge Windows | 7-23 |
| 900-Series Bridges and Switches (including RoamAbout Access Point) | 7-24 |
| Introduction | 7-24 |
| Window-Task Table | 7-24 |
| Bridge and Switch Summary Window Icons | 7-25 |
| Opening Bridge Windows | 7-27 |
| Brouters | 7-28 |
| Introduction | 7-28 |
| Window-Task Table | 7-28 |
| Brouter Icons | 7-28 |
| Opening Brouter Windows | 7-29 |

A Troubleshooting Tips

| | |
|---|-----|
| Troubleshooting | A-1 |
| In This Appendix | A-1 |
| Other Troubleshooting Information | A-1 |
| General Display Problems | A-2 |
| Incorrect Displays with New Hub Installation | A-2 |
| Display Problems with New Module Installation | A-2 |
| Terminal Server Problems | A-3 |
| Incorrect Display with New Terminal Server | A-3 |
| Terminal Server Display Disappears | A-3 |
| Disconnecting Ports Causes Warning | A-4 |
| Terminal Server Parameters Not Taking Effect | A-4 |
| Community Problems | A-5 |
| Community Strings Not Displayed | A-5 |
| New Community Strings Discarded | A-6 |
| Agent Problems | A-7 |
| New Agent Does Not Appear in Community Table | A-7 |
| Agents Not Remembered | A-7 |
| Performance Problems | A-8 |
| HUBwatch Runs Slowly | A-8 |
| Hint | A-8 |
| HUBwatch Shows An Empty Hub | A-8 |

B HUBwatch Summary Windows

| | |
|------------------------------|-----|
| Summary Window Figures | B-1 |
| In This Appendix | B-1 |

Glossary

Index

Figures

| | | |
|-----|---|-----|
| B-1 | 90-Series Repeater Summary Window | B-2 |
| B-2 | 900-Series Repeater Summary Window | B-3 |
| B-3 | 90L and 90L+ Terminal Server Summary Window | B-4 |
| B-4 | 90-Series Bridge Summary Window | B-5 |
| B-5 | Brouter Summary Window | B-6 |
| B-6 | 900-Series Bridge Summary Window | B-7 |
| B-7 | DECconcentrator 900MX Summary Window | B-8 |

Preface

| | |
|---------------------------------|--|
| Introduction | This book tells you how to use HUBwatch™ for Windows™ network management software. You use this software to manage DEChub™ 90 and DEChub 900 MultiSwitch hubs and their configured network modules. You can also use HUBwatch to manage individual standalone modules (like the DECRepeater 90FS and 90TS) and standalone modules installed in a DEChub ONE. |
| Intended Audience | <p>This book is intended for network managers using HUBwatch software to manage the DEChub 90, DEChub 900 MultiSwitch, and any configured network modules.</p> <p>You should know how to use MS–Windows applications.</p> |
| What Is in This Book | This book contains conceptual information you need to use HUBwatch. It also tells you how to use the HUBwatch Graph User Interface (GUI). Additionally, this book gives you an overview of some management tasks and describes the windows you use to do them. |
| What Is Not in This Book | This book does not contain the step-by-step procedural instructions you need to do a particular task. You can find those instructions in the <i>How to Manage...</i> section of the HUBwatch online Help. This book and the online help complement each other and provide all the information you need to use HUBwatch. |

Structure of This Book

This book is structured as follows:

- Chapter 1 introduces HUBwatch software and describes its features.
- Chapter 2 describes in-band and out-of-band management.
- Chapter 3 describes how HUBwatch uses Simple Network Management Protocol (SNMP). It tells you how you use and manage communities in configurations with multiple hubs and SNMP agents. This chapter also describes the tasks associated with managing SNMP agents.
- Chapter 4 describes how to start the HUBwatch software.
- Chapter 5 provides an overview of the interconnect functionality and presents some typical LAN segment configurations available when using the DEChub 900 MultiSwitch.
- Chapter 6 describes how to use the HUBwatch GUI for hubs and network modules.
- Chapter 7 describes the tasks associated with managing hubs and modules.
- Appendix A provides troubleshooting information in the form of possible solutions to potential problems.
- Appendix B contains example figures of the Summary windows you use to manage hubs and their modules.
- A Glossary provides definitions of HUBwatch terms.

Conventions

The following conventions are used in this manual

| Convention | Meaning |
|--|---|
| Special type | Indicates a literal example of system output or user input. User input is in bold. |
| <i>lowercase italics</i> | Indicate a variable. |
| [] | Brackets contain default responses to the installation procedure prompts. To accept the default response to a prompt, simply press <code>[Return]</code> . |
| <code>[Return]</code> | Indicates that you press the Return key. |
| Click on <code>[push button]</code> | Indicates that you use the mouse to point to the HUBwatch window push button named in the box and click MB1. MB1 is to be used to perform all clicking functions unless MB2 is specified. |
| <code>[Ctrl/x]</code> | Indicates that you press the Control key while you type the key noted by <i>x</i> . |
| Ethernet | The term "Ethernet" is used in this manual to refer to the IEEE 802.3 standard. |
| Token Ring | The term "Token Ring" is used in this manual to refer to the IEEE 802.5 standard. |
| HUBwatch | The term "HUBwatch" is used in this manual to refer to the HUBwatch for Windows software. |
| Hub Manager | The term "Hub Manager" is used in this manual to refer to the DEChub 900MS Manager. |
| 00.00.00.00 | Represents an Internet Protocol (IP) address in examples and figures. |
| 08-00-2B-00-00-00 | Represents a Media Access Control (MAC) address in examples and figures. |

Firmware Updates

Because Digital continuously improves the quality of DEChub products, periodic releases of firmware will become available. To ensure that you have the latest functionality and quality of firmware, always use the most current versions of firmware.

You can get information about the latest firmware releases from your local Digital Reseller or your local Digital Sales Office. You can also get this information by reading the README file found in the /pub/DEC/hub900 directory at <ftp.digital.com>.

Firmware updates are customer installable. To register for automatic notification of new firmware releases, return the Business Reply Card supplied with this product. Or, you can use the Internet by sending your Name, Title, and Mailing Address to dechub_notice@lkg.dec.com.

Documentation Comments

If you have comments or suggestions for this book or any of the HUBwatch documents, you can submit them in two ways.

- Mail the Reader's Comment form on the last page of this document to the address on the reverse side of the form.
- If you have access to the Internet, you may mail your comments electronically to the HUBwatch writing group within Digital at doc_quality@lkg.mts.dec.com

HUBwatch Introduction

What Is HUBwatch?

Introduction

HUBwatch software is a flexible, network management application with a GUI. It manages network modules installed in a hub as well as the hub itself.

To communicate management commands to the network modules, HUBwatch sends Simple Network Management Protocol (SNMP) commands to SNMP management agents on the network modules or on the hub itself.

Definitions

A **hub** is a central device, usually in a star topology local area network (LAN), in which network modules are installed. When you install Digital's network modules in a DEChub 90 or DEChub 900 MultiSwitch chassis, the chassis becomes a hub.

A **network module** is a hardware device that occupies a slot in the hub. It provides network infrastructure services by connecting other devices like terminals, workstations, and host systems to the hub. A network module may include front panel status, diagnostic LEDs, connections to the hub, a serial service port, and a MAC interface.

Who Uses HUBwatch?

Network managers responsible for maintaining a hub and its installed modules use the HUBwatch product. Additionally, the graphical presentation of SNMP information and the extensive online information allow nontechnical personnel to use the product.

What You Can Do with HUBwatch

You use HUBwatch software to:

- View the status and activity of the network modules and ports.
- Configure LANs internal to the hub.
- Monitor the flow and accuracy of network data.
- Configure network modules.

HUBwatch Software Environment

The current releases of the HUBwatch network management application run on the MS-DOS[®] operating system in an MS-Windows environment and on the OpenVMS[™] VAX[™] operating system in a Motif[®] windows environment.

The HUBwatch functionality described in this manual assumes that you have installed the latest versions of DEChub and module firmware.

Related Manuals

The following related information may be useful.

| For Information About... | See... |
|--------------------------|--|
| HUBwatch software | <i>HUBwatch Installation and Configuration</i> manual HUBwatch Tutorial |
| HUBwatch's use of SNMP | Chapter 3 of this book |

How You Use HUBwatch

Introduction

You can configure HUBwatch software to run as a standalone application on a network management station or as an add-on application to POLYCENTER network management software.

Using HUBwatch

This is the way you use HUBwatch software to manage network modules.

| Step | Action | Result |
|------|-------------------------------------|--|
| 1 | Run the application. | The software displays the Hub Front Panel window. This window shows you the hub configuration and status of each module and module port. |
| 2 | Select pulldown menu options. | Provides access to non-module hub windows and value-added applications. |
| 3 | Select modules or module ports. | A summary window for the selected module or module port appears. |
| 4 | Select icons on the summary window. | The software displays module management windows. These windows let you manage the selected object. |

Related Information

The following information may be useful.

| For Information About... | See... |
|--------------------------------------|---|
| Configuring the HUBwatch application | <i>HUBwatch Installation and Configuration</i> manual |
| Starting the HUBwatch software | Chapter 4 of this book |
| Using the GUI for hubs and modules | Chapter 6 of this book |
| Managing hubs and network modules | Chapter 7 of this book |

Getting Help

Introduction To get information quickly about an option or a task, use online Help. You can display step-by-step instructions and then complete your HUBwatch management tasks without having to turn away from the screen.

Help Options With HUBwatch help, you can:

- View step-by-step instructions while you perform a task in HUBwatch.
- Use the Help button to get an overview and list of tasks performed at the window.
- Get context-sensitive help by pressing F1 while selecting option or objects on the current window.
- Print a copy of a Help topic.
- Run the online tutorial to learn about the main features of HUBwatch.
- View symptom-based troubleshooting information.

Using the Help Menu The Help menu provides the following options.

| This Option... | Contains... |
|----------------------|---|
| Menu Commands | Descriptions of the HUBwatch menu options and tasks. |
| How To Manage... | Step-by-step instructions for managing SNMP agents and communities, LAN backplane segments, routers, workgroup bridges, bridges, switches, FDDI concentrators, terminal servers, and repeaters. |
| Configuration Sheets | Checklists for configuring modules so HUBwatch can manage them. |
| Troubleshooting | A list of common HUBwatch problems and their suggested solutions. |

| This Option... | Contains... |
|-----------------|--|
| Release Info... | A product overview, the release notes, information about new features, and a customer questionnaire. |
| About | The software version and date, and copyright information. |

Jumps to Other Help Topics

Some words in the Help topics appear in colors and are underscored with a dotted or a solid underline. Clicking on these words jumps you to other Help information.

- Dotted underlined words jump you to a definition of the word.
- Solid underlined words jump you to the Help topic associated with that word.

Context-Sensitive Help

Pressing F1 calls up context-sensitive help as you work. When using any the HUBwatch windows, you can position the cursor on any menu, window object, or dialog box field and press F1. You get a MIB description of the object.

Using the Help Button

All the HUBwatch windows have a Help button. When you click on the Help button, you get a description of the window and the tasks performed at that window.

Printing a Help Topic

You can print any Help topic. A topic prints on the default printer. If you installed more than one printer, you can make any of them the default printer. You can also change the options for the default printer.

Do the Following To Print the Current Help Topic.

| Step | Action |
|------|-------------------------------|
| 1 | Select the File menu in Help. |
| 2 | Choose Print Topic. |

Do the Following to Change Printers and Printer Options.

| Step | Action |
|-------------|---|
| 1 | Select the File menu in Help. |
| 2 | Choose Print Setup. |
| 3 | Choose the printer you want to use. |
| 4 | To change the default printer options, choose the Setup button. |
| 5 | Select the options you want. |
| 6 | Choose OK to close the Setup dialog box. |
| 7 | Choose OK. |

Rule

You cannot print pop-up window information.

The HUBwatch Tutorial

Introduction HUBwatch provides an online tutorial that highlights the key features of the application. You can move through the tutorial at your own pace.

Running the Tutorial These instructions tell you how to use the HUBwatch Tutorial.

| To... | Do this... |
|---|--|
| Run the tutorial | Double click on the HUBwatch Tour icon in the HUBwatch window group. |
| See a demonstration of a HUBwatch feature | Select a topic from the Jump menu.. |
| Leave the tutorial | Choose the Quit button at any time to return to Windows. |

Firmware Revision Levels

- New Firmware** Because Digital continuously improves the quality of DEChub products, periodic releases of firmware will become available. To ensure that you have the latest functionality and quality of firmware, always use the most current versions of firmware.
- FTP Location** You can get information about the latest firmware releases from your local Digital Reseller or your local Digital Sales Office. You can also get this information by reading the README file found in the /pub/DEC/hub900 directory at ftp.digital.com.
- How to Register** Firmware updates are customer installable. To register for automatic notification of new firmware releases, return the Business Reply Card supplied with this product. Or, you can use the Internet by sending your Name, Title, and Mailing Address to *dechub_notice@lkg.dec.com*.

Products That HUBwatch Manages

Introduction

The HUBwatch software can manage:

- Network modules installed in a DEChub 90 or in a DEChub 900 MultiSwitch (MS) chassis .
- Standalone modules without a docking station.
- Standalone modules installed in a DEChub ONE product.

DEChub 90 Description

The DEChub 90 hub provides mounting, power, and ThinWire™ Ethernet connections for up to eight network modules, plus the power supply. The chassis provides all the power and signals to each module through a DIN-style connector. You can install and remove network modules with the power on (a procedure called "hot-swapping"). This feature allows for updates, modifications, or replacement of modules without interrupting the use of other modules in the hub.

DEChub 900 MultiSwitch Description

The DEChub 900 MultiSwitch hub complements Digital's DEChub ONE family of products. It uses advanced hub technology to provide complete backward compatibility with the DEChub 90 network modules.

The DEChub 900 MultiSwitch, referred to as the DEChub 900MS, with either 90- or 900-series modules installed, becomes an integral part of any distribution subsystem within a structured wiring environment. It is a higher density hub that is capable of supporting multiple network technologies. It has a flexible channel architecture that can be extended to support Ethernet, Token Ring, and Fiber Distributed Data Interface (FDDI) technologies, as well as high-speed emerging technologies such as Asynchronous Transfer Mode (ATM).

Supported Modules List

HUBwatch software manages the following network modules:

- DECagent™ 90
- Router modules
 - DECbrouter 90T1
 - DECbrouter 90T2
 - DECbrouter 90T2A
- Bridge modules
 - DECbridge™ 90
 - DECbridge 90FL
 - DECbridge 900MX
- Switch modules
 - DECswitch 900EE
 - DECswitch 900EF
 - PEs switch 900TX
- RoamAbout Access Point module
- DECconcentrator 900MX
- Repeater modules
 - DECrepeater™ 90C
 - DECrepeater 90FA
 - DECrepeater 90FL
 - DECrepeater 90FS
 - DECrepeater 90T
 - DECrepeater 90T+
 - DECrepeater 90TS
 - DECrepeater 900TM
 - DECrepeater 900GM
 - DECrepeater 900FP

- Terminal Server modules
 - DECserver™ 90L
 - DECserver 90L+
 - DECserver 90M
 - DECserver 90TL
 - DECserver 900TM

More Modules

You can also use HUBwatch to display the DECmau 900TL, DECrepeater 900SL and 900TL, DECpacketprobe, and WANrouter 90 modules. HUBwatch recognizes and displays these modules in the Hub Front Panel window, but it does not allow you to manage them.

Related Information

For more complete product information about the DECagent 90, the DEChub 900, or the network modules, see the online Help topic for that device. The following related information also may be useful.

| For Information About... | See... |
|--------------------------|---|
| DEChub Firmware Updates | <i>/pub/DEC/hub900/README at ftp.digital.com</i> |
| DECagent 90 | <i>DECagent 90 User's Information</i> |
| Hub Manager | <i>DEChub 900 Owner's Manual DEChub 900 MultiSwitch Owner's Manual</i> |
| DECbridges | <i>DECbridge 90 Owner's Manual DECbridge 90FL Owner's Manual DECbridge 900MX Owner's Manual</i> |
| DECswitches | <i>DECswitch 900EE Installation PEswitch 900TX Installation RoamAbout Access Point Installation</i> |

| For Information About... | See... |
|---------------------------------|---|
| DECrepeaters | <i>DECrepeater 90C Owner's Manual</i> <i>DECrepeater 90T Owner's Manual</i> <i>DECrepeater 90TS Installation and Configuration Guide</i> <i>DECrepeater 90FA Owner's Manual</i> <i>DECrepeater 90FS Installation and Configuration Guide</i> <i>DECrepeater 90FL Owner's Manual</i> <i>DECrepeater 900FP Installation and Configuration Guide</i> <i>DECrepeater 900GM Installation and Configuration Guide</i> <i>DECrepeater 900TM Installation and Configuration Guide</i> |
| DECservers | <i>DECserver 90L+ Owner's Manual</i> <i>DECserver 90L Owner's Manual</i> <i>DECserver 90TL and 90M Owner's Manual</i> <i>DECserver 900TM Owner's Manual</i> |
| DEC WANrouters | <i>DEC WANroute r90/150/250 Management</i> |
| Miscellaneous | <i>Open DECconnect Application Guide</i> <i>DECconnect System Planning and Configuration Guide</i> |

2

Management Methods

Types of Management Methods

Introduction

You can use the same graphic user interface to manage network modules both in-band and out-of-band.

Definitions

The **DECagent 90** is a 90-series network management agent. The DECagent 90 is a self-contained module. It uses a Motorola™ 68000 CPU and has two ports: a ThinWire port for 10Base2 networks and an asynchronous RS-232 standard port.

The **Hub Manager** is a microprocessor-based controller used to monitor, configure, and control the DEChub 900MS (MultiSwitch). It is built into the DEChub 900MS backplane.

In-band management is the normal network-based method of accessing the hub. Access is available over a LAN or WAN.

Out-of-band management (OBM) is typically used for hub management when the network is not available. This method allows local or remote access to the hub using Serial Line IP (SLIP) through a terminal server port or direct connection to the OBM port on a DECagent 90 V2.0 module or DEChub 900MS.

SLIP is the Serial Line Internet Protocol, used for transmitting IP packets across serial lines.

In-Band Management

Introduction

You can manage both 90-series and 900-series modules in-band with the DEChub 900 MultiSwitch. You generally perform in-band management with the HUBwatch network management application; however, you can manage the DEChub 90 and 900 MS and their modules in-band with any other network management system that supports native SNMP.

Management Options

There are three methods for managing network modules in-band:

- **Using the in-band address of a DEChub 900MS Manager**

This is the preferred method for managing a DEChub 900MS that contains either 90-series network modules or 900-series network modules. This method requires the presence of an IP services module like the DEC repeater 900TM. There are several 90-series modules that you cannot manage this way, including the DECbridge 90 and 90FL, the DECserver 90L and 90L+, and the DECwanrouter 90.

- **Using the in-band address of a DECagent 90**

This is the preferred method for managing a DEChub 90 and its modules. It is the required method if you want to manage a DEChub 900MS populated with 90-series modules and you do not have an IP services module.

- **Using the in-band address of a standalone module**

Some modules are standalone: that is, they have their own built-in SNMP agents. You can manage these modules directly by supplying the IP address of that agent.

The differences in management methods are reflected in the HUBwatch windows you see and in the MIB objects that you can access.

Using IP Addresses

DEChub 900MS Manager IP Address

The DEChub 900MS Manager does not have an in-band connection for communicating with a network management system. Instead, you use a network module that supports IP Services, such as the DECrepeater 900TM, as the primary path for in-band management. To do this, install a module that provides IP services into a slot of the DEChub 900MS chassis. The Hub Manager uses this IP address to communicate with the other installed modules. This IP address is assigned to the hub using Hub Setup and must be different from the module's IP address.

The combination of the IP address and slot location establishes the primary path for in-band management. If you move the module to another slot, you must reconfigure the hub to utilize the new slot.

Important Reference—For more information on setting up IP services, see the *DEChub 900 MultiSwitch Owner's Manual*.

DECagent 90 IP Address

With this management method, you manage a DEChub 90 and its 90-series modules. You can also manage 90-series modules in a DEChub 900MS so they can take advantage of DEChub 900MS features such as redundant power and Hub Status Display messages. However, you cannot use other features like backplane LAN segments with this method. If you also have 900-series modules installed in the hub, you must manage them as standalone modules.

Standalone Module IP Address

You can directly access modules that have their own built-in SNMP agents. You manage these modules by supplying the IP address of the agent. When you use this method, the module that you access appears to be the only one in the hub even if there are other modules physically present.

Proxy SNMP Agents

Note that a proxy agent (such as the DECagent 90) is still required for 90-series devices that do not support the SNMP protocol (for example, the DECbridge 90, the DECbridge 90FL, the DECserver 90L, and the DECserver 90L+). However, you can directly manage all the DECrepeaters with the Hub Manager using the IETF repeater MIB.

Out-of-Band Management

- Overview** You manage the DEChub 900MS and 90- and 900-series network modules with out-of-band management (OBM) through the OBM port.
- This method is similar to in-band management, except that you assign an OBM IP address and an OBM port speed from the setup port Hub Installation menu. The IP address and the port speed at each end of the communications link must be identical. If you want to switch from managing your DEChub 900MS or standalone network modules in-band to managing them out-of-band, select the OBM IP address in HUBwatch.
- OBM Port and SLIP** The OBM port allows you to manage network modules with HUBwatch over a Serial Line Internet Protocol (SLIP) using a modem, or a direct connection to the OBM port. If your network management application supports PING echo, you can use it to verify the SLIP connection.
- You can also manage DEChubs by establishing a connection from HUBwatch to a terminal server that supports SLIP . If you have a DECserver 900TM, DECserver 90TL, or a DECserver 90M installed in your hub, you can establish a SLIP connection between one of the terminal server ports and the Hub Manager OBM port. Full size network modules (except the DECserver 900TM) also have an OBM port.
- References** Refer to your terminal server documentation for instructions on setting up SLIP connections and to the *DEChub 900 MultiSwitch Owner's Manual* for cable and adapter information.

SNMP Concepts

How HUBwatch Uses SNMP Agents

Introduction

HUBwatch software uses the Simple Network Management Protocol (SNMP) to perform GETs and SETs on the MIB values of network modules. HUBwatch sends these SNMP commands to the DECagent 90, the DEChub 900MS Hub Manager, or directly to network modules with built-in agents.

Definitions

Simple Network Management Protocol (SNMP) is a standards-based protocol for network management, usually used in TCP/IP networks. SNMP communicates management information between a manager and an agent.

An **SNMP agent** is an entity in a hardware device that executes SNMP requests. The agent responds to requests for information by the network management stations. The agent performs GET and SET operations, generates appropriate traps, and oversees access control.

Types of SNMP Agents

HUBwatch software communicates with the following types of SNMP agents:

- The DECagent 90.
- The DEChub 900MS Hub Manager.
- SNMP agents built into the modules.

Managing the DECagent 90

The DECagent 90 is a 90-series network management agent. You use it to manage 90-series network modules that do not have their own SNMP agents. You can install and use it either standalone in the DEChub 90 chassis or the DEChub 900MS chassis.

Acting as a proxy SNMP agent, the DECagent 90 accepts SNMP messages on behalf of the 90-series modules, sends an appropriate command to the queried module, and waits for a response. When it receives a response from the module, it sends an SNMP packet to the querying HUBwatch software.

The DECagent 90 has a single Internet Protocol (IP) address and implements the protocols required for SNMP-based access. The protocols used are ARP, IP, UDP, SNMP, and BootP.

Managing the DEChub 900MS

The Hub Manager is a microprocessor-based controller used to monitor, configure, and control the DEChub 900MS (MultiSwitch). It is built into the DEChub 900MS backplane. Using either remote management control or default local control, it provides a central point of control for DEChubs and installed modules, and for allocation of hub resources to installed modules.

For more information about the Hub Manager, refer to the *DEChub 900 MultiSwitch Owner's Manual*.

Managing Modules with Built-In Agents

These network modules have their own SNMP agents and can be managed directly:

- DECbridge 900MX.
- DECbrouter 90T1.
- DECbrouter 90T2.
- DECbrouter 90T2A.
- DECconcentrator 900MX.
- DECrepeater 90FS.
- DECrepeater 90TS.
- DECrepeater 900TM, 900FP, and 900GM.
- DECserver 90M.
- DECserver 90TL.

- DECswitch 900EE.
- DECswitch 900EF.
- PEs switch 900TX.
- RoamAbout Access Point.

Using the Agent File

The Agent file contains a list of SNMP agents that you can use to manage hubs and network modules. When you use an Agent file you can display a specific hub or module by selecting the agent and making it current. With an Agent file, you can also start HUBwatch by specifying an Agent name for a specific hub or module instead of using its IP address.

To manage an SNMP agent with HUBwatch, add an entry for the agent in the Agents file. You can add an agent by using a pulldown option on the Community Table window. See the *Agent File List* section in this chapter and the *SNMP Communities and Agents* section in Chapter 7 for more information.

Agents Must Have an IP Address

Each SNMP agent you want to use must have an associated IP address. You typically assign this address when you configure the hub or the module using a console connected directly to the module or with remote assignment using a boot-tab file. Once you associate an Agent name with an IP address, you can start HUBwatch using just that Agent name.

See *HUBwatch Installation and Configuration* or the module's installation manual for more information.

Agent File Location

You can find the Agent file in this location:

```
HUBWATCH_LIBRARY:hw_agent.dat
```

You can change the location of this file by setting the HUBWATCH_LIBRARY environment variable. Initially, the install program sets this variable to point to the \userdata subdirectory of the directory where you installed the HUBwatch software.

HUBwatch SNMP Communities

Definition

A **community** is one or more modules that you manage as a group. Each community is uniquely identified on the network by an IP address and a community name.

The structure of an SNMP community and how you manage that community differ depending on whether you are using a DECagent 90, the Hub Manager, or built-in agents as the SNMP agent.

Community Names Control Access

You use community names to control access. Each software request contains a community name that the agent uses, like a password, to verify that this requester is authorized to access that agent's management information base (MIB) or a subset of that MIB.

Each agent generally has three community names: a read name, a read-write name, and, possibly, a trap name. This allows you to provide wide access to module status information and limited access to actual module management. For example, for a GET operation, the agent accepts either the read-only or the read-write name. For a SET operation, the agent accepts only the read-write name.

DECagent 90 Community Description

When you manage communities with the DECagent 90, a community can consist of:

- A single hub.
- A double hub (two DEChub 90 hubs daisy-chained together that you manage as one hub community with 16 slots).
- A standalone module (like the DECbridge 90 or the DECserver 90L+).
- A single LAN segment on the DEChub 900MS.

At least one community always exists in a DECagent 90, the community to which the agent itself belongs. This entry is always in the first row of the Communities list box as the Index 1 entry.

Management Recommendations—A single DECagent 90 can manage from 1 to 64 communities; however, practical limits are much lower and are performance dependent. For hubs that contain only bridge and repeater modules, Digital recommends that there be one DECagent 90 for every eight single hubs or every four double hubs. For hubs that contain terminal servers, the maximum number of modules managed by one DECagent 90 should not exceed 64.

**DEChub 900MS
Manager
Community
Description**

When you manage communities with the DEChub 900MS Manager, a community cannot extend beyond the hub backplane.

A single hub can have up to nine communities. The DEChub 900 assigns a community to each slot in the backplane and also a community for the Hub Manager. For example, a DEChub 900MS that contains eight DECreeper 900TM modules must have nine communities—one for each DECserver module and one for the Hub Manager. HUBwatch handles the translation of agent assignment from the backplane to the Hub Front Panel transparently.

**DECagent 90
Community in a
DEChub 900MS**

There are some important community considerations you should be familiar with when you use a DECagent 90 in a DEChub 900MS. For example, If you want to manage a DECbridge 90 with a DECagent 90 in a DEChub 900MS, you must first create a standalone community on the DECagent 90 and then add the DECbridge 90 to it. For more information on this and other important community tasks, see the *HUBwatch Installation and Configuration* manual.

**Built-In Agent
Community
Description**

If a module has a built-in SNMP agent, it can manage only itself. The only community this agent knows about is its own.

Autodiscovery

- Definition** **Autodiscovery** is the capability of the DEChub 900MS and the DECagent 90 to detect, identify, and configure certain network modules when they are installed in a hub. Autodiscovered modules automatically appear in the HUBwatch Front Panel window.
- Rules** You must manually add any modules that cannot be autodiscovered. You use either the hub's console setup port or the HUBwatch Add Module window to do this task.
- If you physically remove a configured module and substitute a new module, the new module will not be autodiscovered until you delete the old module from the configuration (using the Community Table Delete option).
- DEChub 900
Autodiscovery** The DEChub 900MS autodiscovered most network modules. These are the modules that it does not autodiscover:
- DECserver 90L.
 - DECserver 90L+.
 - DECbridge 90.
 - DECbridge 90FL.
- DECagent 90
Autodiscovery** Autodiscovery requires Bus Master services like those found in a DECagent 90 with V.2.0 firmware. If you are using a previous version of DECagent 90 firmware, you need the assistance of a DECbridge 90 to use this feature. The DECagent 90 is capable of autodiscovering these modules:
- DECagent 90.
 - DECrepeater 90T.
 - DECrepeater 90C.
 - DECrepeater 90FA.
 - DECrepeater 90FL.

- DECrepeater 90FS.
- DECrepeater 90T+.
- DECrepeater 90TS.
- DECserver 90L+2.
- DECserver 90M.
- DECserver 90TL (running the DECserver Network Access Software).

Hint

To assist network management applications that feature autotopology or autodiscovery, leave the agent's read-only community string as public.

The HUBwatch Community Table Window

Introduction You use the Community Table window to manage SNMP agents and their associated SNMP communities.

Community Table Window

The screenshot shows the 'Community Table' window with the following sections:

- Identification:** Includes a logo, 'Current Agent: MOB', 'Current Hub: public', and 'Agent File: C:\hubwatch\userdata\hw_agent.dat'.
- Agent File:** A table with columns: Agent Type, Agent, IP Address, Community, and Select. It contains two rows for 'other' agents at 'hub2.com' and 'hub3.com'.
- Communities of Current Agent:** A table with columns: Index, Hub Type, Read-only Community, Read-write Community, and Select. It contains two rows, with the first row selected.
- Buttons:** 'Make Current', 'Agent Options', 'Add', 'Delete' on the right; 'OK', 'Apply', 'Refresh', 'Cancel', 'Help' at the bottom.

| Agent Type | Agent | IP Address | Community | Select |
|------------|----------|-------------|-----------|--------------------------|
| other | hub2.com | 00.00.00.00 | public | <input type="checkbox"/> |
| other | hub3.com | 00.00.00.00 | public | <input type="checkbox"/> |

| Index | Hub Type | Read-only Community | Read-write Community | Select |
|-------|------------------|---------------------|----------------------|-------------------------------------|
| 1 | DEChub90 16-slot | public | public | <input checked="" type="checkbox"/> |
| 2 | Standalone | public | public | <input type="checkbox"/> |

LKG-9465-941

Parts of the Community Table Window

Introduction

The Community Table window has three main sections:

- Identification list.
- Agent File list.
- Communities of the Current Agent list

Identification List

There are two items in the Identification list:

- Current Agent

This entry is the agent that you are using to manage a particular community. The entry for the current agent is highlighted in the Agent File box.

- Current Hub

This entry is the community string (name) of the community that you are managing. If the current agent is a DECagent 90, the current community entry is highlighted in the Communities of the Current Agent box. If the current agent is either a DEChub 900 Hub Manager or a module with its own SNMP agent, such as a DECserver 90TL, the Communities of the Current Agent box is grayed out on the Community Table window.

Agent File List

This list reflects the contents of the Agents file. You build this list as you add agents to or delete agents from your network.

The Agent File list box contains the following information about each agent:

- The type of agent (for example, DECagent 90 or DECconcentrator 900MX).
- The name of the agent.
- The IP address of the agent.

- The agent's community string, or password, for the particular community being managed by the agent. HUBwatch software uses this community string in all SNMP requests generated while this community is current. Therefore, access control will vary depending on the type of string you use.

Communities of the Current Agent List

DEChub 900MS Manager – If the DEChub 900MS Manager is the current SNMP management agent, the Communities list is grayed out to indicate that it is not functioning. The Hub Manager cannot manage multiple communities; so there is no need to switch from one community to another. As a result, you can do all the community management tasks in the Agent file list by selecting and modifying the agent.

DECagent 90—If a DECagent 90 is the current SNMP management agent, this list shows the communities that you can manage. You can see the following information about each community:

- An index entry for each community—a managed hub or standalone module.
- A Hub Type icon that defines the type of hub being managed by the agent. Three hub configurations are supported:
 - Standalone—A standalone module.
 - Single—An 8-slot hub. (Unique icons are provided for the DEChub 90 and DEChub 900MS hubs.)
 - Double—Two 8-slot hubs daisy-chained together to create a 16-slot hub. (Only the DEChub 90 supports this configuration.)
- The read-only community string used for GET type operations.
- The read-write community string used for SET type operations.

The list of SNMP communities appears only if you selected the default community for the DECagent 90 from the Agent File list. In the DECagent 90, all communities are contained within the default community.

Standalone Modules—If a standalone module is the current SNMP management agent, the Communities of the Current Agent list is grayed out to indicate that it does not apply. The standalone modules can manage only their own community; so there is no need to switch from one community to another. Therefore, you can do all the community management tasks in the Agent list box by selecting and modifying the agent.

How You Use the Community Table Window

Introduction You use the Community Table window to manage SNMP agents and communities.

Management Tasks You can perform the following management tasks from the Community Table window:

- Adding or deleting agents.
- Adding or deleting communities.
- Modifying agents or community information.
- Changing the current agent or current community.

Reference Please see *Opening Hub Management Windows* in Chapter 6 for instructions about opening this window. See the *SNMP Communities and Agents* section in Chapter 7 to learn how to do these tasks.

Related Information The following related information may be useful.

| For Information About... | See... |
|---------------------------------|---|
| SNMP management concepts | <i>The Simple Book—An Introduction to Management of TCP/IP-Based Internets</i> by Marshall Rose |

4

Starting HUBwatch

HUBwatch Startup

- Introduction** This section tells you how to start the HUBwatch software. You can start HUBwatch in either of two ways:
- As a standalone Windows application.
 - As an add-on application to network management software like POLYCENTER or OpenView.
- Before You Start** The first time you start HUBwatch, you must supply an IP address for the agent you want to use. You can just accept the remaining default parameters. However, the default community name is *public*. If the community name of the agent you want is different from the default name, you must enter the correct community name.
- Adding Agents** Once you run HUBwatch, you should add entries for the agents you want to use to the Agent File list of the Community Table window. Afterwards, you can run HUBwatch using the name of the agent instead of its IP address. If you added agents to the Agent File list in a previous version of HUBwatch, you can run HUBwatch using the name of one of those agents.
- Agent File Compatibility** HUBwatch V3.1 uses a different Agent file format than previous versions. HUBwatch V2.0 Agent files are compatible and are converted to the new format automatically. However, V3.1 Agent files will not work with HUBwatch V2.0.

Reference

Use this table to find more information about adding agents.

| Section | Chapter |
|------------------------------------|----------------|
| <i>Community Table Window</i> | Chapter 3 |
| <i>How You Open Them</i> | Chapter 6 |
| <i>SNMP Communities and Agents</i> | Chapter 7 |

Starting HUBwatch Standalone

Introduction You can start HUBwatch as a standalone Windows application using a text box or from a command line.

Text Box Startup Steps Do the following, to start HUBwatch using a text box.

| Step | Action |
|------|--|
| 1 | From the application group where the HUBwatch icon resides, double click on the HUBwatch icon. You can also double click on HUBWATCH.EXE from the File Manager. Result: A text box appears. |
| 2 | Supply either an Agent name or an Internet address and click on <input type="button" value="OK"/> . |
| | Result: The HUBwatch Front Panel view appears. |

Additional Startup Information The Startup text box allows you to enter additional information about how you want HUBwatch to start. The following table explains the fields of this box.

| Field | Explanation |
|------------|---|
| IP Address | Use an integer in the format <i>d.d.d.d</i> where <i>d</i> is a decimal number less than 256. |
| Agent Name | The name of the agent you want to use. Example: agent1 |
| Community | The community name used in requests to the agent. The default name is public. Example: myhubs |
| Timeout | The length of time the PC waits for a response after sending a request to the agent. The default is five seconds. |

| Field | Explanation |
|---------|--|
| Retries | The number of times that the PC resends a request to the agent after a timeout. The default number is 1 retry. |

Command Line Startup Steps

Do the following to start HUBwatch from a command line.

| Step | Action |
|------|--|
| 1 | Select Run from the File or Program Manager. |
| 2 | Enter the start command. Examples: c:\hubwatch\hubwatch.exe -x 20.40.32.00 c:\hubwatch\hubwatch.exe -a agent1 Result: The HUBwatch Front Panel view appears. |

Start Command Line Syntax

Use the following syntax when starting HUBwatch from a command line.

```
path\HUBWATCH.EXE -x ip-address -a agent-name -c community
-r retries -t timeout
```

Start Command Variables

Use the following command variables for the start command.

| Variable | Value |
|-------------------|---|
| <i>path</i> | The location of HUBWATCH.EXE. If the current directory is correct, you do not need to enter the path. |
| <i>ip-address</i> | The Internet address in the form <i>d.d.d.d</i> , <i>d</i> being a decimal less than 256. |
| <i>agent-name</i> | The name assigned to the agent module. Example: -a agent1 |
| <i>community</i> | The name assigned to the community. When you enter the community name, use quotation marks Example: -c "public" |

| Variable | Value |
|-----------------|---|
| <i>retries</i> | An integer that sets the number of retries allowed. The default value is one retry. |
| <i>timeout</i> | The timeout period in seconds. The default timeout period is five seconds. |

Starting HUBwatch from POLYCENTER

Introduction

You can start HUBwatch as a POLYCENTER application from the following platforms.

- POLYCENTER SNMP Manager 300
- POLYCENTER Network Manager

Starting from SNMP Manager

Do the following to start HUBwatch from POLYCENTER SNMP Manager 300.

| Step | Action |
|------|--|
| 1 | Select the hub from the POLYCENTER Map window. |
| 2 | Click on the HUBwatch option on the POLYCENTER Map menu bar and click on Manage. |
| | Result: The Hub Front Panel view appears. |

Starting from Network Manager

Do the following to start HUBwatch from the POLYCENTER Network Manager.

| Step | Action |
|------|--|
| 1 | <p>Start the POLYCENTER Network Manager software by entering the appropriate command.</p> <p>Example:</p> <pre>\$ MANAGE/ENTERPRISE/INTERFACE=DECWINDOWS <input type="button" value="Return"/></pre> <p>Result: The POLYCENTER Map window appears.</p> |
| 2 | <p>Click on the File menu and choose an existing domain or open a new domain (The following instructions assume you have opened a new domain).</p> <p>Result: The New Domain window appears.</p> |
| 3 | <p>Enter the domain name in the New Domain window and click on <input type="button" value="OK"/>.</p> |
| 4 | <p>Return to the POLYCENTER Map window and click on the Lock icon in the menu bar to unlock the window.</p> |
| 5 | <p>Click on the Edit menu and choose Toolbox.</p> <p>Result: The POLYCENTER Toolbox window appears.</p> |
| 6 | <p>Click on the SNMP icon.</p> <p>Result: The Add Entity - Enter Entity Information window appears.</p> |
| 7 | <p>Click on the desired Hub icon.</p> <p>Result: The Hub icon is highlighted.</p> |
| 8 | <p>At the SNMP entry box, enter the IP name of the hub and click on <input type="button" value="Apply"/>.</p> <p>Result: A more detailed version of the Add Entity - Enter Entity Information window appears.</p> |

| Step | Action |
|------|--|
| 9 | In the Add Entity window: <ol style="list-style-type: none"> Enter the IP address (for example, 12.14.213.56). Enter the Read Community Name (for example, public). Enter the Write Community Name (for example, public). Click on <input type="button" value="OK"/> to apply the information. |
| 10 | Move the pointer to the POLYCENTER Map window and click MB2 to populate the map. |
| 11 | Click on the Hub icon in the POLYCENTER Map window. |
| 12 | Click on the Applications menu and choose HUBwatch. Result: The Hub Front Panel window appears. (This may take several seconds.) |

Related Information

These instructions also apply to DECMcc V1.2 and V1.3. To run HUBwatch from DECMcc V1.2, all DECMcc users need to modify their own MCC_RESOURCE.DAT files according to the instructions in MCC_SYSTEM:MCC_HUBWATCH.COM.

Adding HUBwatch

For information about adding the HUBwatch application to POLYCENTER, see *HUBwatch Installation and Configuration*.

Starting HUBwatch from OpenView

Introduction

You can start HUBwatch as an application from a platform running OpenView.

Starting HUBwatch

Do the following to start HUBwatch from OpenView.

| Step | Action |
|------|---|
| 1 | Start OpenView. |
| 2 | Open the Map file. Result: The Internetwork view appears. |
| 3 | Double click on the icon of the network you want to manage. Result: The Network view appears. |
| 4 | Double click on the HUBwatch icon for the hub or module you want to manage. Result: The Hub Front Panel view appears. |

Starting HUBwatch Using SLIP

SLIP Connection

For instructions about starting HUBwatch while using a SLIP connection, see the *HUBwatch Installation and Configuration* manual.

Using Backplane LAN Segments

LAN Segments

Introduction

The DEChub 900MS backplane has multiple, flexible channels that you can use to create internal LAN segments within the hub. You connect network modules to these segments so they can exchange data as if they were on external LANs. You can use HUBwatch software to create and delete segments and create and delete connections to the segments. You can do all these tasks remotely without manipulating hardware.

Hardware Overview

The DEChub 900MS backplane contains:

- **One dedicated Ethernet ThinWire segment**

The dedicated Ethernet ThinWire segment provides backward compatibility for the DEChub 90 modules. The dedicated Ethernet ThinWire segment always exists in the hub configuration; you cannot delete it.

- **Two dedicated Token Ring segments**

The Token Ring segments provide support for token ring network modules. You cannot currently display or manage the Token Ring segments with Version 3.1 of HUBwatch.

- **Multiple flexible LAN segments**

These are the internal Ethernet, FDDI, or Token Ring LAN segments that modules use to share data.

Interconnect Functionality

Hubwatch uses SNMP to direct the DEChub 900MS Hub Manager to create or delete LAN segments on the backplane. You use the interconnect functionality just as you would use cables to connect module ports to different backplane LAN segments. However, now you can perform configurations and connections without manipulating hardware.


You can organize the backplane resources for either Ethernet, Token Ring, or FDDI configurations depending on the type of LAN segment you need. You access all the interconnect functionality from the LAN Interconnect window.

Important Information—You cannot currently display or manage the Token Ring segments with Version 3.1 of HUBwatch.

How You Manage LAN Segments

Introduction The DEChub 900MS Hub Manager displays the backplane port-to-segment connections in the LAN Interconnect window.

LAN Interconnect Window Figure



LKG-9463-94I

LAN Interconnect Window Parts

| | |
|------------------------|--|
| Introduction | The following sections describe the different features of the LAN Interconnect window and how you use them. |
| LAN Segments | The LAN segments appear along the left side of the window. An icon and a name identify each segment. When you display the LAN Interconnect window for a hub that uses the factory defaults, only the default dedicated Ethernet ThinWire segment appears. You cannot delete this segment. Additional segments appear below the ThinWire segment as you create them. |
| Network Modules | <p>The network modules appear across the top of the LAN Interconnect window. A slot position in the hub and a module icon identify each module. You can access a management summary window for a particular module by double clicking on its icon.</p> <p>For most network modules, connection pulldowns identify the backplane ports. There is one connection pulldown for each backplane port. For FDDI modules (for example, the DECbridge 900MX), one common pulldown represents either the one or two backplane ports actually in use when one or both the A and B ports are on the backplane. This common pulldown lets you to make one logical connection to an FDDI backplane LAN segment.</p> |
| Port Colors | On all modules, different colors identify different types of backplane ports. When a port is not connected, the port color shows the type of LAN segment to which you can connect it. |

This table lists the colors.

| Port Color | LAN Segment Type |
|-------------------|-------------------------|
| Blue | ThinWire Ethernet |
| Green | Flexible Ethernet |
| Red | FDDI |
| Yellow | Multiple Types |

When you connect a port to a LAN segment, the port takes on the color of that segment.

Port Connector Stars

Ports that have stars in their connection pulldowns are parts of a port group.

Additional LAN Interconnect Buttons

- Introduction** Some modules, like the DECbridge 900MX and the DECconcentrator 900MX, have features that are available from the [Expand](#), [Config](#), and [Group](#) buttons.
- Expanded View** Some modules have more than four backplane ports (for example, the DECbridge 900MX and the DECrepeater 900FP). However, the LAN Interconnect window can display, at most, only four ports per module. To perform LAN interconnect functions on modules with more than four ports, you must open the Expanded View window. You open this window by selecting a module with more than four ports and clicking on the [Expand](#) button.
- Station Configuration** Some modules, like the DECbridge 900MX and the DECconcentrator 900MX, have ports that you can configure between the front panel and the backplane. By default, these ports are active on the front panel; so you do not see them on the LAN Interconnect window until you move them to the backplane. To move these ports to the backplane, you need to open the Station Configuration window. You open the window by selecting a module and clicking on the [Config](#) button.
- The LAN Interconnect window does not display any unusable backplane ports.
- Grouping Ports** You can group ports on the DECrepeater 900FP, which supports switching ports onto different internal LAN segments. Grouping ports allows you to connect multiple backplane ports using a single connection pulldown rail.
- You access this function through the Port Grouping window. To open the window, select a repeater module and click on the [Group](#) button. The LAN Interconnect window does not display any unusable repeater backplane ports.

Grouping Hint

The Port Grouping window displays the state of the module's backplane ports. The LAN Interconnect window displays the state of the hub's backplane ports. If you group a port connector and then disconnect it using the Port Grouping window, the connector will appear in the LAN Interconnect window as though it were available for use. However, the module that controls the port for that connector will not enable that connection. As a result, you can hook up the connector, but it will not function until you use the Port Grouping window to enable the connector's port group.

Connecting Modules

| | |
|--------------------------------|---|
| Introduction | This section provides some information about connecting module backplane ports to LAN segments. You can find additional instructions in the online help. |
| How to Connect a Module | To connect a module to a segment, click on the backplane port and drag the connection pulldown to the desired segment. When you click on a backplane port, all inappropriate LAN segments are grayed out. HUBwatch will not let you connect to an inappropriate LAN segment. |
| 90-Series Modules | <p>Most 90-series network modules have only one backplane port. By default, most 90-series network modules are always connected to the DEChub 900MS dedicated Ethernet ThinWire segment. You cannot use the HUBwatch LAN Interconnect window to change these connections.</p> <p>Newer 90-series modules, like the DECpeater 90FS and 90TS, do not have this restriction. They can connect to the ThinWire and to the top segment of the same LAN type.</p> |
| 900-Series Modules | All 900-series network modules have one or more backplane ports. You can connect 900-Series modules to backplane LANs of the same LAN type as that of the module's backplane port (Ethernet, FDDI, and so forth). |

Interconnect Tasks

Using the LAN Interconnect Window

You can do the following management tasks from the LAN Interconnect (or Expanded View) window:

- Create a LAN segment.
- Connect a module to a LAN segment.
- Disconnect a module from a LAN segment.
- Delete a LAN segment.
- Modify some of a network segment's characteristics.
- Expand the LAN Interconnect window
- Configure a module's ports between the front panel and the backplane.
- Logically group some of a module's backplane ports and treat them as a single connection.

Reference

Please see *Backplane LAN Segments* in Chapter 7 for instructions about accessing this window. Chapter 1 also explains how to use the HUBwatch Help to get step-by-step instructions for any of these tasks.


Configuration Example 1

Introduction

The following example configuration shows you how you might use HUBwatch to create LAN segments and connect repeater modules to them.

Configuration 1 Figure

This figure shows how you configure repeaters on the LAN segments.



LKG-8412-93I

Configuration 1 Description

This figure shows a mix of 90-series and 900-series repeaters. This configuration shows how you can integrate 90-series repeaters into the DEChub 900MS network environment. By default, this hub connects 90-series repeaters to its dedicated ThinWire Ethernet LAN segment. You cannot change these connections (as denoted by the solid black connector).

In a similar way, the DEChub 900MS connects backplane port 1 of 900-series repeaters to the dedicated Ethernet LAN segment. You can, however, use the LAN Interconnect window to disconnect port 1, but you cannot connect it to any of the flexible Ethernet LAN segments. The remaining backplane ports of 900-series repeaters are flexible channel ports. They are not connected by default and you can connect them to any of the

flexible Ethernet LAN segments (also referred to as "backplane Ethernet LAN segments"). You cannot connect these ports to the dedicated ThinWire Ethernet LAN segment. HUBwatch does not let you connect repeater ports 1 and 2 to the same type of LAN segments because each port supports a different network technology. When you use the flexible channel port over port 1 for network communications you reduce the number of hops by 50 percent, minimizing the number of repeater hops in the network configuration.

Extended LAN

Notice that by connecting port 1 of a DECRepeater 900TM to the dedicated ThinWire Ethernet LAN segment, all 90-series repeaters installed in the hub gain access to the flexible LAN segment to which repeater port 2 is connected. In effect, the two LAN segments become an extended LAN.


Caution

Do not disconnect the IP services from a LAN segment if the Network Management Station uses that segment to reach the IP services module. For more information on IP services, see *DEChub 900MS Manager IP Address* in Chapter 2.

Configuration Example 2

Introduction This configuration is an example of an external FDDI backbone connected to bridged Ethernet Workgroups.

Configuration 2 Figure



LKG-9457-94I

**Configuration 2
Description**

Configuration 2 presents an FDDI ring that is external to the hub. The ring represents the backbone of the network. The hub is used to connect the ring to end stations. Each repeater or terminal server connects end users to their own LAN segment to form a Workgroup. These LANS, or Workgroups, are then connected to one another through the DECbridge 900MX. The bridge not only provides connectivity, but also allows you to filter user defined traffic if a Workgroup is not interested in it.

Single Rail


Note that the DECbridge 900MX shows multiple connections on a single rail. Each of these connections is black with a star in the box. This single rail notation indicates that you cannot display or move the individual connections from this particular window.

**Moving
Connections**

To view or move the individual connections, select the DECbridge 900MX and click on the button. This action opens the Expanded LAN Interconnect window for the DECbridge 900 MX (see the following *Expanded LAN Interconnect Window Figure* for an example).

Expanded LAN Interconnect Window Figure

You use this window with modules that have more than four ports.



LKG-9519-941

Steps for Building Configuration 2

You build this configuration in two stages. In the first stage, you create LAN segments. In the second stage, you connect modules to them.

Create LAN Segments

Do the following to create LAN segments

| Step | Action |
|------|--|
| 1 | Select the Create LAN button on the LAN Interconnect window. Results: An Ethernet workgroup LAN appears (like Workgroup 1 in the figure). |
| 2 | Repeat this step for the other 3 LAN segments. |

Any 90-series modules automatically come up on the ThinWire. You can not move these modules. However, you must configure the remaining modules as follows.

Connect Modules

Do the following to connect the modules

| Step | Action |
|------|--|
| 1 | Disconnect the first port of the DECRepeater 900TMs and 900GM ThinWire. Result: This action isolates these Workgroups from traffic on the ThinWire LAN segment. Drag the second port connection down to the appropriate Workgroup. |
| 2 | Drag both port connections of the DECserver 900TMs down to the appropriate workgroup. |
| 3 | Select the DECbridge 900MX icon. |
| 4 | Click on the Config button to open the Station Configuration window. |
| 5 | Configure ports 2 through 6 to the backplane. |
| 6 | Return to the LAN Interconnect window. |
| 7 | Click on the Expand button to go into the Expanded LAN Interconnect window. |

| Step | Action |
|-------------|--|
| 8 | Drag connector 3 down to the ThinWire connection. |
| 9 | Drag connectors 2, 4, 5, and 6 down to Workgroups 1-4. |


Finishing—The backplane connections are now complete and the hub is ready for cables to be connected to the front panel.

Connecting FDDI Devices—You must physically connect the A port from the hub neighbor on the external FDDI ring to the B port of the DECbridge 900MX. You must physically connect the B port from hub neighbor on the external FDDI ring to the A port of the DECbridge 900MX. See *fdconfig* in this chapter for more information.

Configuration Example 3

Introduction This configuration is an example of an FDDI backbone ring as part of a HUB backbone.

Configuration 3 Figure



LKG-9111-94I

**Configuration 3
Description**

Configuration 3 presents an external FDDI dual (trunk) ring that is connecting hub concentrator and bridge modules using the backplane FDDI segment. The primary ring enters the hub using the front panel A port of the concentrator in slot 3. The ring exits the hub using the front panel B port of the bridge in slot 6.

**Steps for
Building
Configuration 3**

You create this configuration in two stages. The first stage involves hardware steps. The second stage consists of software steps.

Hardware Steps—When you insert an into the hub, both A and B ports in the module are on the front panel, meaning the backplane FDDI ports are unused. Hubwatch does not display such ports in the LAN Interconnect window. The front panel A/B ports blink green, indicating a disconnect from the ring.

| Step | Action |
|------|---|
| 1 | Insert the FDDI connectors from the external ring into port A in slot 3 and port B in slot 6. |

Hint—To keep the external trunk ring closed, You may want to close the external ring on the outside of the hub by connecting port B in slot 3 with port A in slot 6 using a temporary external fiber cable.


The dual ring is now closed and FDDI port LEDs on both modules should be solid green, provided that the hub neighbors on the ring are operational.

Software Steps—You use HUBwatch for all the subsequent interconnect operations.

| Step | Action |
|------|---|
| 1 | Create a backplane FDDI segment. |
| 2 | Select the slot 3 concentrator icon and click on the Config button to go into the Station Configuration window (see the following <i>Station Configuration Window Figure</i> for an example). |
| 3 | Change the station type to A-front/B-back. Result: The dual ring is now wrapped in both slot 3 and 6 modules. The backplane FDDI port (port B) for slot 3 now appears on the LAN Interconnect window. |
| 4 | Go into Station Configuration window for slot 6 and change the station type to B-front/A-back. Result: The backplane FDDI port (port A) for slot 6 now appears on the LAN Interconnect window. |
| 5 | Connect the FDDI backplane ports for slots 3 and 6 to the backplane FDDI segment by dragging the FDDI pull-downs to the segment. Results: The FDDI ring is now closed using the hub backplane. Hint —You can now disconnect the temporary fiber cable if you used it. |
| 6 | Insert any other FDDI modules into the ring. Before you do this, you have to change the module's station configuration so that both A and B ports are on the backplane. After you change the station configuration, you can connect the modules to the ring in the usual way. |

Station Configuration Window Figure

You use this window to change the station type by clicking on the network building block and selecting a different station type from the menu.



LKG-9518-941

Unlit LEDs

Note that in this configuration, a module is logically isolated from any external FDDI ring connected to its front panel FDDI A/B ports. The LEDs for these ports will be lit.


**Other
Connection
Options**

Configuration 3 figure shows a Workgroup 1 connected to the FDDI backbone using a repeater in slot 7 and the DECbridge 900MX bridge in slot 6. You can also connect other Workgroups to the FDDI backbone using either the bridge front panel Ethernet ports or slave (M) ports on the FDDI concentrator front panels.

Configuration Example 4

Introduction This configuration is an example of a collapsed Ethernet backbone connecting hubs in a star configuration.

Configuration 4 Figure



LKG-9462-941

Configuration 4 Description

Configuration 4 presents a collapsed Ethernet backbone in a central DEChub 900 backplane. Its purpose is to connect multiple hubs around a campus into a star configuration. The hubs connect to the star using a DECrepeater 900FP fiber repeater in the central DEChub 900.

The DECrepeater 900FP ports are segmented or grouped onto three different LANs in the DEChub 900 backplane, thus isolating the hubs into different Ethernet segments. These segments are then bridged together by a DECbridge 900MX, also located in the central DEChub 900 backplane.

Steps for Building Configuration 4

You build this configuration in two stages. In the first stage, you create LAN segments. In the second stage, you connect modules to them.

Create LAN Segments

Do the following to create LAN segments

| Step | Action |
|------|--|
| 1 | Open the LAN Interconnect window from the HUBwatch front panel. |
| 2 | Click on the <input type="button" value="Create LAN"/> button to create an Ethernet hub group LAN. Repeat this step for the other two hub group Ethernet segments. |

Important Information—Any older 90-series modules automatically come up on the ThinWire. You can not move these. However, you must configure the remaining modules using the following steps.


Connect Modules

Do the following to connect modules

| Step | Action |
|------|---|
| 1 | Select the DECrepeater 900FP module and click on the Group button to open the Group window (see the following <i>Port Grouping Window Figure</i> for an example). |
| 2 | Follow these instructions: <ol style="list-style-type: none">Put ports 1-2 into a group labeled <i>1</i>.Put ports 3-8 into a group labeled <i>2</i>.Put ports 9-12 into a group labeled <i>3</i>. |
| 3 | Group the ThinWire port with ports 1 and 2 to provide connectivity for the 90 modules in the DEChub 900 that connect only to the ThinWire port. You must group one of the six pairs of front panel ports with the ThinWire segment. |
| 4 | Go back to the LAN Interconnect window. Drag down backplane connectors 1 through 3 on the DECrepeater 900FP to HubGroup Ethernet LANs 1 through 3 respectively. Result: These connectors represent repeater port groups 1 through 3 created in steps 1 through 3. Leave connector 7 (the ThinWire connector) on the ThinWire segment. This action provides connectivity for the older 90-series modules in the hub that connect only to the ThinWire segment. (Table continued after Figure) |

Port Grouping Window Figure

You use this window to put the ports into different port groups.



LKG-9458-941

| Step (Cont.) | Action |
|-------------------------|---|
| 5 | Select the DECbridge 900MX icon. |
| 6 | Click on the Config button and go into the Station Configuration window. |
| 7 | From this window, configure ports 2 through 4 to the backplane. |
| 8 | Return to the LAN Interconnect window. |
| 9 | From this window, click on the Expand button and go into the Expanded LAN Interconnect window. |
| 10 | Drag connectors 2 through 4 down to HubGroup Ethernet LANs 1 through 3, respectively. |

The backplane connections are now complete and the hub is now ready for the external wiring of hubs to the DECrepeater 900FP front panel ports.

Backplane LAN Segment Configuration Guidelines

| | |
|---|---|
| Introduction | Follow these guidelines when using the LAN Interconnect window to configure LAN segments within the hub backplane. |
| Low Numbered Slot | When you connect ports on FDDI modules to an FDDI flexible LAN segment, start with the module in the lowest numbered slot (for example, slot 1) and connect the modules in ascending order. This ensures that the Hub Manager will allocate backplane channels in the most efficient manner. |
| Six Segments Only | Do not create more than six Ethernet LAN segments. Repeaters cannot be connected to more than six Ethernet LAN segments in the hub backplane. |
| DECRepeater 90FS/TS Restrictions | If you have two or more DECRepeater 90FS or 90TS modules in your hub and you want to connect them to a flexible LAN segment, you must connect port 2 on all of them to the same Ethernet flexible LAN segment. DECRepeater 90FS and 90TS modules are half-height modules; therefore, the Hub Manager can connect only port 2 of these modules to a single flexible LAN segment. |
| Rule | If you connect port 2 of one DECRepeater 90FS or 90TS module to a backplane flexible LAN segment and you attempt to connect port 2 of a different DECRepeater 90FS or 90TS to a different backplane flexible LAN segment, the Hub Manager rejects the connection. |

DECrepeater Configuration Guidelines

| | |
|------------------------------|---|
| Introduction | This section describes some DECrepeater configuration issues. |
| Repeater Restrictions | <p>DECrepeater 900FP, 900GM, and 900TM — You cannot connect these repeaters to more than six flexible LAN segments.</p> <p>DECrepeater 90FS Restrictions — The DECrepeater 90FS and 90TS can connect only on the ThinWire or the top Ethernet flexible channel. If you try to connect a different DECrepeater 90FS to a different flexible channel than another 90FS in the same hub, the Hub Manager attempts to reconfigure backplane connections to accommodate the connection but it will fail.</p> <p>DECrepeater 90T, 90C, 90FA, and 90FL Restrictions — You can connect these repeaters only to the ThinWire segment.</p> <p>DECrepeater 900FP Restrictions — You must group one of the six pairs of front panel ports with the ThinWire segment (or the AUI in a DEChub ONE).</p> |


Preventing Repeater Loops

Introduction This section describes repeater loops and suggests how you can avoid forming them.

What Are Repeater Loops? On the DEChub 900MS backplane, a repeater loop forms when both backplane ports on two 900-series repeaters are connected to the same extended LAN. A repeater loop can cripple the network on which it forms. The *Prohibited Repeater Loop Figure* shows this type of loop connection.

Exception The DECrepeater 900FP is an exceptional case where you can connect multiple backplane ports of the same type to the same LAN segment. See *Preventing 900FP Repeater Loops*.

Prohibited Repeater Loop Figure This is an example of a typical repeater loop.



LKG-9108-941

Kinds of Repeater Loops

For most repeaters, the DEChub 900MS firmware and HUBwatch software prevent repeater loops by applying these restrictions to repeater connections:

Loops Within a Single Repeater Module — HUBwatch software usually does not allow you to connect both the ThinWire port and a flexible channel port of the same repeater to the same type of LAN segment.

For example, DECrepeater 900TM modules have two backplane ports: a ThinWire port and the flexible channel port. You cannot connect these two ports to the same LAN segment because each one is compatible with a different type of LAN segment.

Loops Between Multiple Repeater Modules — The DEChub 900MS firmware does not allow you to connect the flexible channel ports of multiple repeaters to the same flexible LAN segments if the ThinWire ports of these repeaters are currently connected to the ThinWire LAN segment.

What Happens

If you attempt to make a connection that forms a prohibited loop and you answer OK to the Confirmation box, the DEChub 900 MultiSwitch firmware simply refuses to make the connection on the hub backplane and notifies HUBwatch software of the connection request refusal. The HUBwatch software notifies you of the failed connection attempt by redisplaying the actual interconnect.

Preventing 900FP Repeater Loops

You can group the DECrepeater 900FP backplane ports so that they act as if they were on separate virtual repeaters. This port grouping feature overrides any firmware and software repeater loop safeguards. Therefore, you have to be careful when connecting DECrepeater 900FP backplane port groups to LAN segments so as not to form a repeater loop.

The key to preventing this type of repeater loop is to keep track of the port group to which the ThinWire port belongs. This port group is configurable; so you may have to open both the LAN Interconnect Expanded View and the Port Group windows in order to keep track of which port group includes the ThinWire port.

Loop Example


In the *DECRepeater 900FP Loop Figure* for example, the ThinWire port (connection pulldown 7) is connected to port group 1 (connection pulldown 1) on both repeaters. Therefore, the configuration shown forms a loop. If the ThinWire port on the first repeater, 900FP-1, were connected with port group 2, no repeater loop would be formed.

ThinWire Port Group

To determine the port group to which the ThinWire port is connected, open the LAN Interconnect Port Grouping window for the DECRepeater 900FP module in question. For example, in the *Port Grouping Window Figure*, the ThinWire port is connected to port pair 1-2 which is part of port group 1. So, in effect, the ThinWire port is connected to port group 1.

DECRepeater 900FP Loop Figure

This is an example of a DECRepeater 900FP repeater loop.



LKG-9107-941

DECserver Configuration Guidelines

| | |
|-------------------------------|--|
| Introduction | This section describes some DECserver configuration issues. |
| DECserver 900TM Ports | By default, both ports on DECserver 900TM terminal servers connect to the Ethernet ThinWire segment. Port 1 (the operations port) handles normal data traffic between the terminal server and connected terminals. You use port 2 (the maintenance port) for maintenance functions like downline loading software, setting operating parameters, and checking counters. You may want to connect port 2 to a different LAN segment than port 1. This action isolates maintenance operations from user services. |
| DECserver Restrictions | <p>A DECserver 900TM can operate only one channel at a time. The distinction between maintenance and operational channels is a logical one only. You cannot connect the DECserver 900TM to more than one Ethernet LAN segment.</p> <p>Within the DECserver 900TM, there are no restrictions on channel assignment between the maintenance channel and the operational channel. They can be the same channel or different channels depending on the network manager's preference.</p> <p>All DECserver 90 modules can connect only to the ThinWire LAN segment.</p> |
| DECserver Load Host | When you initially turn power on to the hub, all repeater and terminal server modules are by default connected to the dedicated ThinWire LAN segment. Therefore, if the DECserver 900TM needs to access a remote load host, it does so by way of port 2 through the ThinWire LAN segment. Once the software is loaded, port 2 is deactivated and port 1 becomes operational. |

Rule

If you want to connect the DECserver 900TM to a flexible LAN segment, you must move the port 1 connection pulldown to that segment. The only reason ever to move port 2 to a flexible LAN segment would be to keep it on a segment that has access to the remote load host in the event the hub reboots. Upon rebooting, the DEChub 900MS Hub Manager saves the configuration of the backplane LAN segments and ensures that port 2 on the DECserver 900TM connects to the same LAN segment.

DECbridge Configuration Guidelines

Introduction This section describes some DECbridge and DECswitch configuration issues.

**DECbridge
900MX Port 3** You can connect port 3 of the DECbridge 900MX to the ThinWire or any of the Ethernet flexible channels. You can connect the other Ethernet ports only to the Ethernet flexible channels.

FDDI Configuration Guidelines


Introduction This section describes some FDDI configuration issues.

Types of FDDI Configurations The way you configure a backplane FDDI ring depends on the FDDI topology restrictions of the module's station configuration type. FDDI dual ring configurations must be one of two types:

Type 1 - A closed backplane ring (a collapsed ring) with no external A/B connections.

Type 2 - A backplane ring closed using external A/B connections.

Types Figure



LKG-9508-941

**FDDI Ring
Grayed Out**

HUBwatch, on each user connection request, automatically generates or updates the appropriate backplane ring configuration unless the current module Station Configuration type prevents the module from joining the ring. In such a case, the ring is grayed out when you select the module's FDDI pulldown.

Trunk Rings

HUBwatch V3.1 supports only Trunk Rings for FDDI backplane configurations. Backplane Tree configurations are not supported.

6

The HUBwatch GUI for Hubs and Modules

Using the GUI

Introduction

HUBwatch software is designed to make managing the hub and its installed modules easy. The graphic user interface (GUI) reflects this approach. When you run HUBwatch, the software displays a window containing a realistic diagram of the hub configuration. This window is called the Hub Front Panel window.

The menu bar on the Hub Front Panel window lets you get to other windows that you use to manage the hub configuration, SNMP communities, backplane configurations, polling, and other applications. You use a set of standard buttons to select options on a particular window.


You access summary windows for the network modules and their ports from the Hub Front Panel window by double clicking on a module or its ports.

Hub Front Panel Window

- Introduction** This window provides a graphic representation of your hub configuration. You get to all other HUBwatch windows from the Hub Front Panel window. From this window, You select pulldown menu options or you double click on modules and module ports to access module management windows.
- How to Open It** You see the Hub Front Panel window when you first start up HUBwatch. See Chapter 4 for instructions.

**Hub Front
Panel Window
Figure**

This is the Hub Front Panel view.




LKG-9460-941

Types of Views

| | |
|----------------------|--|
| Introduction | HUBwatch provides both a physical view and a logical view of the hub chassis from the Hub Front Panel window. Both views, physical and logical, allow you to double click on modules and module ports to access module management windows. |
| Physical View | The physical view depicts an exact representation of the hub's front panel, which can be useful in circumstances where a close correlation to the hub is needed. This view is particularly useful for troubleshooting the hub over the network. |
| Logical View | The logical view displays the same technical data as the physical view, but it uses a standard module template with labels and icons to distinguish module types. The logical view repaints the screen faster (because it has less fine detail). It is also easier to use to select individual ports because they appear larger. |

**Physical View
Figure**


This is a Front Panel physical view.



LKG-9467-941

**Logical View
Figure**

This is a Front Panel logical view.



LKG-9461-941

Hub Management Windows


When You Use Them

You use hub management windows to:

- Exit HUBwatch.
- Add modules to or delete modules from the configuration.
- Manage SNMP agents and community information.
- Change the view of the Hub Front Panel window.
- Create or delete backplane LAN segments and their connections.
- Monitor the physical environment of the hub.
- View and manage the message log.
- Set polling.
- Find Ethernet stations (including duplicate addresses).
- Get Help.

Hub Management Window Figure

This figure shows you the hierarchy of hub management windows.



LKG-9456-941

How You Open Them

You open hub management windows by pulling down options from the menu bar of the Hub Front Panel window. Some of the menu options have keyboard accelerators.

Menu Options

The following table describes the menus, their options, and keyboard accelerators.

| Menu | Option | Keyboard Accelerator | Function |
|---------------|-----------------------|----------------------|--|
| File | Exit | Ctrl/x | Dismisses HUBwatch. |
| Configuration | Add | Ctrl/a | Adds a module. |
| | Delete | Ctrl/d | Deletes a module. |
| Community | Manage Table | None | Displays the list of available SNMP agents and their communities. Used to add, delete, and modify agents and communities. |
| | Manage Current | None | Allows access to a summary window for the current agent. Used to add, delete and modify the current agent and its communities. |
| View | Logical | None | Displays a logical representation of the DEChub and its installed modules. The view is displayed in the Hub Front Panel window. |
| | Physical | None | Displays a physical representation of the DEChub and its installed modules. The view is displayed in the Hub Front Panel window. |
| | LAN Interconnect | None | Displays the LAN Interconnect window. You use this window to create LAN segments and connect modules to them. |
| | Environmental Summary | None | Displays chassis power and status information (DEChub 900 only). |

| Menu | Option | Keyboard Accelerator | Function |
|--------------|-----------------|----------------------|---|
| Options | Polling | None | Polling offers four options: Refresh, Enable, Disable, and Set up. |
| | Message Setup | None | Allows you to modify message log file parameters. |
| Applications | Find Address | Ctrl/f | Searches the SNMP agent's database for a particular Ethernet station. |
| | Find Duplicates | None | Searches the SNMP agent's database for duplicate Ethernet addresses. |

Lowercase You must type the keyboard accelerator as a lowercase letter.

Help Menu

The following table shows you which Help options you have and tells you about those options.

| Option | Function |
|----------------------|--|
| How to Manage | Provides a description of the GUI and the management tasks performed with HUBwatch. |
| Troubleshooting | Provides a list of common HUBwatch problems and their solutions. |
| Configuration Sheets | Provides checklists for configuring modules for use by HUBwatch |
| About | Provides a product overview and the software version and date. |
| Release Info... | Provides release notes, copyright information, information about new features, an online user questionnaire, and a list of management help topics. |

Context Sensitive Help

You can get context sensitive help for any window object by positioning the cursor on the object and pressing F1.

Reference

See Chapter 7 for instructions about using hub management windows. See Chapter 1 for a detailed description of the HUBwatch online help options and how to use them.

Module Management Windows

When You Use Them

You use module management windows to:

- Manage the DECagent 90 or the DEChub 900MS Manager.
- Manage bridges.
- Manage routers.
- Manage FDDI concentrators.
- Manage repeaters.
- Manage switches.
- Manage terminal servers.


How to Open Them

To open a particular module management window, double click on the module or one of its ports in the Hub Front Panel window.

To open the management window for the Hub Manager, select the Manage Current option from the Community menu on the Hub Front Panel window.

Module Management Window Figure

This figure shows the types of modules you can manage.



LKG-9459-941

Reference


See Chapter 7 for instructions about using the module management windows.

Network Module Icons


Each module management window has its own icon that shows the network module that the window manages. These are the network module icons.




Designates the Agent Summary window, which is used to display and manage the agent module.




Designates all windows used to display or manage repeater modules.




Designates all windows used to display or manage terminal server modules.




Designates all windows used to display or manage bridge modules.



Designates all windows used to display or manage brouter modules.



Designates all windows used to display or manage concentrator modules.



Designates all windows used to display or manage switch modules and the RoamAbout Access Point.

Standard Buttons

HUBwatch windows have a series of standard push buttons along the bottom. The following table lists the buttons and their functions.

| Button | Function |
|--|--|
| <input type="button" value="OK"/> | Executes requested changes and closes the current window. |
| <input type="button" value="Apply"/> | Executes requested changes. |
| <input type="button" value="Refresh"/> | Causes the HUBwatch software to poll the network modules for updated information. Some information is continuously updated if polling is on. See the Help text for the individual items to determine which items need to be refreshed. |
| <input type="button" value="Cancel"/> | Dismisses the current window and ignores requested changes. |
| <input type="button" value="Help"/> | Opens an online Help window that provides a brief description of major areas on the current window with crossreference hotspots to the context-sensitive help. The help information also includes a list of management tasks that you can perform using the window with crossreference hotspots to detailed descriptions of each task. |

7

Managing DEChubs and Modules

Using HUBwatch Windows

**Chapter
Structure**

This chapter describes hub and module management tasks as concepts. It also tells you how to navigate the management windows. This chapter does not include detailed information about performing a specific task.

**Task
Instructions**

You can find all the step-by-step instructions for doing management tasks in the *How to Manage...* section of the HUBwatch online Help. You access that help from one of the HUBwatch windows.

Reference

You can find more information about using online Help in Chapter 1.

HUBwatch Management Windows

Introduction

HUBwatch management windows let you manage:

- The hub and its configuration.
- SNMP communities and agents.
- Backplane LAN segments.
- Routers.
- DECconcentrator 900MX.
- DECserver 90L and 90L+ terminal servers.
- DECserver 90TL, 90TS, 90M, and 900 TM terminal servers.
- Hub environmental sensors.
- HUBwatch messages.
- 90-series repeaters (except the 90FS and 90TS).
- 900-series repeaters (including the 90FS and 90TS).
- 90-series bridges.
- 900-series bridges and switches (including RoamAbout Access Point).

Refer to the following tables for more information about accessing the different types of management windows.

Hub Management

Opening Hub Management Windows

You access the Hub Front Panel window when you start HUBwatch. You can get to the remaining hub management windows by clicking on the following menus in the Hub Front Panel window menu bar:

| Menu | Task |
|---------------|---|
| Configuration | Add and delete modules. |
| Community | Add or delete communities or agents View current agent information. |
| View | Select physical view or logical view. Use backplane LAN segments. Display the HUBwatch Messages window. Display chassis environmental information. |
| Options | Enable or disable Polling. Set the polling interval. |
| Applications | Find Ethernet Address or Duplicate Addresses windows. Modify the message log file defaults. |

Reference

The following table tells you how to find more information about each hub management task.

| Task | See |
|---|--------------------------|
| Add and delete modules. | Online Help |
| Add, delete, and modify communities or agents. View agent information. | Online Help Chapter 7 |
| Select physical or logical views | Chapter 6 |
| Use backplane LAN segments. | Online Help Chapter 5 |

| Task | See |
|--|-------------|
| Display HUBwatch messages. | Online Help |
| Display environmental information. | Online Help |
| Enable or disable polling. Set the polling interval. | Online Help |
| Modify message file defaults. | Online Help |
| Find Ethernet address. | Online Help |
| Find duplicate addresses. | |

SNMP Communities and Agents

Introduction

You manage SNMP communities and agents with the Community Table and Manage Current windows. The following table lists the available tasks and the windows you use to perform them.

Window-Task Table

| Window | Task |
|-----------------|---|
| Manage Current | Display agent information for the current agent. Modify the agent's location and contact. |
| Community Table | Add or delete an agent. Add or delete a community. Modify agents. Change the current agent or community. Modify the community information. Change the agent's hub type. Access remote agents. |

For instructions about performing any of the agent or community tasks, see the Help topic for that task.

Opening Agent Summary Windows

The way you access an Agent Summary window depends on the type of SNMP agent. There are two agent types:

- Modules with built-in SNMP agents, such as the DECagent 90 module or the DECserver 90TL module.
- The DEChub 900MS Hub Manager.

Do the following to open the Agent Summary window.

| Type of Agent | Steps |
|----------------|---|
| Built-in agent | From the Hub Front Panel window, click on the module you want. Then, choose Manage Current from the Community menu. |
| Hub Manager | From the Hub Front Panel window, choose Manage Current from the Community menu. To open the Agent Summary window for the Hub Manager itself, choose Manage Current from the Community menu when <i>no</i> modules are selected. For example, click on the blue background to deselect any selected module. |

Backplane LAN Segments

Introduction

You use the LAN Interconnect window to manage backplane LAN segments. The following table lists the available tasks and the windows you use to perform them.

Window-Task Table

| Window | Task |
|--------------------------------|--|
| LAN Interconnect | Create a LAN segment. Connect a module to a LAN segment. Disconnect a module from a LAN segment. Delete a LAN segment. Modify a network segment's characteristics. |
| LAN Interconnect Expanded View | Same options as LAN Interconnect window but used for modules with more than four backplane ports. |
| Station Configuration | Configure module ports between the front panel and the backplane. |
| Group View | Group module ports on 900-series repeaters. (V3.1 only supports the DEC repeater 900FP) |

For instructions about performing any of the interconnect tasks, see the Help topic for that task.

Opening the Backplane Management Windows

Do the following to open the LAN Interconnect window.

| Window | Steps |
|-----------------------|---|
| LAN Interconnect | Click on the View menu from the Hub Front Panel window. Next click on the LAN Interconnect option. |
| Station Configuration | Open the LAN Interconnect window. Select a DECbridge 900MX or DECconcentrator 900MX, then click on the Config button. You can also reach this window by clicking on the Station Configuration icon on the DECbridge 900MX or the DECconcentrator 900MX Summary windows. |
| Expanded View | Open the LAN Interconnect window. Click on the module you want to expand, then click on the Expand button. You can also reach this window by clicking on the LAN Interconnect icon on the DECbridge 900MX or the DECrepeater 900FP Summary windows. |
| Group View | Open the LAN Interconnect window. Click on the DECrepeater 900FP, then click on the Group button. You can also reach this window by clicking on the Group icon on the DECrepeater 900FP Summary window. |

DECconcentrator 900MX

Introduction

You use these windows to manage the DECconcentrator 900MX. The following table describes these windows and the tasks associated with them. For instructions about performing any of the concentrator management tasks, see the Help topic for that task.

Window-Task Table

| Window | Task |
|---------------------------|---|
| Hub Front Panel | Interpret concentrator LEDs. |
| Concentrator Summary | Display or assign the concentrator description. Configure the concentrator. Disable the concentrator. Display configuration information. Enable or disable concentrator ports. Display port information. Display network utilization. Display station information. Display MAC information. Reset the concentrator. Reset the concentrator to factory defaults. |
| Concentrator MAC Summary | Display MAC status. Configure token timer. Enable and disable the ring purger. Display port information. Display MAC information. |
| Concentrator MAC Counters | Display MAC counter information. |
| Concentrator Port Details | Display port information. Enable and disable ports. |

| Window | Task |
|-----------------------|--|
| Station Configuration | Configure ports between the backplane and the front panel. |

Opening Concentrator Windows

Do the following to open the concentrator windows.

| Window | Steps |
|---------------------------|--|
| Concentrator Summary | Double click on the concentrator module in the Hub Front Panel window. |
| Concentrator MAC Summary | Click on Summary in the Concentrator Summary window. |
| Concentrator MAC Counters | Click on Counters in the Concentrator Summary window. |
| Concentrator Port Details | Double click on the port PMD you want from the Port table in the Concentrator Summary window. Another method is to double click on a port on a Concentrator module from the Hub Front Panel window. |
| Station Configuration | Click on the Station Configuration icon in the DECconcentrator 900MX Summary window. |

90-Series Repeaters

Introduction You use these windows to manage 90-series repeaters (except the DECrepeater 90FS and 90TS). The following table lists the available tasks and the windows you use to perform them.

Hint You use these windows for DECrepeater 90 modules that are managed by the DECagent 90.

Window-Task Table

| Window | Task |
|-----------------------|--|
| Hub Front Panel | Interpret repeater LEDs. |
| Repeater Summary | Interpret repeater port connections. Display repeater summary information. Display port information. Assign the repeater description. Name repeater ports. Enable and disable repeater ports. |
| Repeater Port Summary | Display port information Name repeater ports Enable and disable repeater ports |

For instructions about performing any of the repeater tasks, see the Help topic for that task.

Opening 90-Series Repeater Windows

Do the following to open the 90-series repeater windows.

| Window | Steps |
|-----------------------|---|
| Repeater Summary | From the Hub Front Panel window, double click on a repeater module. |
| Repeater Port Summary | From the Hub Front Panel window, double click on a port on the Repeater module. Another method is to open the Repeater Summary window and double click on a port icon in the Port table. |

900-Series Repeaters

Introduction

You use these windows to manage the 900-series repeaters (including the DECrepeater 90FS and 90TS.) The following table describes these windows and the tasks associated with them

Window-Task Table


| Window | Task |
|---|--|
| Hub Front Panel | Interpret repeater LEDs. |
| Repeater Summary | Interpret repeater port connections. Display port information. Display repeater summary information. Assign the repeater description. Name repeater ports. Enable and disable repeater ports. Enable and disable repeater modules. Reset repeater modules. Configure repeater modules. |
| Repeater Port Summary | Display port information. Name repeater ports. Enable and disable repeater ports. Display repeater port performance statistics. |
| Repeater Port Details | Enable and disable repeater ports. Enable or disable link test administration status. Display Repeater Port counters. |
| Dual Port Redundancy (DECrepeater 90FS, 90TS, and 900FP only) | Set up redundant master and responder links. Display redundant link status. Modify redundant links. Remove redundant links. |

| Window | Task |
|----------------------------------|--|
| Repeater Security Summary | Set up repeater port security. Display repeater port security. Add or remove port authorization stations. |
| Repeater Security Intrusions Log | Display security intrusions for the Repeater module. Display security intrusions for a single repeater port. |
| Expanded View | Create a LAN segment. Connect a module to a LAN segment. Disconnect a module from a LAN segment. Delete a LAN segment. Modify a network segment's characteristics. |
| Port Grouping | Group module ports. (HUBwatch V3.1 only supports the DEC repeater 900FP) |


For instructions about performing any of the 900-series repeater tasks, see the Help topic for that task.

900-Series Repeater Window Push Button Icons


The 900-series repeater windows include the following push button icons.




Security—click on this push button to open the Repeater Security Summary window. The Repeater Summary window and the Repeater Port Summary window have this push button.




Security Intrusions—click on this push button to open the Repeater Security Intrusions Log window. The Repeater Summary window and the Repeater Port Summary window have this push button.



LAN Interconnect—click on this push button to open the LAN Interconnect window. The Repeater Summary window has this push button.



Dual-Port Redundancy—click on this push button to open the Dual-Port Redundancy window. The Repeater Summary window and the Repeater Port Summary window have this push button.



Port Grouping—click on this push button to open the repeater's Port Grouping window. The Repeater Summary window has this push button.

Opening 900-Series Repeater Windows

Do the following to open the 900-series repeater windows.

| Window | Steps |
|-----------------------|---|
| Repeater Summary | From the Hub Front Panel window, double click on a Repeater module. |
| Repeater Port Summary | From the Hub Front Panel window, double click on a port on the Repeater module. Another method is open the Repeater Summary window and click on a Port icon in the Port table. |
| Repeater Port Details | Open the Repeater Port Summary window and click on Details . |

| Window | Steps |
|----------------------------------|---|
| Repeater Security Summary | <p>Open the Repeater Summary window and click on the Security icon either in the Port table or in the Configuration list.</p> <p>Another method is to open the Repeater Port Summary window and click on the Security icon in the Security box.</p> |
| Repeater Security Intrusions Log | <p>Open the Repeater Summary or Repeater Ports Summary window and click on the Security Intrusions Log icon in the Configuration list box.</p> <p>Another method is to open the Repeater Security Summary window and click on the Security Intrusions Log icon in the Security Functions box.</p> |
| Dual Port Redundancy | <p>Open the Repeater Summary or Repeater Port Summary window and click on the DPR icon.</p> |
| LAN Interconnect Expanded View | <p>Open the Repeater Summary or Repeater Ports Summary window and click on the Expand icon.</p> |
| Port Grouping | <p>Open the Repeater Summary or Repeater Ports Summary window and click on the Group icon.</p> |

DECserver 90L and 90L+ Terminal Servers

Introduction

You use these windows to manage the 90L and 90L+ terminal servers. The following table describes these windows and their associated tasks.

Window-Task Table

| Window | Task |
|------------------------------|--|
| Hub Front Panel | Interpret LEDs. |
| Terminal Server Summary | Interpret port connector colors. Display port information. Assign the terminal server's description. Modify the 90L+ session prompt. Select a port. Select the device type. Name the port. Set the port speed. |
| Terminal Server Port Summary | Select a port. Select the device type. Name the port. Enable and disable autoconfigure. Modify <BREAK> Passthru. Enable and disable remote modify. Enable and disable 90L+ on-demand load. Display Port counters. |
| Terminal Server Counter | Display Terminal Server counters. |

For instructions about performing any of the terminal server tasks, see the Help topic for that task.

Opening the Terminal Server Windows

Do the following to open the terminal server windows.

| Window | Steps |
|------------------------------|--|
| Terminal Server Summary | From the Hub Front Panel window, double click on the terminal server module you want to use. |
| Terminal Server Counters | Open the Terminal Server Summary window and click on the <input type="button" value="Counters"/> push button. |
| Terminal Server Port Summary | From the Hub Front Panel window, double click on the terminal server port you want to use. Another method is to open the Terminal Server Summary window and click on the MMJ Connector of the port you want to use. |

DECserver 90TL, 90M, and 900TM Terminal Servers

Introduction

You use these windows to manage the 90TL, 90M, and 900TM terminal servers. The following table describes these windows and their associated tasks.

Window-Task Table

| Window | Task |
|------------------------------|--|
| Hub Front Panel | Interpret LEDs. |
| Terminal Server Summary | Interpret port connector colors. Display port information. Display session summary information. Enable and disable ports. Set IP forwarding. Assign the terminal server's description. Select a port. Select the admin origin. Name the port. Set the port speed. View maximum number of sessions. View input and output flow control |
| Terminal Server Port Summary | Display port counters. Select the admin origin. Name the port. Set the port speed, with split speeds. Set maximum number of sessions. Set input and output flow control type. Set bits per character. Select parity. |
| Terminal Server Session | Display terminal server session information. Disconnect a session. |

| Window | Task |
|--------------------------|-----------------------------------|
| Terminal Server Counters | Display Terminal Server counters. |

For instructions about performing any of the terminal server tasks, see the Help topic for that task.

Opening the Terminal Server Windows

Do the following to open the terminal server windows.

| Window | Steps |
|--------------------------------|---|
| Terminal Server Summary | From the Hub Front Panel window, double click on the terminal server module you want to use. |
| Terminal Server Counters | Open the Terminal Server Summary window and click on the Counters push button. |
| Terminal Server Port Summary | From the Hub Front Panel window, double click on the terminal server port you want to use. Another method is to open the Terminal Server Summary window and click on the RJ45 Connector of the port you want to use. |
| Terminal Server Session Detail | From the Terminal Server Summary window, click on a port's Session Information push button in the Port table. |

90-Series Bridges

Introduction

You use these windows to manage 90-series bridges. The following table describes these windows and their associated tasks.

Window-Task Table

| Window | Task |
|----------------------|---|
| Bridge Summary | Display port information. Assign the bridge description. Disable bridge ports. Display spanning tree attributes. |
| Bridge Port Summary | Show status. Disable bridge ports. Display spanning tree attributes. |
| Bridge Port Detail | Show traffic statistics and Error counters. Disable bridge ports. |
| Bridge Filtering | Set protocol filtering. Add Ethernet protocols. Delete protocols. |
| Bridge Spanning Tree | Display spanning tree attributes. |
| Bridge Forwarding | Display forwarding database. Set forwarding database. |
| Bridge Traffic | Display traffic statistics in bar graph format. |


For instructions about performing any of the bridge management tasks, see the Help topic for that task.

Bridge Summary Window Icons


The Bridge Summary window uses icons to label push buttons in the More Information box. Clicking on these push buttons activates other bridge management windows. These are the Bridge Summary icons.




Bridge Forwarding—click on this icon in the Bridge Summary window to open the Bridge Forwarding window.



Bridge Protocol Filter—click on this icon in the Bridge Summary window to open the Bridge Protocol Filter window.



Bridge Spanning Tree—click on this icon in the Bridge Summary window to open the Bridge Spanning Tree window.



Bridge Traffic—click on this icon in the Bridge Summary window to open the Bridge Traffic window.

Opening Bridge Windows

Do the following to open the bridge windows.

| Window | Steps |
|----------------------|---|
| Bridge Summary | From the Hub Front Panel window, double click on a Bridge module. |
| Bridge Forwarding | From the Bridge Summary window, click on the Forwarding icon in the More Information box. |
| Bridge Filtering | From the Bridge Summary window, click on the Protocol Filter icon in the More Information box. |
| Bridge Spanning Tree | From the Bridge Summary window, click on the Spanning Tree icon in the More Information box. |
| Bridge Traffic | From the Bridge Summary window, click on the Traffic Detail icon in the More Information box. |
| Bridge Port Summary | From the Hub Front Panel window, double click on a bridge port. Another method is to open the Bridge Summary window and click on a port in the Port Information box. |
| Bridge Port Detail | Open the Bridge Port Summary window and click on Details . |

900-Series Bridges and Switches (including RoamAbout Access Point)

Introduction

You use these windows to manage 900-series bridges and switches including the RoamAbout Access Point. The following table describes these windows and their associated tasks. For instructions about performing any of the bridge management tasks, see the Help topic for that task.


Window-Task Table

| Window | Task |
|-------------------------|---|
| Hub Front Panel | Interpret bridge LEDs. |
| Bridge Summary | Display or assign the bridge description. Display bridge status information. Display management agent information. Display spanning tree attributes. Display port attributes and status. Enable or disable forwarding on a port. Reset the bridge. Reset the bridge to factory defaults. |
| Bridge Port Information | Display Port counters. Display bridge configuration changes. |
| Address Filter | Create address filters. Modify address filters. Delete address filters. Create a default filter. Write a list of filters to a file. Display the last port seen for each filter. |


| Window | Task |
|------------------------------------|--|
| Protocol Filter | Create protocol filters. Modify protocol filters. Delete protocol filters. Create default protocol filters. Write a list of filters to a file. |
| Forwarding Database | Display forwarding database status information. Locate specific database entries. Write the contents of the forwarding database to a file. |
| LAN Interconnect. Expanded view | Create a LAN segment. Connect bridge ports to LAN segments. Disconnect bridge ports from LAN segments. Delete a LAN segment. Modify a network segment's characteristics. |
| Station Configuration | Configure bridge and FDDI concentrator ports between the front panel and the backplane (DECbridge 900MX only). |
| Bridge Configuration | Set bridge configuration parameters Add and remove entries from the Bridge Trap Address table. |
| FDDI Summary | Access any of the FDDI windows (DECbridge 900MX only). |

Bridge and Switch Summary Window Icons


The Bridge Summary window uses icons to label push buttons in the More Information box. Clicking on these push buttons activates other bridge and switch management windows. These are the Bridge and Switch Summary icons.




Forwarding—click on this icon in the Bridge Summary window to open the Forwarding window.




Address Filtering—click on this icon in the Bridge Summary window to open the Address Filtering window.




Protocol Filtering—click on this icon in the Bridge Summary window to open the Protocol Filtering window.




LAN Interconnect Expanded View—click on this icon in the Bridge Summary window to open the LAN Interconnect Expanded View window.



Configuration—click on this icon in the Bridge Summary window to open the Bridge Configuration window.



FDDI Summary—click on this icon in the Bridge Summary window to open the FDDI Summary window.



Station Configuration—click on this icon in the Bridge Summary window to open the Station Configuration window.

Opening Bridge Windows

Do the following to open the bridge windows:

| Window | Steps |
|--------------------------------|---|
| Bridge Summary | From the Hub Front Panel window, click on a Bridge module. |
| Bridge Port Information | From the Bridge Summary window, click on a port connector. Also, from the Hub Front Panel physical view, double click on a port connector. From the Hub Front Panel logical view, click on the Port button. |
| Bridge Forwarding | From the Bridge Summary window, click on the Forwarding icon in the More Information box. |
| Bridge Address Filtering | From the Bridge Summary window, click on the Address Filtering icon in the More Information box. |
| Bridge Protocol Filtering | From the Bridge Summary window, click on the Protocol Filtering icon in the More Information box. |
| Bridge Configuration | From the Bridge Summary window, click on the Bridge Configuration icon in the More Information box. |
| LAN Interconnect Expanded View | From the Bridge Summary window, click on the LAN Interconnect icon in the More Information box. |
| Station Configuration | From the Bridge Summary window, click on the Station Configuration icon in the More Information box. |
| Any FDDI Window | From the Bridge Summary window, double click on the FDDI icon. The FDDI Summary window allows you to reach the other FDDI windows. |

Brouters

Introduction

You use these windows to manage brouters. The following table describes these windows and their associated tasks.


Window-Task Table

| Window | Task |
|-------------------------|--|
| Hub Front Panel | Interpret brouter LEDs. |
| Brouter Console | Configure the brouter. |
| Brouter Summary | Display port status. Assign brouter name. Select port. Name a brouter port. |
| Brouter Port Summary | Display port status. Display port protocol information. Name a Brouter port. |
| Brouter Health Counters | Display brouter counters. |
| TELNET Console Window | Access Brouter Console Control functions. |


For instructions about performing any of the brouter management tasks, see the Help topic for that task.

Brouter Icons

Brouter icons label push buttons in the More Information box on the Brouter Summary window. Clicking on these push buttons activates other brouter windows. These are the Brouter icons.



Brouter Console—click on this icon in the Brouter Summary window to open the Brouter Console window.



Brouter Counters—click on this icon in the Brouter Summary window to open the Brouter Counters window.

Opening Brouter Windows

Do the following to open the brouter windows:

| Window | Steps |
|-------------------------|---|
| Brouter Summary | From the Hub Front Panel window, double click on a Brouter module. |
| Brouter Port Summary | From the Hub Front Panel window, double click on a brouter port. Another method is to open the Brouter Summary window and double click on a Port icon in the Port table. |
| Brouter Console | From the Brouter Summary window, click on the Console icon in the More Information box. |
| Brouter Health Counters | From the Brouter Summary window, click on the Counters icon in the More Information box. |

A

Troubleshooting Tips

Troubleshooting

In This Appendix

This appendix contains some solutions to the following types of problems:

- General display problems.
- Terminal server problems.
- Community problems.
- Agent problems.
- Performance problems.

Other Troubleshooting Information

Refer to your hub or module owner's manuals for additional information.

General Display Problems

Incorrect Displays with New Hub Installation

Problem:

You installed a new hub, but when you start the HUBwatch software and display the Hub Front Panel window, one or more of the modules installed in the hub are either not displayed or not manageable.

Solution:

Refer to the *HUBwatch Installation and Configuration* manual and follow the instructions to ensure that you perform all required configuration procedures correctly.

Display Problems with New Module Installation

Problem:

You installed additional modules standalone or in an existing hub, but when you start the HUBwatch software and display the Hub Front Panel window, one or more of the modules installed in the hub are either not displayed or not manageable.

Solution:

Refer to the *HUBwatch Installation and Configuration* manual and follow the instructions to ensure that you perform all required configuration procedures correctly.

Terminal Server Problems

Incorrect Display with New Terminal Server

Problem #1:

You added a terminal server to your hub configuration, but when you access the Terminal Server Summary window, the connectors are shown in black. (The ports are enabled, but no devices are attached to the port.)

Problem #2:

You added a terminal server, but when you try to access the Terminal Server Summary window, you get a pop-up warning that the module is being polled or managed by another user.

Solution:

You need to verify the MAC address of the terminal server. An incorrect MAC address can cause either of these conditions. If the MAC address is correct, reload or update the device firmware.

Terminal Server Display Disappears

Problem:

You added a DECserver 90TL to the hub configuration and, at first, it appeared on the screen as though it were in the hub, but then it disappeared.

Solution:

When a DECserver 90TL first boots, it operates using its own PROMs, and it responds to DECagent 90 backplane identification commands. The PROMs then receive a downline load image, and control is transferred to the new image. The new image does not respond to the backplane identification commands, making it seem to the DECagent 90 that the DECserver 90TL has been removed.

Although the DECserver is removed from the screen, it is functional. You must manually add the 90TL module to the hub and using the Add Module window being sure to set Polling Status to Disabled. Refer to *(Opening Hub Management Windows)* in Chapter 7 for instructions about using the Add Module window. Additionally, you must add the

DECserver 90TL to the Agens file. See *SNMP Communities and Agents* in Chapter 7 for instructions for adding an agent.

Disconnecting Ports Causes Warning

Problem:

You added a terminal server, but when you attempt to disconnect a port, you keep getting a pop-up warning about the server being polled or managed by another user.

Solution:

1. Be sure the DECserver 90L or 90L+ module is not in the Authorized/Manager mode.
2. You may not have the correct module installed. Make sure that the module is a DECserver 90L or 90L+.

Terminal Server Parameters Not Taking Effect

Problem:

Sometimes when you set parameters on a terminal server, they do not take effect.

Solution:

It is possible to issue a SET request followed closely by a GET request. When using terminal servers, these two commands generate a large amount of communications activity. The GET requests may happen faster than the SET requests in the terminal server, giving the appearance of a SET request failure. If you wait a few seconds and click on or , you will probably find that your SET has worked.

Also, remember to click either on to execute any change or on to execute the change and close the window.

Community Problems

Community Strings Not Displayed

Problem:

When you access the Community Table window and select an agent, you do not see any community strings.

Solution:

Check the following:

- Your agent may be unreachable. Check the network connections.
- You may have set a filter on the bridge that prevents access to the agent.
- Another hub could be using that agent for management.
- You could have accidentally deleted the agent from the community.
- The name of the default community could be entered incorrectly. Check the Community Name field of the agent. (The default community is usually named “public.”) Try using public as the community name.

If none of these conditions apply, and you still do not have any community strings, try the following:

1. Try a soft reset of the DECagent 90.
Turn off power to the agent, then turn it on again.
2. Try a factory reset.
Attach a terminal to the agent console port. From the Console menu, select the [21] Restore Factory Settings option. This reset makes the agent forget everything it knows about any communities except for itself in the community “public.”

**New
Community
Strings
Discarded**

Problem:

You can access the Community Table window, but when you attempt to add a new community, the new community string is discarded.

Solution:

Be sure you are entering a unique community string. If you attempt to create a new community using a name that already exists in another community, HUBwatch ignores your request.

Agent Problems

New Agent Does Not Appear in Community Table

Problem:

You added a new agent to the Agent list on the Community Table window. You exited the window and when you opened the Community Table window again, the new agent was gone.

Solution:

Remember to click on either to execute any change or on to execute the change and close the window.

Agents Not Remembered

Problem:

The HUBwatch software does not remember all of its agents automatically.

Solution:

HUBwatch stores the agent list in the Agent file. Currently, there is no way to add an agent automatically to the file and to the Agent table in the Communities Table window. Therefore, this information must be added manually to the HUBwatch software.

Performance Problems

HUBwatch Runs Slowly

Problem:

The HUBwatch software seems to be running slowly.

Solution:

The following conditions can cause poor HUBwatch performance:

- Heavy network traffic can cause a slowdown. HUBwatch needs to use the network to communicate with each module. To improve performance, keep the station running HUBwatch in the same bridge Workgroup as the agent and use the bridge to filter all unnecessary traffic from the Workgroup side.
- Make sure that you configure your management station with the appropriate system parameters. See *HUBwatch Installation and Configuration* for system configuration information.

Hint

Managing a hub full of repeaters can slow down the network. Every time you poll the hub, HUBwatch must ask for and receive many variables. This is especially true if there are many stations connected to the repeaters.

HUBwatch Shows An Empty Hub

Problem:

When the network is busy, sometimes the HUBwatch software shows you a view of an empty hub, even though a short time before a populated hub was displayed.

Solution:

When your network is very busy, you may want to increase the agent's Retry or Timeout values. The agent will be more persistent in its attempts to get the information that you need, but HUBwatch performance may suffer.

B


HUBwatch Summary Windows









Summary Window Figures

**In This
Appendix**

This appendix contains example figures of the summary windows you use to manage hubs and their modules.

Figure B-1 90-Series Repeater Summary Window


| Identification | | Management Information | Status |
|---|-------------------------------|-------------------------|----------------|
|  90FL Slot 6 | Reg Name: | Agent Slot: 7 | Status On-line |
| | Description: DECrepeater 90FL | IP Address: 00.00.00.00 | |
| | Type: DECrepeater 90FL | Community: public | |
| | Revision: VERSION1 | Access: read-write | |
| | Ports: 4 | Up Time: 619:07:03 | |

| Connected Stations List | | | |
|--|---|------------------|-----------------|
| 1   gee1 | No Connected Stations | | |
| 2   gee2 | No Connected Stations | | |
| 3   gee3 | <table border="1"> <tr> <td>64.246 ANDERS</td> <td>64.833 SKUNK</td> </tr> </table> | 64.246 ANDERS | 64.833 SKUNK |
| 64.246 ANDERS | 64.833 SKUNK | | |
| 4   gee4 | No Connected Stations | | |

| | | | | |
|----|-------|---------|--------|------|
| OK | Apply | Refresh | Cancel | Help |
|----|-------|---------|--------|------|


LKG-9520-94I

Figure B-2 900-Series Repeater Summary Window



LKG-9510-94I

Figure B-3 90L and 90L+ Terminal Server Summary Window





LKG-9514-941







Figure B-4 90-Series Bridge Summary Window

▼ ▲

Bridge Summary

| Identification | Management Information | Status |
|--|--|--|
|  <p>Reg Name: N/A Description: DECBRIDGE90 Type: DECbridge90 Revision: HW=V1.0 ROM=V1.0 SW=V3.0</p> | <p>Agent Slot: 7 IP Address: 00.00.00.00 Community: public Access: read-write</p> | <p>Module State: On-line NVRAM Test: OK Up Time: 4 21:26:02 WG Size: 3 HUB Mgmt: <input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF</p> |

| Spanning Tree Information | Problem Counters | More Information |
|--|---|--|
| <p>Root: 08-00-2b-00-00-00 Root Cost: 10 Protocol Specification: IEEE 802.1d Mode LB100 Compatibility: AutoSelect</p> | <p>Topology Changes: 0 Spanning Tree Mode Changes: 3 WG Exceeded: 0</p> |  |


| Port ID | Bridge Address | Admin Status | Oper | Port State | Fwd Ratio | Spanning Tree Algorithm |
|-----------|-------------------|---|---|------------|-----------|--|
| Backbone | 08-00-2b-00-00-00 |  |  | Forwarding | 45 |  |
| WorkGroup | 08-00-2b-00-00-00 |  |  | Forwarding | 67 |  |

LKG-9513-94

Figure B-5 Brouter Summary Window

Brouter Summary

Identification



Reg Name: Brouter1
 Description:
 Type:
 Revision:
 Interfaces: 3



Slot 1

Management Information







IP Address: 00.00.00.00
 Community: public
 Access: read-write
 Up Time: 117:10:31
 Contact:
 Location:

More Information

Brouter

Port Table

| Port ID | Name | Admin Status | Oper Status | In Pkts/Sec | Out Pkts/Sec |
|-----------|----------|---|---|-------------|--------------|
| Ethernet0 | Ethernet |  |  | 13 | 0 |
| Serial0 | Sync Po |  |  | 0 | 0 |
| Serial1 | Sync Po |  |  | 0 | 0 |

OK

Apply

Reset

Refresh

Cancel

Help

LKG-9512-941

Figure B-6 900-Series Bridge Summary Window

▼ ▲
DB900 Summary:netdoc:slot 3

Identification

Reg Name:

Description:

Type: DECbridge 900MX

Revision: DECbridge 900MX, 6

Interfaces: 7

Slot 3

Management Information

IP Address: 16.20.224.5

Community: public

Status

Up Time: 21 23:29:29

Rate Limiting: Disable, 400pkts./sec.

Mgmt Port: 7

Spanning Tree Information

Root:

Root Cost:

Priority:

Topology Changes: 1074

Protocol: IEEE 802.1D

Mode Changes: 2

Hello Time(sec.): 1

Max. Age Time(sec.): 15

Forward Delay Timer(sec.): 30

More Information

▶▶

↔
Address

↔
Protocol

⊙
FDDI

📊

📦

📊

Port Information Time Interval(sec.): 1

| Port ID | Fwding Enable | State | Path Cost | Frames In Pkts/Sec | Frames Out Pkts/Sec | Filtered % |
|-------------------|-------------------------------------|-------|---------------------------------|--------------------|---------------------|---|
| 08-00-2b-a3-4a-db | <input checked="" type="checkbox"/> | ↔ | <input type="text" value="10"/> | 0 | 126 | <input type="text"/> |
| 08-00-2b-a3-4a-dc | <input checked="" type="checkbox"/> | — | <input type="text" value="10"/> | 0 | 0 | <div style="width: 20px; height: 10px; background-color: black;"></div> |
| 08-00-2b-a3-4a-dd | <input checked="" type="checkbox"/> | ↔ | <input type="text" value="10"/> | 0 | 0 | <input type="text"/> |

OK

Apply

Refresh

Reset

Factory


Cancel



Help

LKG-9509-941



Figure B-7 DECconcentrator 900MX Summary Window

Concentrator Summary:16.20.224.4:slot 1

| Identification | Management Information | Status |
|--|--|--|
|  <p>Reg Name: <input type="text"/></p> <p>Description: <input type="text"/></p> <p>Type: DECconcentrator 900MX</p> <p>Revision: HW=v0,RO=v1.0,SW=hazel_f</p> <p>Slot 1</p> | <p>Agent Slot: 1</p> <p>IP Address: 16.20.224.4</p> <p>Community: public</p> <p>Access: read-write</p> | <p>OperState: Enabled</p> <p>CF State: CWrapA</p> <p>ECM State: In</p> <p>Resets: 2011791475</p> <p>Up Time: 205 9:53:16</p> |

| Station Information | MAC Information | Configuration |
|---|---|--|
| <p>Station ID: 00-00-08-0-2b-a1-ea-08</p> <p>Station Type: DAC</p> <p>Optical Bypass: Present</p> <p>Master Cut: 5</p> <p>Non-Master Cut: 2</p> <p>Report Policy:</p> <p><input type="checkbox"/> Report</p> <p><input type="checkbox"/> Do not Report</p> <p><input type="button" value="Connection Policy"/></p> <p><input type="button" value="Timers"/></p> | <p>MAC State: On-Ring Run</p> <p>Current Path: Primary</p> <p>MAC Address: 08-00-2b-a1-ea-08</p> <p>UNA: 08-00-2b-a1-ea-02</p> <p>DNA: 08-00-2b-a3-86-c5</p> <p>Network Utilization</p>  <p><input type="button" value="Summary"/> <input type="button" value="Counters"/></p> |  <p style="text-align: center;">Root Primary</p> |

Port Information

| Neighbor Type | Reject Reason |
|---|--|
|  | <p>1  No Reason</p> |

LKG-9511-941

Glossary

This glossary is a comprehensive source of definitions for HUBwatch terms and acronyms.

active port

A redundant repeater port over which communication is currently taking place. An active port is enabled and handles any communication between the connected repeater ports.

administration status

The desired state. In contrast, the operational state is the current state.

agent

A background task running on the object being managed. The agent responds to requests for information by the network management stations (NMS). The agent is responsible for performing GET and SET operations, for generating the appropriate traps, and for performing access control.

Agent file

A file that contains a list of Simple Network Management Protocol (SNMP) agents that can be used to manage hubs and network modules.

Aging time

A spanning tree parameter that controls how long a bridge keeps each learned entry in the forwarding database. If an entry is stored longer than the aging time, the bridge marks that entry as Inactive and allows it to be overwritten.

alarms

Conditions in a hub or a community for which the alarms software monitors. The conditions are detected by polling a predetermined list of MIBs on each type of network module. When a MIB value changes, the alarms software generates an alarm. For example, topology changes, security violations, and frames discarded are considered alarm conditions.

Alarms agent file

Contains a list of Simple Network Management Protocol (SNMP) agents that are polled for alarm events. For each agent, the file contains the agent name, IP address, community name, polling interval, and the types of events (configuration changes, traps, and alarms) that are enabled. Each time you add, delete, or modify entries in the Alarms Agents list box and apply the change, this file is updated. Each time you refresh the Alarms Setup window by clicking on the push button, this file is used to restore entries in your Alarms Setup window to their last saved conditions.

algorithm

A computational design that determines how values for a particular object are determined.

authorized stations

An addressable node on a local area network (LAN) capable of transmitting, repeating, and receiving data.

Always Forward

Always Forward is the second of the three priority states assigned to GIGAswitch filters. The priorities for GIGAswitch filtering states are, in order of precedence:

1. Always Filter
2. Always Forward
3. Filter

A state of Always Forward applies, explicitly, only to the white cells in a filter. The state means: "Always allow packets to pass through the input/output pattern indicated by white cells—unless another filter with a state of Always Filter overrides this instruction."

Always Filter

Always Filter is the highest of the three priority states assigned to GIGAswitch filters. The priorities for GIGAswitch filtering states are, in order of precedence:

1. Always Filter
2. Always Forward
3. Filter

A state of Always Filter applies, explicitly, only to the black cells in a filter. The state means: "Always and unconditionally block packets exhibiting the input/output pattern indicated by black cells." Since Always Filter is the highest state, no other filter can override this instruction.

attachment unit interface (AUI)

An Ethernet station is sometimes connected to the network through an AUI, which is a 15-pin Ethernet or DIX connector.

autodiscovery

The capability of the hub chassis and its associated firmware to detect, identify, and configure certain network modules when they are installed in the hub. Modules that the hub cannot autodiscover must be added manually to the hub's configuration using either the hub's Console Setup port or the HUBwatch Add Module window.

autopartition

To disable a repeater port automatically.

The autopartition algorithm protects the network from certain fault conditions that would halt all LAN communications (for example, a media short or break, a faulty connector, or faulty or missing media termination). If it detects such faults on any of its ports, the repeater isolates the faulty segment from the network.

A repeater does not respond to input received from an autopartitioned port, except to determine whether or not the fault condition has been removed. However, a repeater continues to transmit data to an autopartitioned port.

backbone

A core network (usually high speed) to which multiple local area networks (LANs) are connected using bridges or routers and over which internetwork traffic can pass.

Bad Hello

If a designated bridge receives a Hello message on the port on which it is designated, and the message contains worse root information, the message is called a Bad Hello message.

bandwidth

A measure of the amount of traffic the media can handle at one time. In digital communications, describes the amount of data that can be transmitted over the line in bits per second.

BootP

A protocol that is used by a network node to determine the Internet Protocol (IP) address of its Ethernet interfaces in order to use network booting.

Break character

A character that switches you from a service node session to the terminal server local mode. If you are using a modem to connect to a service node through a terminal server, and the modem interprets the Break signal as a command to end a dial-in connection to the terminal server, you must specify a local switch character, or Break character to use in place of your terminal's Break key when you want to return to the terminal server local mode.

<BREAK> Passthru

A terminal server port characteristic that determines whether or not the port responds to a local or remote break.

bridge

An intelligent, protocol-independent, store-and-forward device that operates as a Data Link layer relay. Used to connect similar or dissimilar local area networks (LANs). LANs connected by bridges are referred to as extended LANs.

brouter

A bridge with minimal routing capabilities. In general, a brouter can deliver least-cost routing; some can also deliver minimal load balancing.

chassis

The physical housing of the hub.

click

The action of pressing and releasing the mouse button while the cursor is pointing at an object on the user interface.

Clock card

The Clock card provides the clock signals for the GIGAswitch System. It also performs these functions:

- Provides central arbitration of the backplane bus.
- Identifies the presence, model number, and type of modules in slots 1-6 and 9-14.
- Stores management parameters.

The Clock card contains the out-of-band management port. This card is always installed in slot 7 of the GIGAswitch.

community

A set of attributes that are managed as a group. Community names are used to control access. Each software request contains a community name that is used by the agent like a password to verify that the requester is authorized to access the agent's management information base (MIB) or a subset of that MIB.

Community names indicate whether or not the requester has read-only or read-write authority.

In Digital's implementation, MIBs are defined by the agent and include:

- Community name.
- Internet address of the hardware from which the agent accepts requests.
- Community type (read-only, read-write).

- The MIB variables to be accessed.

community string

A text string, also referred to as a community name, that is used as a password by an SNMP agent to authenticate or verify that the network management station (NMS) making the request is allowed access to the contents of the agent's management information base (MIB).

concentrator

The FDDI concentrator is a Physical layer repeater that allows the attachment of multiple single attachment stations, dual attachment stations, or other concentrators to the FDDI network.

Config(uration) Changes

Changes to SNMP agents within a hub or a community. A community can consist of one module or one to eight hubs. The following are a few examples of configuration changes:

- A module is removed from or installed in a hub.
- One or more ports on a module are disabled.
- The module's operating status MIB changes state.

Configuration Management

Configuration Management is that portion of connection management that provides for configuration of PHY and MAC entities within a station.

context-sensitive help

A form of user information in which a program shows the user information about the current command or operation being attempted. Because it provides details about the work at hand without requiring the user to leave the program, context-sensitive help is particularly useful when the user is either learning a new program or using an unfamiliar program feature.

CRC

A Cyclic Redundancy Check. A method of detecting errors in a frame by performing a mathematical calculation of the number of bits in the frame and appending the result to the end of the frame. The receiving station performs the same calculation on the frame and then checks that the result matches the CRC at the end of the frame.

Crossbar Switch card

The Crossbar Switch card provides interconnection between the ports on the GIGAswitch, enabling multiple connections to exist simultaneously. This card is always installed in slot 8 of the GIGAswitch.

datagram

A unit of data passed between the transport and the network Services layer.

DECnet

The Digital networking software that runs on nodes in both local and wide-area networks.

DECnet address

A series of numbers that identifies a device's location in the DECnet network.

DECnet name

A unique alphanumeric string that identifies a device on the DECnet network.

DECwindows Motif

The environment used to run HUBwatch windows.

destination address

The field in a frame that contains the address of the station to which the frame is being sent.

device

A network element external to the hub.

Can also refer to computer equipment (for example, a printer, terminal, or personal computer) that is attached to a terminal server port.

Data In circuit (DI)

Sourced by the MAU, the DI is a differential pair consisting of DI-A (Data In circuit A) and DI-B (Data In circuit B). A data receive circuit from the MAU to the DTE (for example, a repeater). For a complete description, refer to ISO 8802-3 ANSI/IEEE Standard 802.3.

Data Out circuit (DO)

Sourced by the DTE, the DO is a differential pair consisting of DO-A (Data Out circuit A) and DO-B (Data Out circuit B). A data transmit circuit from the DTE (for example, a repeater) to the media access unit (MAU). For a complete description, refer to standard ISO 8802-3 ANSI/IEEE Standard 802.3.

dialog box

The windows in which you enter or view information.

double click

The action of quickly pressing and releasing a mouse button twice.

double hub

Two eight-slot hubs daisy-chained together. A double hub is treated as a single hardware device and is represented by a single community.

downline load

The process of sending a software image from a load host to the bridge.

Downstream Neighbor Address

The terms "upstream" and "downstream" refer to the relative position of stations on the FDDI ring.

The downstream neighbor address is the MAC address of an FDDI station's downstream neighbor. A station is "downstream" from its neighbor if it receives the token *after* the neighbor receives it (that is, if the station *receives* the token from its neighbor).

drag

The action of pressing and holding down the mouse button, then moving the mouse across a surface, carrying the cursor across the work area.

DSAP

A Destination Service Access Point.

DSR

A Data Set Ready.

DTR

A Data Terminal Ready is a control signal that enters a modem from the data terminal or communications device that is using the modem. When the signal is set, it informs the modem that the data terminal equipment is ready to receive and transmit data.

Dual attachment station

An FDDI station that offers two connections to the FDDI dual counter-rotating ring. FGL2 cards can accommodate up to 2 dual attachment stations; FGL4 cards accommodate only single attachment stations.

Entity Coordination Management (ECM) state

The ECM controls the optical bypass switch of the Physical Media Dependent (PMD) layer and signals the physical control management (PCM) when media is available. The ECM starts the PCMs for the A and B ports in the station when the optical bypass is complete. In concentrators, ECM also starts the PCMs associated with M ports.

Ethernet

A network communications system developed and standardized by Digital, Intel™, and Xerox®, using baseband transmission, CSMA/CD access, logical bus topology, and coaxial cable.

Ethernet station

An addressable node on an Ethernet network capable of transmitting, repeating, and receiving data.

exit

The action of ending a session by clicking on the Exit push button.

fan tray

The GIGAswitch system houses two fan trays. Each fan tray assembly contains two fans. Their purpose is to cool the system. Like the power supply units, the fan tray units can be hot-swapped.

FDDI

The Fiber Distributed Data Interface. A set of ANSI/ISO standards that defines a high-bandwidth (100-Mb/s), general-purpose, local area network (LAN) connection between computers and peripheral equipment in a timed-passing, dual ring of trees configuration.

FDDI station

A node on an FDDI ring capable of transmitting, receiving, and repeating data. A station has one instance of SMT, at least one instance of PHY and PMD, and an optional MAC entity.

FGL2 card

A type of line card containing 4 ports and 2 FDDI stations. FGL2 cards can support both SAS (Single Attachment Stations) and DAS (Dual Attachment Stations) and PMD daughter cards. On an FGL2 card, each station has one A and one B port.

FGL4 card

A type of line card containing a maximum 4 ports and 4 FDDI stations. FGL4 cards can support only SAS (single attachment station) and PMD daughter cards. On an FGL4 card, each SAS is normally connected to a different FDDI ring. Each station has one S port associated with it.

Filter

Filter is the lowest of the three priority states assigned to GIGAswitch filters. The priorities for GIGAswitch filtering states are, in order of precedence:

1. Always Filter
2. Always Forward
3. Filter

A state of Filter applies, explicitly, only to the black cells in a filter. The state means: "Always block packets exhibiting the input/output pattern indicated by black cells—unless another filter with a state of Always Forward overrides this instruction."

Filter state

Every GIGAswitch filter has a state associated with it. Filter states determine how they will be applied by the switch, and ultimately determine how individual filters will work together to produce a combined result. The priorities for GIGAswitch filtering states are, in order of precedence:

1. Always Filter
2. Always Forward
3. Filter

flow control

A terminal server port characteristic that allows a terminal server to start and stop data transfer between the terminal server port and the attached device.

FOIRL

Fiber-optic inter-repeater link.

forwarding database

Maintained by a bridge, a table that contains a list of addresses and the bridge line number on which the address can be reached. The bridge creates its forwarding database through learning (noting the source line and source address of each incoming frame).

frame

A group of digits transmitted as a unit, over which a coding procedure is applied for synchronization.

Front Panel view

A graphic of the hub chassis (either the DEChub 90 or DEChub 900) and its installed network modules. The Front Panel view comes in two varieties:

- **The physical view:** Displays an exact representation of the hub chassis, the installed modules, and all the physical characteristics of the modules.
- **The logical view:** Displays a graphic representation of the modules. It offers a consistent look for modules from different vendors.

FRU

A Field Replaceable Unit.

GET

A Simple Network Management Protocol (SNMP) request in which the named instance is retrieved if the community string matches. If the community string does not match, an error is returned.

GIGAswitch

An intelligent multiport FDDI bridge that forwards packets among a set of connected data links. The GIGAswitch is a standalone modular device that uses both distributed and centralized processing algorithms to perform these ANSI and IEEE 802.1d bridging functions:

- Forwarding.
- Filtering.

- Learning.
- Aging.
- Spanning tree.

GIGAswitch filters

GIGAswitch filters are based on the source address, destination address, or protocol ID of packets passing through the switch. The switch uses user-designed filters to determine whether to block or forward packets passing through it. In cases when the switch determines that a packet may be forwarded, the process determines what ports it may forward them through.

GIGAswitch slot

The physical slot in the GIGAswitch chassis. The GIGAswitch contains 14 slots, 11 of which can accommodate FGL2 or FGL4 line cards. The remaining 3 slots are reserved for the Clock card, the Crossbar Switch card, and the Switch Control Processor card.

GUI

The graphic user interface. A type of display format that allows the user to choose commands, start programs, and see lists of files and other options by pointing to icons and list of menu items on the screen. Generally, choices can be generally activated either with the keyboard or with a mouse. Graph user interfaces are used by the HUBwatch application.

grayed out

A field or option that is not available in a particular instance.

Hello interval

A spanning tree parameter that controls how often a bridge sends a Hello message.

Hello messages

A Hello message determines which bridges are elected as designated bridges and which bridge becomes the root bridge. When the spanning tree computation is complete, the root bridge originates the Hello message and the other bridges propagate it down the spanning tree.

hot-swap

To "hot swap" a component means to remove and replace it while the system is in operation. Any of the GIGAswitch line cards, the fan trays, and the power units can be hot swapped without affecting operation of the switch. Modules that cannot be hot swapped are the:

- Crossbar Switch card.
- Switch Control Processor card.
- Clock card.

hub

A central device, usually in a star topology local area network (LAN), to which each network module is attached.

Hub Manager

A microprocessor-based controller used to monitor, configure, and control the hub. Under either remote management control or default local control, the Hub Manager provides a central point for allocation of hub resources to hub-mounted network modules.

ICMP

The Internet Control Message Protocol. A simple reporting protocol for Internet Protocol (IP).

icon

A pictorial representation on a user interface used to indicate an object (for example, a network module).

Idle signal (IDL)

The media access unit (MAU) sends an `input_idle` message to the data terminal equipment (DTE) on the Data In circuit when the MAU does not have data to send. The physical realization of the `input_idle` message is the Idle signal. Thus, the Idle signal lets the DTE know that the MAU is functioning properly. For a complete description, refer to standard ISO 8802-3 ANSI/IEEE Standard 802.3.

IEEE

The Institute of Electrical and Electronics Engineers.

in-band management

The managing of a device over a network.

IP

The Internet Protocol. The network protocol offering a connectionless-mode network service in the Internet suite of protocols.

IP address

The Internet Protocol address. The address is a series of numbers that identifies a device's location on the Internet.

IP forwarding

The forwarding of IP packets between interfaces (ports) on a DECserver 90TL, 90M, or 900TM.

IP name

The Internet Protocol name. A unique, alphanumeric string that identifies a device on the Internet.

label

An inactive Windows symbol that identifies a control.

LAN

The local area network. A data communications network that spans a limited geographical area. The network provides high-bandwidth communication over coaxial cable, twisted-pair, fiber, or microwave media.

LAN segment

The portions of the DEChub 900MS backplane that are organized in either a bus, ring, or point-to-point configuration.

LAT

The local area transport. A communications protocol used in a local area network.

LB100

The LANbridge 100.

LED

A light emitting diode. A source of status on a network module.

listening mode

The state in which a bridge identifies the addresses of messages received from the network.

link loss

A link-loss condition occurs when the Keep-Alive signals are no longer received between two media access units (MAUs).

Line card

GIGAswitch Line cards provide the packet input/output ports for the GIGAswitch system. These cards forward packets with known destination addresses. Packets with unknown destinations are forwarded to the SCP for further consideration.

list box

A Windows object that displays a list, such as available modules, from which a user can select. List boxes can include scroll bars to allow users to move through lists that are too long to be displayed in the list box.

loopback

When it receives data on the Data Out circuit (DO), the media access unit (MAU) returns that data to the data terminal equipment (DTE) on the Data In circuit (DI). This action constitutes a loopback function.

low light

Low light refers to the intensity of the light detected by a fiber-optic media access unit (MAU). When the intensity of the light drops to such a low level that the error rate reaches an unacceptable level, the low-light condition is said to exist.

MAC address

A unique, 48-bit, binary number (usually represented as a twelve digit hexadecimal number) encoded in a device's circuitry to identify it on a local area network.

management agent

See SNMP agent.

map

The file that contains all the pictures for one network.

manual mode

The condition in which a bridge does not learn addresses but uses only addresses you specify because you have created a filter for all unspecified addresses.

master mode

Master mode designates a pair of repeater ports (primary and secondary) that control a redundant link. Because the remote ports, or responder ports, to which the master ports are connected must be on the same LAN or are otherwise bridged together, only one of the master ports may be enabled at a time.

matrix

A user-designed, storable pattern of inputs and outputs that maps to GIGAswitch ports. Each GIGAswitch filter is based on one and only one matrix.

MAU

A media access unit. Applies to connections to a token ring.

Media Access Control layer

In FDDI (and other types of shared-medium LANs) the Data Link layer sublayer responsible for scheduling, transmitting, and receiving data.

menu

The list of options in a window.

menu item

The list of options available under each menu from which you can make a selection.

MIB

A Management Information Base. A dynamic, virtual collection of data about a managed object. The managed object provides the data to the network management station (NMS), which gathers the values from the managed object and loads them into the MIB representing the object.

MJ8 connector

A port on a DECserver 90TL, 90M, and 900TM.

MMJ connector

A port a DECserver 90L or 90L+.

module

An interchangeable unit that provides functionality and interconnection to a local area network (LAN) through the hub.

See also network modules.

MOP Session

A logical connection using the Maintenance Operation Protocol (MOP).

mouse

The device used to move the cursor around the HUBwatch windows.

mouse button

On the mouse device, a button used for selecting, dragging, and pointing at objects.

multicast

A type of network addressing that enables a node to send messages or data packets to an address that represents a group of stations rather than a single station.

multiswitch backplane

A backplane that allows flexible allocation of its signals so that multiple local area network (LAN) segments can be managed. The DEChub 900 has a multiswitch backplane.

network

A collection of computers, terminals, and other devices together with hardware and software that enables the exchange of data and sharing of resources over short or long distances.

Network layer

Layer 3 of the OSI model, which permits communications between network nodes in an open network.

network management

In the OSI model, the five functional application areas of accounting management, configuration management, fault management, performance management, and security management.

network management application

A collection of software tools that provides information about the network by communicating with agent software in the managed objects.

network modules

The hardware devices that gather data to be reported to the hub. Modules include front panel status and diagnostic LEDs, connections to the hub, a serial service port, and a MAC interface.

NMS

The network management station. An OpenVMS™, UNIX®, or ULTRIX™ workstation, or an IBM® PC, or IBM PC-compatible workstation supplied with an Ethernet, FDDI, or token ring network module and HUBwatch software, which enables it to communicate with and manage network modules.

no loopback

See Loop.

node

Any intelligent device that communicates with other devices in the network.

NVRAM

The nonvolatile random access memory.

OBM

The out-of-band management. Management of a network module or the DEChub 900MS backplane over a telephone line or direct line to a console port rather than over the network.

ODL

The On-Demand Load. An Asian terminal's use, through a DECserver 90L+, of the On-Demand Loading (ODL) font protocol to override flow control, while fonts are being down loaded to the terminal.

OID

The registered Object ID (OID) of the device.

option button

The small circular area within a dialog box that represents a choice. Click on an option button to select your choice. You can select only one option button from a group of option buttons.

partition

A repeater port is said to be partitioned when it is management disabled or autopartitioned.

PC

A personal computer.

PC Type

A variable that specifies the type of downstream port being managed by the GIGAswitch port's physical connection management facility. The four different Port connector types are:

- A - The port is a dual attachment station or concentrator that attaches to the primary in and secondary out when attaching to the dual ring.
- B - The port is a dual attachment station or concentrator that attaches to the secondary in and the primary out when attaching to the dual ring.

- S - Either one port in a single attachment station or one port in a single attachment concentrator.
- M - A port in a concentrator that serves as a master to a connected station or concentrator.

physical connection management

That portion of connection management that manages the physical connection between adjacent PHYs. This includes the signaling of connection type, link confidence testing, and enforcement of connection rules.

PDU

A Protocol Data Unit. A data object exchanged by protocol layers that contains both protocol control information and user data.

Physical Layer Protocol

A Fiber Distributed Data Interface (FDDI) standard that defines symbols, line states, clocking requirements, and the encoding of data for transmission.

physical topology

The actual arrangement of cables and hardware that make up the network.

Physical Layer Medium Dependent

FDDI standards that define the media and protocols to transfer symbols between adjacent PHYs.

power supply

The power supply uses regulated 48 Vdc power to energize the discrete power modules located on each logic card, and 12 to 26 Vdc power to energize the fans. The GIGAswitch can also accommodate a redundant power supply unit.

Like the fan trays, GIGAswitch power supply units can be hot-swapped.

protocol

A formal set of rules governing the format, timing, sequencing, and error control of exchanged messages on a data network. May also include facilities for managing a communications link or contention resolution.

A protocol may relate to data transfer over an interface, between two logical units directly connected, or on an end-to-end basis between two end users over a large and complex network. There are hardware protocols and software protocols.

protocol filtering

A feature in which some bridges can be programmed to always forward or always reject transmissions that are originated under specified protocols.

proxy access

The way a proxy Simple Network Management Protocol (SNMP) agent provides requests to the network management station (NMS). A proxy agent acts on behalf of network devices that do not support SNMP. When such a network module is to be managed, the NMS contacts the proxy agent and indicates the identity of the network module. The proxy agent translates the protocol interactions it receives from the NMS into interactions that are supported by the network module.

pulldown menu

A menu that is displayed when a user presses a mouse button and the pointer is positioned on a menu name in the menu bar.

push button

A round box containing text. By clicking the mouse on the text, you select the function. For example, clicking on the Help push button takes you to the help for the current window.

radio button

A diamond shape that precedes text and allows you to make a choice. By clicking on the radio button, you select the option.

rate limit

The total number of frames on all ports allowed by a bridge per second.

registered name

The name by which the network management application (for example, POLYCENTER SNMP Manager) recognizes a node.

release

An action used in conjunction with drag. After dragging the mouse, you release the mouse button.

repeat

A station receives a frame or token from an upstream station, retimes it, and places it on the ring for its downstream neighbor. The repeating station can examine the frame, copy it to a buffer, or modify control bits in the frame as appropriate.

repeater

A level 1 hardware device that performs the basic actions of restoring signal amplitude, wave form, and timing of signals, before transmission on another network segment.

responder port

A redundant repeater port that connects to either a master primary or a secondary port. Because responder ports are always enabled, no action is taken to switch ports in case of link failure. However, a responder port does detect and report link failures to its partner (master primary or master secondary) port by continuously pulsing its fiber transmit LED on and off. If the master port connected to the responder port is active, the responder port treats this event as a link failure and causes a link failover. Link failures include the following conditions:

- Autopartitioning.
- Management disable.
- Carrier loss.

responder mode

This mode designates ports that connect to master mode ports. Responder ports are always enabled but are active only when their master port is active. A key function of the responder port, other than receiving and transmitting data, is to report link failures to the master port. When the master port detects a link failure, it causes the link to failover to the standby link.

If the standby link is not available when the active link fails, the failover process waits until it is available. If the previously active link becomes available during this waiting period, the master returns to using it. Otherwise, the failover to the standby link takes place as soon as the standby link is good. Thus, the highest utilization possible on a dual-port redundant link is achieved.

ring

The connection of two or more stations in a circular logical topology. Information is passed sequentially between active stations, where each one in turn, examines or copies the data, and returns it to the originating station, which removes the data from the network.

root bridge

The bridge in an extended local area network that controls the network configuration by originating Hello messages.

The spanning tree algorithm determines the root bridge by comparing the bridge IDs for all bridges in the extended LAN. The root bridge is the bridge with the lowest bridge ID (root priority and hardware address).

root priority

A spanning tree parameter that determines a bridge's priority for becoming the root of the logical spanning tree. The Root Priority parameter value is used as a prefix to the bridge's address to form the bridge's identification (for example, 128/08-00-2B-2C-08-21).

secondary port

A redundant master repeater port that is placed in the standby state when redundant ports are configured.

scroll bar

The bar used to move from left to right and up and down within a window or dialog box.

scroll box

The rectangular portion of the scroll bar that moves either up or down or right or left to indicate the direction you are scrolling.

select

The action of choosing a menu item or symbol by clicking on it.

server

A network node or specialized device that provides and manages access to shared network resources, such as hard disks, printers, and software.

service node

A node with which a terminal is able to establish a session through a terminal server port.

session

A logical connection between a terminal and a service node.

session origin

The port characteristic on a DECserver 90TL, 90M, or 900TM that determines where a session on a port can originate.

SET

A Simple Network Management Protocol (SNMP) request in which the named instance is modified if the community string matches.

shielded twisted-pair

A cable composed of two insulated wires, twisted together and surrounded by a braided metal shield or foil under the outer insulation.

Single attachment station

An FDDI station that offers one S port for attachment to the FDDI ring. FGL4 cards can accommodate up to 4 single attachment stations. On an FGL4 card, each station maps to a single port.

single hub

An eight-slot hub(as opposed to a double hub which is two eight-slot hubs daisy-chained together).

SLIP

The Serial Line Internet Protocol, used for transmitting IP packets across serial lines.

SNMP

The Simple Network Management Protocol. A high-level, standards-based protocol for network management, usually used in TCP/IP networks.

SNMP agent

An entity in a hardware device that executes SNMP requests.

SNMP MIB II

The Simple Network Management Protocol Management Specification for managers of 802.5/Token Ring systems. Uses TCP/IP as the transport stack.

source address

The network address of the station that transmitted the data to the network.

spanning tree

A method of creating a loop-free logical topology on an extended local area network (LAN). Formation of a spanning tree topology for transmission of messages across bridges is based on the industry-standard spanning tree algorithm defined in IEEE 802.1d.

spanning tree algorithm

A computation that determines how a spanning tree topology is formed.

spanning tree mode

Determines whether or not a bridge is using a loop-free logical topology.

split speed

A DECserver 90TL, 90M, or 900TM port characteristic of having different input and output speeds.

SQE

Signal quality error.

standalone module

A network module in a single configuration.

standby port

A redundant repeater port that is configured as a backup port to an active port. A standby port is disabled and is held in readiness in case the active port fails.

Station Management

The entity within a station on the FDDI ring that monitors and exercises overall control of station activity.

Switch Control Processor card

The GIGAswitch Switch Control Processor card performs various management and spanning tree functions. In addition, the card forwards multicast packets and packets with unknown destination addresses.

TCP

The Transmission Control Protocol. The transport protocol offering a connection-oriented transport service in the Internet suite of protocols.

TELNET

A commercial wide-area network with thousands of local dial-up numbers. TELNET provides log-on services to a variety of commercial, online, computer services, such as Dialog Information Services and CompuServe.

terminal server

A module that allows a terminal to connect to a network node.

text entry box

A Windows dialog box control that allows you to enter text in a structured area.

title bar

An area at the top of a Windows display that contains the name of the application and sometimes additional information.

token ring

A network with a ring topology that passes data-bearing tokens from attached stations to the next. The original protocol developed by IBM was succeeded by the IEEE 802.5 standard for token ring network communications.

topology

The logical or physical arrangement of nodes on a network.

trap

Messages generated by firmware in Simple Network Management Protocol (SNMP) agent hardware. The firmware monitors the hardware for faults and sends messages to monitoring software. For the HUBwatch application, the Alarms Poller software communicates with the SNMP agents in a hub or a community and arranges for specific traps to be sent to the network management station running the HUBwatch application. The Trap table in the Alarms Definition file determines which traps to monitor. Cold start, warm start, and authentication failure are examples of traps monitored by the alarms software. The Alarms Poller software uses Internet Protocol (IP) addresses and community names to communicate with specific SNMP agents, such as the DECagent 90, the Hub Manager, and modules with built-in SNMP agents.

Unicast

A type of network addressing that enables a node to send messages or data packets to a single node on the network.

UDP

The User Datagram Protocol. The transport protocol offering a connectionless-mode transport service in the Internet suite of protocols.

upstream neighbor address

The terms "upstream" and "downstream" refer to the relative position of stations on the FDDI ring.

The upstream neighbor address is the MAC address of an FDDI station's upstream neighbor. A station is "upstream" from its neighbor if it receives the token *before* the neighbor receives it (that is, if the station *passes* the token to its neighbor).

window

A portion of the screen used for displaying information.

Workgroup

A group that consists of a relatively small number of devices attached to a LAN that is isolated from the extended LAN backbone by a bridge or a router.

XOFF

A transmission control character indicating transmission off.

XON

A transmission control character indicating transmission on.

Index

A

Access control, 3-4
Adding agents, 3-3, 4-1
Agent, 7-5
 file, 3-3
 file address, 3-3
 file compatibility, 4-1
 list, 3-9
Applications menu, 6-10
Audience, 1-1

B

Backplane LAN segments, 5-1
Bridge modules, 1-11
Brouter modules, 1-11
Built-in
 agent, 3-2
 agent community, 3-5

C

Choosing hubs, 3-3
Colors, 5-4
Communities
 of the current agent, 3-10
Community, 3-5, 7-5
 table, 3-8, 3-12
Community menu, 6-9
Configuration
 example 1, 5-10
 example 2, 5-12
 example 3, 5-18

Configuration (cont'd)
 example 4, 5-23
 guidelines, 5-29, 5-33
 station, 5-6
Configuration menu, 6-9
Connecting 900-series modules, 5-8
Connecting 90-series modules, 5-8
Connector not working, 5-7
Current agent, 3-9
Current community, 3-9

D

DECagent 90, 3-2
 community, 3-4
 in DEChub 900MS, 3-5
 setup, 3-5
DECbridge 90, 3-5
DECbridge 900MX, 5-35
DEChub 90
 overview, 1-10
DEChub 900
 overview, 1-10
 using a DECagent 90, 3-5
DECrepeater 90FS, 5-29
DECserver 900TM restrictions, 5-33
DECserver load host, 5-33
Definition, 1-1

E

Expand button, 5-6
Expanded view, 5-6

F

- FDDI configurations, 5-36
- FDDI rings, 5-37
- Firmware updates, 1-2, 1-9
- Flexible channel, 5-1
- Front panel
 - hub, 6-2

G

- Grouping ports, 5-6

H

- Help menu, 6-11
- Hub
 - front panel, 6-2
 - management tasks, 6-7
 - management windows, 6-9
 - manager, 3-2, 3-10
 - manager community, 3-5
- HUBwatch
 - explanation, 1-1
 - management abilities, 1-10
 - overview, 1-1
 - startup, 4-1
 - uses, 1-2
 - using, 1-3

I

- Identification list, 3-9
- In-band management, 2-1, 2-2
- IP address, 2-3, 4-1

L

- LAN
 - interconnect, 5-3, 5-9
 - segments, 5-1, 5-2, 5-4, 7-7
- LAN segment
 - guidelines, 5-28

M

- Management
 - methods, 2-1
 - tasks, 7-1
 - windows, 7-2
- Managing
 - Agent
 - opening agent summary window, 7-5
 - opening community table window, 7-5
 - Bridge
 - opening bridge windows, 7-23, 7-27
 - Brouters
 - opening brouter windows, 7-29
 - Concentrator
 - opening concentrator windows, 7-10
 - Hub, 6-7
 - opening windows, 7-3
 - LANs
 - backplane LAN segments, 5-1
 - hardware overview, 5-1
 - LAN interconnect window, 5-3
 - 90-series repeater
 - opening repeater windows, 7-12
 - 900-series repeater
 - opening windows, 7-15
 - Terminal server
 - opening terminal server windows, 7-18, 7-20
 - Using the GUI, 6-1
 - Applications menu, 6-10
 - Community menu, 6-9
 - Configuration menu, 6-9
 - Help menu, 6-11
 - Options menu, 6-9
 - standard buttons, 6-16
 - View menu, 6-9
- MIB, 3-1
- Module management windows, 6-12

N

- Network
 - modes, 1–10
 - module icons, 6–14
 - modules, 5–4
- Network modules
 - supported, 1–11

O

- OBM port, 2–5
- Opening
 - Agent Summary window, 7–5
 - backplane management windows, 7–8
 - bridge windows, 7–23, 7–27
 - brouter windows, 7–29
 - Community Table window, 7–5
 - concentrator windows, 7–10
 - hub management windows, 7–3
 - 90-series repeater windows, 7–12
 - 900-series repeater windows, 7–15
 - terminal server windows, 7–18, 7–20
- Options menu, 6–9
- Out-of-band management, 2–1, 2–5

P

- Port grouping restriction, 5–7
- Proxy agents, 2–4

R

- Related information, 1–2, 1–4, 1–12, 3–12
- Repeater
 - loops, 5–30
 - modules, 1–11
 - restriction, 5–29

S

- SLIP, 2–5, 4–10
- SNMP, 7–5
 - agent, 3–1, 3–2
 - communities, 3–4
 - HUBwatch uses, 3–1
- SNMP community management
 - agents, 3–9
- SNMP Community Management
 - communities, 3–10
- Software environment, 1–2
- Standard buttons, 6–16
- Startup, 4–1
- Station configuration, 5–6
- Summary windows, B–1
- Supported
 - devices, 1–10
 - modules, 1–11

T

- Terminal server ports, 5–33
- Troubleshooting tips, A–1
- Trunk rings, 5–37

U

- Using the GUI
 - applications menu, 6–10
 - Applications menu, 6–10
 - Community menu, 6–9
 - Configuration menu, 6–9
 - Help menu, 6–11
 - Options menu, 6–9
 - standard buttons, 6–16
 - View menu, 6–9

V

- View menu, 6–9

W

Workgroup modules
 proxy agent, 3-2